



Document Display

Search :

[Back to Results](#)**ODA - Oracle Database Appliance - How to Setup ILOM [ID 1393191.1]**[To Bottom](#)

Modified: Dec 12, 2012

Type: HOWTO

Status: PUBLISHED

 Comments (0)

Priority: 3

Applies to:

Oracle Appliance Kit - Version 2.1.0.1 and later
Information in this document applies to any platform.
ODA , ILOM , BIOS,

Goal

In this note we will provide to visual examples of how to:

- Configure your ILOM -- This note
- Use BIOS to set a CORE count (not to be confused with CORE Count via MOS) -- companion note

Fix**Oracle Database Appliance - ILOM Setup
Prepared by: Farhat Safi
01/06/12**

1. Press "F2" during bootup process to get into BIOS settings (May have to repeatedly press "F2" after powering ON)