












Ⓜ️TODO: check jack normalization



Use jumper to select noise or sub to output on the extra out jack.



Shielding pairs  
DO NOT GROUND ON UI BOARD!



Use these jumpers to ground critical default inputs to ground if needed.

- Ⓜ️ H1 MountingHole
- Ⓜ️ H2 MountingHole
- Ⓜ️ H3 MountingHole
- Ⓜ️ H4 MountingHole
- Ⓜ️ H5 MountingHole

Shmørgerh

Sheet: /  
File: vco-ui.kicad\_sch

**Title: Moduleur VCO UI**

Size: A4 Date: 2025-12-11  
KiCad E.D.A. 9.0.6

Rev: v1.0  
Id: 1/1