


[IQ8] How to fix Wifi(2015_0311)

1. Copy IQ8_FixWiFi.apk to SDCard or USB Disk



P.S my example is use USB Disk

2. Plug in USB or SDCard to IQ8

P.S my example is use USB Disk


3. Install IQ8_FixWiFi.apk APP to IQ8

3.1. Open “FX” APP




3.2. Click “usbdisk0”

P.S If you have USB Disk, can see “usbdisk” (my example is USB Disk)




3.3. Click will be install APP(my example is install “IQ8_FixWiFi.apk”)




3.4. Install APP


3.4.1. If you see this screen, please click “Settings” button




3.4.2. Click “Unknown sources”




3.4.3. Click “OK”




3.4.4. Check have select “Unknown sources”




After click back button



3.4.5. Click “install”



3.5. If install success, can see “Done” and “Open” button




4. Use IQ8_FixWiFi.apk fixWiFi question

4.1. open “IQ8_FixWiFi” on Desktop




4.2. click “WiFi Config 1” button

P.S 00:0A:F5:89:89:FF is error code, will to fix




4.3. click “OK” button



4.4. click “OK” button


P.S if config chang is success, your system will reboot



5. Check your WiFi can link
6. Check Mac Address format is success
P.S Correct format is 60:02:B4:XX:XX:XX

Unresolved:

P.S 00:0A:F5:89:89:FF is error code



Solve

P.S Correct Mac format is 60:02:B4:XX:XX:XX

