


# HowToUseHotkeyOnMT8382


## 1. Default hotkey config:

P.S If you device not barcode device, T key will not function




## 2. Custom define hotkey config


### 2.1. Open APP (MT8382HotkeyDefine)



## 2.2. Open Custom Hotkey item




## 2.3. Setting 1 key




Click APP


P.S My example is select "Brower APP"



Setting Key 1 success can see this photo




## 2.4. Setting 3 key




Click APP

P.S My example is select “File Manager”




Setting Key 3 success can see this photo




## 2.5. Save your config

Click Save button



After reboot device


P.S If setting end, **need reboot devices**




## 2.6. Verify

P.S Press 1 key and 3 key verify function

P.S My example result , press 1 key should start Brower APP




P.S My example result , press 3 key should start File Manager APP




### 3. Clear Custom define

#### 3.1. Open APP (MT8382HotkeyDefine)




After you can see old config


P.S My old config example is “Brower” and “File Manager”



#### 3.2. Click “Set Default Config” button



After **need reboot** device




### 3.3. Verify

P.S 1 Key should not function


P.S 3 Key should not function

### 4. Use default Hotkey


#### 4.1. Open APP (MT8382HotkeyDefine)



#### 4.2. Off Custom Hotkey item




After need reboot



#### 4.3. Verify

P.S Hotkey setting should is default config

P.S If you device not barcode device, T key will not function



5. End