

nav_core::BaseGlobalPlanner



```
classDiagram
    RRTPlanner --|> nav_core::BaseGlobalPlanner
```

The diagram illustrates a class hierarchy. At the top is a white rectangular box with a thin gray border containing the text 'nav_core::BaseGlobalPlanner'. Below it is a gray rectangular box with a black border containing the text 'RRTPlanner'. A solid blue arrow points vertically from the top center of the 'RRTPlanner' box to the bottom center of the 'nav_core::BaseGlobalPlanner' box, indicating that RRTPlanner inherits from BaseGlobalPlanner.

RRTPlanner