

<p>(1) M8x1.0 Heat Set Insert (for proximity sensor)</p> <p>Proximity Sensor</p>	<p>(1) M6x80 Socket Head Cap Screw</p> <p>Main Axle</p>	<p>(3) M6x30 Socket Head Cap Screws</p> <p>(1) Tension Cam Axle</p> <p>(2) Mount Screws</p>	<p>(1) M3x18 Socket Head Cap Screw</p> <p>Tension Cam Spring Mount</p>
<p>(1) M4x8 Socket Head Cap Screw</p> <p>Tension Cam Stop</p>	<p>(4) M3x12 Socket Head Cap Screws</p> <p>Motor Mount Screws</p>	<p>(2) M3x16 Socket Head Cap Screws</p> <p>Camera and Drop Tube Set Screws</p>	<p>(1) 5x5x30 Stainless Steel Tension Spring</p> <p>Tension Cam Spring</p>
<p>(1) M3 Nut (tension cam mount lock)</p> <p>Spring Mount Nut</p>	<p>(1) 5mm Motor Flange with lock screws</p> <p>Motor Flange Coupler</p>	<p>(4) M3x12 Phillips Pan Head</p> <p>Flange Gear Mount Screws</p>	<p>(2) 626zz Bearings</p> <p>Feed Wheel Bearings</p>
<p>(3) M3x8 Socket Head Cap Screws</p> <p>(2) Homing Sensor Mount</p> <p>(1) Light Shade Set Screw</p>	<p>(1) M3 Heat Set Insert</p> <p>Light Shade Lock</p>	<p>(1) .3x4x20mm Compression Spring</p> <p>Homing Sensor</p>	