




# USER MANUAL



## RF Magic Controller

- Safety information**
- Supply voltage of this product is DC12V, never connect to other high voltage.
  - Never connect two wires directly in case of short circuit.
  - Lead wire should be connected correctly according to colors that connecting diagram.
  - Warranty of this product is Two year, but excludes the artificial situation of damaged.



Connecting diagram