



[illegible]

SPI




Remove shunt only for Programming ICE.

Restore shunt for programming Flash and for normal operation.



PMOD AND I/O PINS



REGULATOR CONNECTION

