

ENR 3.3 AREA NAVIGATION (RNAV) ROUTES

Route designator Name of sig- nificant points Coordinates	Track MAG Rev Track MAG Length (NM)	Upper limit Lower limit Airspace class	Direction of cruis- ing levels		RNP Type	Remarks
			Odd	Even		
1	2	3	4		5	6
UR784						
▲ NIDOS 13°04'00"S 026°51'06"E						
	<div>027°</div> <div>206°</div> <div>70 NM</div>	<div>UNL</div> <div>FL245</div> <div>Class A</div>	<div>↓</div>	<div>↑</div>	(RNP 10)	Two-way radio contact to be maintained with ATC in these airspaces. Solwezi Approach avail- able HJ as a relay sta- tion. Lusaka Control Frequency. 120.500Mhz 123.925Mhz 8888.0Khz 8873.0Khz 6586.0Khz
▲ ENKOT 11°59'32"S 027°19'33"E						
Two-way radio contact to be maintained with Area Control.						

THIS PAGE  
INTENTIONALLY  
LEFT BLANK