

**Part Number: PT767-35B20****Kit Contents**

Item #	Quantity Req'd.	Description
1	1	Molle Panel; Interior
2		
3		

**Hardware Bag Contents**

Item #	Quantity Req'd.	Description
1		
2		
3		

**Additional Items Required For Installation**

Item #	Quantity Req'd.	Description
1		
2		
3		

**Conflicts**

4-door "Double Cab" Tacoma
----------------------------

**Recommended Tools**

<b>Personal &amp; Vehicle Protection</b>	<b>Notes</b>
<b>Special Tools</b>	<b>Notes</b>
<b>Installation Tools</b>	<b>Notes</b>
Torque Wrench	0-10 Nm
T30 Torx Bits	
<b>Special Chemicals</b>	<b>Notes</b>

**General Applicability**

MY24 and newer Tacoma, HV (2 door "XtraCab")
--

**Recommended Sequence of Application**








Item #	Accessory
1	
2	
3	

\*Mandatory

**Vehicle Service Parts** (may be required for reassembly)

Item #	Quantity Req'd.	Description
1		
2		
3		

**Legend**

	<b>STOP:</b> Damage to the vehicle may occur. Do not proceed until process has been complied with.
	<b>OPERATOR SAFETY:</b> Use caution to avoid risk of injury.
	<b>CAUTION:</b> A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	<b>TOOLS &amp; EQUIPMENT:</b> Used in Figures calls out the specific tools and equipment recommended for this process.
	<b>REVISION MARK:</b> This mark highlights a change in installation with respect to previous issue.
	<b>SAFETY TORQUE:</b> This mark indicates that torque is related to safety.
	<b>REGULATORY MARK:</b> This mark indicates the component is related to regulatory compliance

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.

## 1. Access the Cab Rear



(a) Be careful during installation to prevent scratching of vehicle truck bed. Cover the truck interior with blankets if necessary.

(b) Lift up on the passenger seat adjustment bar to slide the passenger seat all the way forward. (Fig 1-1).



Fig. 1-1

(c) Pull the rope handle to lay the passenger seat backrest down flat. (Fig 1-2).



Fig. 1-2

(d) In the rear of the cab, locate the interior storage compartment. (Fig 1-3).



Fig. 1-3



- (e) Pull up on the silver latch to drop the hatch to access the rear storage compartment. (Fig 1-4).




## 2. Install Interior Molle Panel

- (a) Locate the 6 mounting holes in the rear storage compartment. (Fig 2-1).




- (b) Align the molle panel's attachment bolts to the mounting holes and hand start each bolt into the threads in the order shown. (Fig 2-2).



- (c) Use a T30 Torx to torque the (x6) molle panel attachment bolts to 10 N-m in the sequence numbered. (Fig 2-3).

# TOYOTA TACOMA, HV 2024 - HARD ORGANIZER

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
<u>Accessory Function Checks</u>  <input type="checkbox"/> Verify parts:  <input type="checkbox"/> Verify torque:  <input type="checkbox"/>  <input type="checkbox"/>	  Removed items have been discarded & replaced items are in place  All bolts are properly torqued to 10 N-m.
<u>Vehicle Function Checks</u>  <input type="checkbox"/>  <input type="checkbox"/>  <input type="checkbox"/>	
<u>Vehicle Appearance Check</u>  <input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.	  Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMNA Accessory Quality Shipping Standard.)