


SYNTHIAM


Assembly Instructions

Infrared Camera + Wide Angle Lens Rev 2




PARTS & TOOLS



#	Qty	Name
1	1	HDF-3M-811-WX13 EZ-Robot Camera
2	1	Daylight Filter
3	1	100° Wide Angle Lens (Infrared filter removed)
4	1	Tweezers



Step 1. Place the Daylight Filter on top of the camera CCD



IMPORTANT Ensure the Infrared filter is removed from the lens



Focused Position

Step 2. Thread the 100° Wide Angle Lens into the Camera housing until the focused position has be achieved



Infrared Camera is now complete!