


# SYNTHIAM

## Assembly Instructions

*Visible Light Camera + Wide Angle Lens Rev 3*


### PARTS & TOOLS

#	Qty	Name
1	1	HDF-3M-811-WX13 EZ-Robot Camera
2	1	100° Wide Angle Lens with 850nm Infrared filter
3	1	Black permanent Marker






**\*IMPORTANT\*** Ensure the 850nm Infrared filter is present




Focused Position

**Step 1.** Thread the 100° Wide Angle Lens with Infrared filter into the Camera housing until the clear focus position has been achieved.



**Step 2.** Turn the camera over and place a black mark on the orange flexible PCB with the marker



**Visible Light Camera is now complete!**