


1-2 Roller Clutch Spring Kit

K84956-SP

16 Springs

Note: Not compatible with 1996-up black plastic roller clutch update.



Installation Instructions

1. Remove the roller clutch assembly from the 1-2 outer race.
2. Remove the OEM accordion springs and return the empty roller clutch to the outer race.
3. Return the rollers to the roller clutch, butting them up to the open ends of the roller stops.
4. Insert the Sonnax **K84956-SP** springs into the roller clutch, to the left of the rollers.
5. Spring orientation is important, so refer to the drawing below.

