


## Pressure Switch O-Ringed End Plug

### 36940-17K

1 End Plug  
1 O-Ring



### Disassembly Steps

Remove and discard OEM pressure switch/dummy plug.

### Installation/Assembly Steps

1. Install O-Ring in indicated Sonnax End Plug groove. Coat with ATF or Translube and roll on bench to size.
2. Install the Sonnax O-Ringed End Plug into casting bore and retain with OEM retaining clip.