


Low/Reverse Modulator Valve Plunger & Sleeve

36947-06K

1 Valve Plunger

1 Sleeve



Inspection

Visual wear on the inside diameter of the sleeve is evident by shiny aluminum patches.

Installation

Remove the worn sleeve and valve plunger assembly from the valve body. Reference the photo for proper valve, sleeve and spring orientation when installing this direct replacement assembly.