

Universal Stator Support Shaft Kits

4L60-E: '04-up Reluctor Style


77918S-08K 298mm Converter

1 Stator Support Shaft *with Bushings*

4L60-E, 4L65-E & 4L70-E:
'04-up Reluctor Style

77918S-09K 280mm or
300mm Converter

1 Stator Support Shaft *with Bushings*



Installation: 77918S-08K & 77918S-09K

1. Place Loctite® #518 sealant on leading edge of stator support shaft before press operation.
2. Align oil holes and dowel holes exactly on the shaft and pump cover, then press shaft into the cover and fasten together.

