


Main Bearing Shim Kit

100567A-01K

4 Rear Output Bearing Shims
4 Front Input Bearing Shims



Installation of the Main Bearing Shims:

1. The larger shims are for the front input bearing. The smaller shims are for the rear output bearing.
2. Install the greatest number of shims that will still allow the retaining ring to be installed.