

Oversized Accumulator Pin & Reamer


84573-01K

4 Accumulator Pins

84573-02K

10 Accumulator Pins

1 Reamer



Installation Instructions

1. Remove piston and pin.
2. Ream piston bore using cutting oil (kerosene gives the best finish, and a drill press or ridged process gives best results).
3. Replace with Sonnax oversized pin.