

COMPLAINT

SECONDARY COMPLAINT:

Pump bearing or seal failure

- Converter codes

CAUSE

Normal wear causes parts to fail.


CORRECTION

This replacement bearing is a direct replacement for the OEM bearing.

Pump Shaft Bearing with Seal

33000-01

1 Pump Shaft Bearing



Sonnax Part Summary

Bearing and pump shaft wear are common causes of unit failure in 4T40-E transmissions. When the integral seal is damaged, pump oil pressure will cross leak into the TCC release circuit, triggering TCC stuck on codes when TCC is not applied, and causing TCC slip codes when TCC is applied. Sonnax now offers **33000-01**, a direct replacement pump bearing with integral seal. We recommend that you replace this part in every overhaul.

Features & Benefits

- OEM approved.
- Includes integrated seal.

Save

\$75 in pump replacement costs