

Boost Valve Assembly

72754-01K

1 Boost Valve
1 Boost Sleeve


Also available:

72754-03K

1 Spring
1 Oversized Pressure Regulator Valve
1 Oversized Boost Valve Assembly

F-72754-TL3

1 Reamer
1 Guide Pin
1 Reamer Jig



Installation Instructions

1. Discard both the OEM sleeve and valve.
2. Replace with Sonnax boost valve assembly.

Wet Air Test

To Wet/Air test the boost valve assembly, place a small amount of oil into the torque signal port. Follow with low air pressure. There should be little or no leakage past the boost spool and out the reverse port. Place a small amount of oil into the reverse boost port and follow with low air pressure. There should be little or no leakage past either valve spool and out the torque signal orifice or the exhaust port on the back of the casting.

