


Pressure Switch O-Ringed End Plug Kit

36940-17K

1 End Plug
1 O-Ring



Disassembly Steps

Remove and discard OEM pressure switch/dummy plug.

Installation/Assembly Steps

1. Install O-ring in indicated Sonnax end plug groove. Coat with ATF or Translube and roll on bench to size.
2. Install the Sonnax O-ringed end plug into casting bore and retain with OEM retaining clip.