


Servo Belleville Cushion Washer

85701-01

2 Servo Cushion Washers



Installation Instructions:

1. Remove the E-clip from the servo assembly.
2. Remove the piston assembly and any broken or cracked cushion washers.
3. Assemble two cushion washers in a clam shell configuration as shown in Figure 1.
4. Re-install the piston assembly and E-clip.

FIGURE 1

