

Standard TCC Regulator Valve

37947-38


1 Valve

OEM Size

Also available

**TCC Regulator
Sleeve Kit**

37947-09K



INSPECTION

Perform a visual inspection of the two critical valve spools for excessive scratches.

Visual inspection of the casting bore should also be performed to look for excessive wear. If excessive bore wear is seen, the Sonnax TCC Regulator Sleeve Kit **37947-09K** should be used.

INSTALLATION

1. Remove and discard the OEM valve. (Helpful hints on removing these bore components can be found on page 14 of the **37947-BOOK** instructions, available by visiting our Web site: www.sonnax.com)
2. Insert the 2 OEM springs into the replacement valve spring pocket.
3. Install the springs and valve into the bore, referencing the photo for proper orientation.