


B2 Apply Control Plunger Kit

27741-06K

1 Plunger Valve
1 Plunger Sleeve



Installation

1. Remove and discard OEM sleeve and plunger valve.
2. Insert Sonnax valve and sleeve assembly as shown in photo, reusing the OEM retainer pin.

Final Verification

Perform a Wet Air Test or Vacuum Test in the location shown. If performing a WAT, no leakage should occur at the port shown. A vacuum test must hold a minimum of 18".

