


3-4 Accumulator Spring

12861-01

1 Spring



Instructions

Install the Sonnax spring in place of the OEM 3-4 accumulator spring.