

Accumulator Piston Kit

57917E-19K

1 Accumulator Piston


2 O-Rings

***Note:** Kit fits the following applications;

4 Speed - U140E/F, U240E, U241E

5 Speed - U150E, U151E/F, U250E, A750E/F

6-Speed - A760E/H/F & A761E



Installations/Assembly Steps

1. Remove OEM piston and springs.
2. Discard OEM piston.
3. Place Sonnax O-Ring in replacement piston groove and roll on bench to size.
(Kit has one extra O-Ring.)
4. Install piston, O-Ringed end first into the bore.
5. Re-install OEM springs.