


Lockup Control Plunger & Sleeve Kit

59954-01K

- 1 Lockup Plunger Valve
- 1 Lockup Plunger Sleeve



Disassembly / Assembly Steps:

1. Remove and discard the OEM sleeve and valve.
2. Install the Sonnax sleeve and valve assembly as pictured.

Final Verification Steps:

Perform a Wet Air Test or vacuum test of the sleeve assembly while in the bore at the outboard converter apply feed port as indicated. A vacuum test should reach at least 18" of vacuum. If performing a WAT, no leakage should occur at the neighboring exhaust port.

For more information on the valve body testing procedures, go to www.sonnax.com

