


Clutch/Band/Line Accumulator Piston Kit

15741-14K

Five Locations

1 Accumulator Piston
1 O-Ring

Note: Fits Volvo (AM6); Opel (AF40); Peugeot (TF80); Saab (AF40/6); Land Rover (TF80); Ford (AF21); Mazda (AW6A-EL); BMW (6F21WA) & VW/Audi (09G, 09K, 09M).



Installation Steps

1. Remove OEM piston and springs.
2. Discard piston.
3. Place o-ring in replacement piston groove, and roll on bench to size.
4. Install piston, o-ringed end first into bore.
5. Re-install OEM springs.