



Perth (2012-13)

- 40% ground
- 27% desal sea
- 33% surface



Seawater → Potable


Distillation



water evaporates, then condenses

- high energy demand ..C

Reverse Osmosis



salt left is called the concentrate (better)

Set 28

12. The majority of Earth's water is seawater, which has a high TDS, and also contains high levels of salts. As a result, this water is unusable for either human consumption or for agriculture.

On the other hand, not all fresh water is safe for consumption, as some of the sources can be stagnant and have a buildup of dead matter and other harmful organisms.

13. TDS: total dissolved solids, the total amount of solids that is dissolved in the water.

There is no upper limit because it depends on the solids that are dissolved in water.

14. Potable water is water that is safe to be used for human consumption or for cooking.

b. With advancing technologies, it is getting cheaper and cheaper to filter seawater. Also, it is a very abundant source of water.

c. A semipermeable membrane (SPM) is a membrane that allows water to pass through it but not other, larger particles, such as dissolved salts. In plants, a process called osmosis is used to transfer water from the environment into the plant.

Osmosis occurs when two liquids with different concentrations of TDS are separated by a semi-permeable membrane. In this scenario, the net flow will be from the liquid with the lower concentration into the liquid with a higher concentration, until both liquids have an equal concentration.

d. Osmosis occurs naturally. Conversely, RO requires some pressure to be applied in order to move the water from the solution of higher concentration into the side with a lower concentration.

what's with this shift?




15. Inside the salty feed water


solution, the Na^+ and

H_2O molecules are attracted to each other by ion-dipole intermolecular forces. In order to separate these, the ion-dipole force must be overcome and thus energy must be put into the system.


a. Most of the energy involved in desalination by RO involves the use of pressure and an SPM to separate various salt ions from water molecules. Why should energy be needed to separate ions like Na^+ from H_2O molecules? Explain in terms of chemical bonding. *with?*





Groundwater Processing



Aeration: removes the air from bore water
e.g. CO_2 , H_2S
(can discolour water, etc)



Clarification: fine particles are removed
- adds $\text{Al}_2(\text{SO}_4)_3$
(coagulation & flocculation agent)




sand filtration: filters out fine particles


← anthracite + sand



disinfection: destroy pathogenic viruses and bacteria by using chlorine



fluoridation: adding fluoride to water strengthens teeth from bacteria



pH control:
+ $\text{CaO} \rightarrow$ basic
+ $\text{CO}_2 \rightarrow$ acidic

Control

- Turbidity
- pH
- TDS
- pathogens
- heavy metals (potentially toxic) ☠
e.g. Arsenic

Set 28 cont.

$$1b. 1 \times 10^{-6} = \frac{m(F^-)}{45000}$$

$$m(F^-) = 0.045 \text{ kg} = 45 \text{ g}$$

$$b. n(F^-) = \frac{m(F^-)}{M(F^-)}$$
$$= \frac{45}{19}$$

$$= 2.37 \text{ mol}$$

~~$$2.37 = \frac{m(\text{NaF})}{14.01 + 19}$$~~

~~$$m(\text{NaF}) = 78.18 \text{ g}$$~~

c. This because ppm does NOT calculate concentration based off of moles but rather off of mass. Because NaF and F^- have different M_r mass, their concentration in ppm will also differ.

~~$$d. n(\text{NaF}) = \frac{m(\text{NaF})}{M(\text{NaF})}$$
$$= \frac{4.1}{14.01 + 19}$$~~

~~$$= 0.124 \text{ mol}$$~~

~~$$n(\text{NaF}) = n(F^-) = 0.124 \text{ mol}$$~~

~~$$m(F^-) = 0.124 \times M(F^-)$$
$$= 0.124 \times 19$$
$$= 2.36 \text{ g}$$~~

$$C = \frac{2.36}{100} \times 10^6$$

$$= 23600 \text{ ppm} \quad (\text{p.147})$$

x x
:) x

16b but correct:

$$16. 1 \times 10^{-5} = \frac{m(F^-)}{45000}$$

$$m(F^-) = 0.045 \text{ kg} = 45 \text{ g}$$

$$b. n(F^-) = \frac{m(F^-)}{M(F^-)}$$

$$= \frac{45}{19}$$

$$= 2.37 \text{ mol}$$

$$2.37 = \frac{m(\text{NaF})}{M(\text{NaF})}$$

$$= \frac{m(\text{NaF})}{22.99 + 19}$$

$$m(\text{NaF}) = 99.45 \text{ g}$$

$$d. n(\text{NaF}) = \frac{4.1}{41.99}$$

$$= 0.0976 \text{ mol}$$

$$m(F^-) = 0.0976 \times 19$$
$$= 1.86 \text{ g}$$

$$C = \frac{1.86}{100} \times 10^6$$

$$= 18600 \text{ ppm}$$

☹️³⁰³

17.9. Chlorine is added to water in order to sanitise it i.e. destroy pathogenic organisms such as bacteria and viruses.

$$b. 1 = \frac{m(\text{Cl}_2)}{9.79 \times 10^8}$$

=

$$\frac{1 \times 9.79 \times 10^8}{10^6} = m(\text{Cl}_2)$$

$$979 \text{ kg} = m(\text{Cl}_2)$$

C. To keep the Chlorine across the entire system of water distribution, excess chlorine would need to be added in order to account for various factors, i dunno man