


Red - Positive
Black - Negative
Green - IO
Purple/Orange - Overside connections
Blue - Underside connections



Undo purple GND wire and replace with male-to-male jumper



All orange wires should be female to male

Add resistor

Purple wires should be male-to-male

Blue is connections on underside through pads

Turquoise/Cyan should be male-to-female with the male end in the perfboard



VCC2
Power Supply
9V