




RUDDER QUADRANTS




QUARTEDECK

Webbing hinge joins rudder assembly to stern




STERN


NOTE: Frame quadrants (shown on this and following pages) are intended to be used in conjunction with the hull and keel. The frame quadrants are intended to be used in conjunction with the hull and keel. The frame quadrants are intended to be used in conjunction with the hull and keel.



Station 2




Station 3



Sheet No. 2

Version 1.0

© 1993 GBD/DBC



Sheet No. 3

Version 1.1

© 1993 GBD/DBC