


QIG




Insert the supplied CD into your computer's disk drive. The setup program should start automatically after a few seconds. If instruction does not appear, locate and double-click the setup.exe file on the CD.







Select your purchased model
For example: **"AWUS036NH"**



Read the license agreement and choose **"I accept the terms of the license agreement"** and click Next




Choose **"Install driver and Ralink WLAN Utility"** and click **"Next"**

	<p>Choose “Ralink Configuration Tool” and click “Next”</p>
	<p>Click “Install” to continue.</p>
	<p>Click “Finish” and the Utility will pop up for Windows XP. (Choose “No, I will restart my computer later” and click “Finish” for Windows Vista)</p>
	<p>Attach the antenna to the wireless adapter and plug in the USB cable to AWUS036NH. Insert the USB connector into an available USB port, your computer will then detect and activate the adapter automatically. Do Not remove the CD from the computer</p>
	<p>Found New Hardware pops up from the utility bar</p>



Click the Scan icon to Select your target network and double click



Add to Profile list to link

You can see the Link information to make sure you have successfully connected to your wireless network.