










Quick Installation Guide to AWUS036NHV

	<p>Insert the supplied CD into your computer's disc drive. The setup program should start automatically. If the instructions do not appear, locate and double-click the setup.exe file on the CD.</p>
	<p>When the 1st title screen appears, click “AWUS036NHV” then on the following screen select the operating system your computer is operating on.</p>
	<p>Click Next and proceed with the following instructions to complete the installation process.</p>
	<p>Select No, I'll restart my computer later and click Finish.</p>


	<p>Found New Hardware notification will pop up from the notification area after AWUS036NHR was been plugged in.</p>
	<p>Double click on the “Realtek 11n USB Wireless LAN Utility” and select the Available Network tab. Double click your target network to establish the wireless connection.</p>

MAC OS X


	<p>Insert the supplied CD into your computer’s disc drive.</p>
	<p>Click on the CD icon located on your desktop and look for installation folder “NHV” and then select your Mac OS then click Installer.pkg to launch the installation wizard.</p>
	<p>Click Continue and proceed with the following instructions to complete the installation process.</p>



For the authentication menu, please enter your name and password then click **OK** to continue the installation process.



Click **Restart** to complete the installation process.



Plug in your AWUS036NHV into your computer and the **Wireless Network Utility** window will pop up. Select your target network then **Connect** to establish the wireless connection.