



Dimension





Unit:mm

LUMINAIRES				Driver(Kg)
L=1210mm	no=5	300W	≈4. 7Kg	≈2Kg
L=1210mm	no=9	550W	≈6. 7Kg	≈4Kg

Luminaire Inlet&Installation Options


1. Steel clips space



Unit:mm


Distance(D)	Recommend
750mm-1190mm	1118mm

2. Luminaire Inlet




Thanks for choosing our product, please read this guide carefully before installation.

2. Luminaire Inlet



Thanks for choosing our product, please read this guide carefully before installation.


2. Luminaire Inlet





Thanks for choosing our product, please read this guide carefully before installation.

2. Luminaire Inlet

- 1, Open the junction box by removing four (4) screws on corners.
- 2, Wire the power cable inside the box as indicated and then close the junction box.



- L(black)
- Earth(green)
- N(white)
- DIM-(grey)
- DIM+(purple)



25

