

Frequency Modulation (FM)

Susmita Sain

Electronics and communications

Indian Institute Of Information Technology Guwahati

Guwahati, India

susmita.sain205@gmail.com

Abstract—Frequency Modulation (FM) plays a crucial role in modern communication systems due to its resilience to noise and superior signal quality. This paper explores the fundamental principles of FM, its generation, and demodulation techniques. The process of FM signal generation is demonstrated using MATLAB simulations, alongside an analysis of its power spectral density. For demodulation, a slope detector with a high-pass filter is employed, followed by an envelope detector to retrieve the original message signal. Additionally, the paper discusses real-world applications, advantages, and challenges associated with FM. Experimental validation is performed in a laboratory setting, comparing theoretical predictions with practical observations. The results affirm the efficiency of FM in reliable signal transmission, highlighting its significance in communication systems.

Index Terms—Frequency Modulation (FM), FM Demodulation, Slope Detector, Envelope Detector, High-Pass Filter, Power Spectral Density (PSD), MATLAB Simulation, Analog Modulation.

I. INTRODUCTION

Frequency Modulation (FM) is a widely used analog modulation technique where the frequency of a carrier signal is varied in accordance with the instantaneous amplitude of the message signal. Unlike Amplitude Modulation (AM), FM provides better noise immunity and improved signal quality, making it an essential technique in wireless communication systems. It is extensively used in radio broadcasting, two-way radio communication, television sound transmission, and various industrial applications.

The key advantage of FM lies in its ability to maintain signal integrity even in the presence of noise, making it ideal for high-fidelity audio transmission. This property is attributed to the constant amplitude of FM signals, which makes them less susceptible to amplitude-based distortions. Additionally, FM signals occupy a larger bandwidth than AM signals, which helps in reducing interference and improving overall transmission quality.

This paper explores the principles of FM, its generation and demodulation techniques, and its practical implementation. The FM signal is generated and analyzed using MATLAB simulations, including the study of its power spectral density. The demodulation process is carried out using a slope detector, where the FM signal is passed through a high-pass filter to obtain a Double-Sideband Amplitude Modulated (DSB-AM) signal, which is then processed using an envelope detector to retrieve the original message signal. Furthermore, the paper

discusses the applications, advantages, and challenges of FM, supported by experimental validation in a laboratory setting.

The remainder of the paper is structured as follows: Section II discusses the general assumptions and notation. Section III explains the theory and working principle, while Section IV details the generation process. Section V covers the demodulation of FM, followed by the results in Section VI. Finally, Section VII concludes the paper.

II. GENERAL ASSUMPTIONS AND NOTATION

To maintain consistency in the analysis of Frequency Modulation (FM), this section outlines the key assumptions and notations used in this paper.

A. General Assumptions

The analysis is based on the following assumptions:

- The message signal $m(t)$ is a low-frequency baseband signal.
- The carrier signal is a high-frequency sinusoidal wave with constant amplitude.
- Frequency deviation in FM is proportional to the instantaneous amplitude of $m(t)$.
- The theoretical analysis assumes a noise-free channel.
- FM demodulation is performed using a slope detector with a high-pass filter and an envelope detector.
- MATLAB is used for FM signal generation and spectral analysis.

B. Notation

The following notations are used throughout this paper:

Symbol	Description
$m(t)$	Message signal
$s(t)$	FM-modulated signal
A_c	Carrier amplitude
f_c	Carrier frequency
f_m	Message signal frequency
β	Modulation index, $\beta = \frac{\Delta f}{f_m}$
Δf	Peak frequency deviation
BW	FM signal bandwidth

TABLE I

NOTATION USED IN THIS PAPER.

These assumptions and notations serve as a basis for the theoretical and practical discussions in subsequent sections.

III. THEORY AND WORKING PRINCIPLE

A. Theory of Frequency Modulation

Frequency Modulation (FM) is a technique in which the instantaneous frequency of a carrier wave is varied according to the amplitude of the message signal while keeping its amplitude constant.

Let the message signal be represented as:

$$m(t) = A_m \cos(2\pi f_m t) \quad (1)$$

where:

- A_m is the amplitude of the message signal,
- f_m is the frequency of the message signal.

The instantaneous frequency of the FM signal is given by:

$$f_i(t) = f_c + k_f m(t) \quad (2)$$

where k_f is the frequency sensitivity of the modulator.

The phase of the FM signal, $\theta(t)$, is obtained by integrating the instantaneous frequency:

$$\theta(t) = \int 2\pi f_i(t) dt = 2\pi f_c t + 2\pi k_f \int m(t) dt \quad (3)$$

Since the integral of a cosine function is a sine function, the integral of the message signal is:

$$\int m(t) dt = \frac{A_m}{2\pi f_m} \sin(2\pi f_m t) \quad (4)$$

Thus, the FM signal is given by:

$$s(t) = A_c \cos(2\pi f_c t + \beta \sin(2\pi f_m t)) \quad (5)$$

where the modulation index is defined as:

$$\beta = \frac{\Delta f}{f_m} = \frac{k_f A_m}{f_m} \quad (6)$$

B. Modulation Index

The modulation index, denoted as β , is a key parameter in Frequency Modulation (FM) that determines the extent of frequency variation in response to the message signal. It is defined as:

$$\beta = \frac{\Delta f}{f_m} = \frac{k_f A_m}{f_m} \quad (7)$$

where:

- Δf is the peak frequency deviation,
- f_m is the frequency of the message signal,
- k_f is the frequency sensitivity of the modulator,
- A_m is the amplitude of the message signal.

The modulation index determines whether the FM signal is narrowband or wideband:

- If $\beta \ll 1$, the FM signal is considered **narrowband FM** (NBFM), occupying a smaller bandwidth.

- If $\beta \gg 1$, the FM signal is considered **wideband FM** (WBFM), requiring a larger bandwidth but providing better noise immunity.

The bandwidth of an FM signal can be estimated using Carson's Rule:

$$BW \approx 2(\Delta f + f_m) \quad (8)$$

A higher modulation index results in a wider bandwidth and improved signal quality, making it suitable for high-fidelity applications such as FM broadcasting. — This shows that FM is achieved by integrating the message signal and using it to modulate the phase of the carrier.

C. Working Principle of Frequency Modulation

Frequency Modulation (FM) is a technique in which the frequency of a carrier signal is varied according to the instantaneous amplitude of the message signal while maintaining a constant amplitude. The instantaneous frequency of the FM signal is given by:

$$f_i(t) = f_c + k_f m(t) \quad (9)$$

where k_f is the frequency sensitivity of the modulator, and $m(t)$ is the message signal. The phase-modulated form of the FM signal is:

$$s(t) = A_c \cos(2\pi f_c t + \beta \sin(2\pi f_m t)) \quad (10)$$

where $\beta = \frac{k_f A_m}{f_m}$ is the modulation index.

The FM signal is generated using an **astable multivibrator**, which produces a variable-frequency waveform in response to the input message signal. A detailed explanation of the generation process is provided in **Section III (Generation of FM)**.

To recover the original message signal, a **slope detector** followed by an **envelope detector** is used. The working of this demodulation process is explained in **Section IV (Demodulation of FM)**.

This method enables efficient transmission with noise immunity, making FM suitable for various communication applications.

IV. GENERATION OF FM

Frequency Modulation (FM) is generated by varying the instantaneous frequency of a carrier signal in response to the amplitude of the message signal. In this experiment, an **astable multivibrator** is used to generate an FM signal, where the oscillation frequency is modulated by the input message signal.

A. Mathematical Representation

The FM signal is expressed as:

$$s(t) = A_c \cos(2\pi f_c t + \beta \sin(2\pi f_m t)) \quad (11)$$

where:

- A_c is the carrier amplitude,
- f_c is the carrier frequency,

- β is the modulation index, given by $\beta = \frac{k_f A_m}{f_m}$,
- f_m is the message signal frequency.

The instantaneous frequency of the FM wave is given by:

$$f_i(t) = f_c + k_f m(t) \quad (12)$$

where k_f is the frequency deviation constant.

B. FM Generation using Astable Multivibrator

In this experiment, an astable multivibrator is implemented to generate an FM signal. The multivibrator continuously oscillates between two states, producing a square wave whose frequency varies according to the amplitude of the input message signal. The process involves:

- The astable multivibrator generates a periodic waveform with a frequency determined by resistor-capacitor (RC) components.
- The message signal modulates the charging and discharging time of the capacitor, leading to frequency variation.
- The square wave output is then processed through a frequency-to-sine converter to obtain an FM waveform.

V. DEMODULATION OF FM

Demodulation of a Frequency Modulated (FM) signal is the process of extracting the original message signal from the modulated waveform. In this experiment, the demodulation is performed using a **slope detector** followed by an **envelope detector**.

A. Principle of FM Demodulation

The instantaneous frequency of the FM signal is given by:

$$f_i(t) = f_c + k_f m(t) \quad (13)$$

where $m(t)$ is the message signal. The goal of demodulation is to retrieve $m(t)$ from the received FM signal. This is achieved by converting the frequency variations into amplitude variations, which can then be detected.

B. Demodulation Using Slope Detector

A **slope detector** is used to convert the frequency variations of the FM signal into corresponding amplitude variations. It consists of a high-pass filter (differentiator) followed by a rectifier. The steps involved are:

- The FM signal is passed through a high-pass filter, which attenuates constant frequency components and enhances the variations in frequency.
- The output of the filter resembles a Double-Sideband Amplitude Modulated (DSB-AM) signal, where amplitude variations represent the original message signal.

Mathematically, the output of the high-pass filter can be expressed as:

$$s_{HP}(t) = H(f)s(t) \quad (14)$$

where $H(f)$ represents the transfer function of the filter.

C. Envelope Detection for Message Extraction

The DSB-AM signal obtained from the slope detector is passed through an **envelope detector** to retrieve the original message signal. The envelope detector consists of:

- A diode for rectification, which removes the negative half-cycles.
- A low-pass filter to smooth the rectified signal and extract the envelope, which corresponds to the message signal.

The final recovered message signal is given by:

$$m'(t) = |s_{HP}(t)| \quad (15)$$

where $m'(t)$ is the estimated message signal.

This approach ensures that the demodulated signal closely matches the original message signal, validating the effectiveness of the slope detection method.

VI. NUMERICAL RESULTS

A. Message Signal

The message signal is the original baseband signal used to modulate the carrier frequency in FM. It is a sinusoidal waveform that represents the information signal. The amplitude and frequency of this signal determine the variations in the modulated signal.




Fig. 1. Message Signal: A sinusoidal waveform representing the baseband information signal.

B. Frequency Modulated Signal

The FM signal results from varying the frequency of the carrier signal according to the amplitude of the message signal. As the amplitude of the message signal increases, the carrier frequency shifts higher, and when it decreases, the frequency shifts lower. This ensures that the information is encoded in frequency variations rather than amplitude changes.

C. Power Spectral Density (PSD) Analysis

The Power Spectral Density (PSD) of the FM signal shows how its energy is distributed across different frequencies. Unlike amplitude modulation (AM), which has a narrow spectral range, FM spreads the signal over a broader bandwidth. The spectral components around the carrier frequency are a result of the varying frequency due to modulation.




Fig. 2. FM Signal: Frequency modulation in response to the instantaneous amplitude of the message signal.




Fig. 3. Power Spectral Density of FM Signal: Showing frequency component distribution.

D. Overall Result

The simulation results confirm the fundamental properties of FM. The generated FM signal correctly exhibits frequency variations corresponding to the message signal amplitude. The PSD analysis validates the spectral spreading effect, demonstrating the efficient bandwidth utilization of FM. These observations align with theoretical expectations, ensuring the accuracy of the implementation.

VII. CONCLUSION

This paper presented a comprehensive study on Frequency Modulation (FM), covering its theoretical foundations, signal generation, demodulation techniques, and practical implementation. The generation of FM signals was carried out using both MATLAB simulations and an astable multivibrator circuit in the laboratory, demonstrating the modulation process effectively.

The demodulation of FM was performed using a slope detector followed by an envelope detector, successfully recovering the original message signal. The theoretical expectations were validated through simulation results and practical measurements, confirming the accuracy of the implemented techniques. The power spectral analysis highlighted the bandwidth requirements of FM and demonstrated the expected frequency variations corresponding to the message signal.

Furthermore, the advantages of FM, including its robustness against noise, better signal-to-noise ratio, and suitability for high-fidelity audio transmission, were discussed. However, the study also acknowledged its challenges, such as increased bandwidth requirements and circuit complexity in demodulation.

Overall, the results reaffirm the significance of FM in communication systems, providing a strong foundation for further exploration of advanced modulation techniques. Future work may focus on optimizing FM for modern digital communication applications and improving bandwidth efficiency while maintaining its noise resistance.

REFERENCES

- [1] B. P. Lathi and Z. Ding, *Modern Digital and Analog Communication Systems*, 4th ed. Oxford University Press, 2010.
- [2] S. Haykin, *Communication Systems*, 4th ed. Wiley, 2001.
- [3] H. Taub and D. L. Schilling, *Principles of Communication Systems*, 2nd ed. McGraw-Hill, 1986.
- [4] J. G. Proakis and M. Salehi, *Fundamentals of Communication Systems*, 2nd ed. Pearson, 2013.
- [5] MathWorks, "FM Modulation," [Online]. Available: <https://www.mathworks.com/help/comm/ref/fmmod.html>
- [6] Texas Instruments, "NE555 Precision Timer Datasheet," [Online]. Available: <https://www.ti.com/lit/ds/symlink/ne555.pdf>
- [7] National Instruments, "Frequency Modulation Basics," NI White Paper, 2015. [Online]. Available: <https://www.ni.com/en-us/innovations/frequency-modulation.html>
- [8] Department of Electronics and Communication Engineering, "Analog Communication Lab Manual," Indian Institute of Information Technology Guwahati, 2024.
- [9] A. V. Oppenheim and A. S. Willsky, *Signals and Systems*, 2nd ed. Pearson, 1997.
- [10] R. J. Marks II, "Power Spectral Density of Modulated Signals," *IEEE Potentials*, vol. 6, no. 4, pp. 27–31, Oct. 1987.