

F = 0 for Progressive System

F = 0 for Field One Interlaced

F = 1 for Field Two Interlaced

Vertical Blanking

Active Picture

**Horizontal
Blanking**

V = 1

V = 0

H = 1

H = 0

EAV

SAV

**Total
Number
of Lines
Per Frame**

