

SBC-Klammer 2  
Layer 2

+

+

+

+

SBC-Klammer 2  
Layer 1

Grannophone-Rückwand

Nur für Lautsprecher vom Typ Visaton SC 5.9 ND  
ausschneiden/bohren

The diagram illustrates the back panel of a Grannophone, which is designed for use with Visaton SC 5.9 ND speakers. It features two identical octagonal cutouts for the speakers. Each octagon is marked with eight small circles, indicating the positions for mounting screws. The panel is further defined by a border of additional mounting holes: four along the top and bottom edges, and two on each of the left and right sides.

**Nur für Lautsprecher vom Typ Visaton SC 5.9 ND  
ausschneiden/bohren**