



Power switch front panel, mounts on the panel itself.

Sheet: /		
File: BulkyMIDI-32 Power Switch FP1.sch		
Title: Power Switch (Panel)		
Size: A4	Date:	Rev: A
KiCad E.D.A. kicad (5.1.8)-1		Id: 1/1