



Input switch front panel, mounts on the panel to hide the electronics.

Sheet: /		Date:	
File: BulkyMIDI-32 Input Switch FP1.sch		Rev: A	
Size: A4		Id: 1/1	
KiCad E.D.A. kicad (5.1.8)-1			