



Gameport





MIDI IN (optional)

Mk7-keyboard does not actually have MIDI IN, so this is just in case I ever find one that would require it.



MIDI OUT



Gameport to MIDI, note that this replaces the gameport instead of plugging into one.

Sheet: /
File: BulkyMIDI-32 Mk7 Adapter.sch

Title: BulkyMIDI-32 Mk7 Adapter

Size: A4
KiCad E.D.A. kicad (5.1.8)-1

Date:
Rev: A
Id: 1/1