


TERMINAL INSERTION VIEW



| FUSE TABLE | | | |
|------------|----------------|------|----------|
| FUSE # | FUNCTION | STUD | SOURCE |
| F1 | SPARE | VS | BATT |
| F2 | WORKLIGHTS1 | VS | BATT |
| F3 | FLASHER | VS | BATT |
| F4 | HORN | VS | BATT |
| F5 | HEADLIGHTS | VS | BATT |
| F6 | HVAC/FAN | VS | BATT |
| F7 | WIPERS | VS | BATT |
| F8 | WORKLIGHTS2 | VS | BATT |
| F9 | TAILLIGHTS | VS | BATT |
| F10 | STOP LIGHTS | VS | BATT |
| F11 | TRAILER LIGHTS | VS | BATT |
| F12 | OPTION LIGHTS | VS | BATT |
| F13 | SPARE | KS | IGNITION |
| F14 | ENGINE FAN | KS | IGNITION |
| F15 | GUGES | KS | IGNITION |
| F16 | ABS | KS | IGNITION |
| F17 | ECM | KS | IGNITION |
| F18 | TCM | KS | IGNITION |
| F19 | SPARE | KS | IGNITION |
| F20 | ACCESSORY | KS | IGNITION |