

Power & Control

File: Power.kicad_sch

UserPort adapter for connecting to the BulkyModem via a 2x8-pin IDC cable.

Sheet: /

File: BulkyModem UserPort Adapter.kicad_sch

Title: BulkyModem (C64 UserPort Adapter)



Size: A4

Date:

Rev: C

KiCad E.D.A. 8.0.2

Id: 1/2



The C64 and BulkyModem will need to be independently powered, this is in order to avoid backfeeding – one side being partially powered up through digital signal lines. This will cause something to eventually burn out, so we will need to monitor each side and only enable communication once both are powered up.

Sheet: /Power & Control/
File: Power.kicad_sch

Title: Power and control

Size: A4

Date:

KiCad E.D.A. 8.0.2

Rev:

Id: 2/2