



Transforms the C64 JoyKEY into a simple 3-button controller for the Sega Mega Drive (named Sega Genesis in North America). Given that we are missing one of the buttons, this adapter has a separate START button when used with the base unit (C64 Arcade version can assign any of the other 3 buttons to this).

This design is untested!

|  |         |
|--|---------|
| Sheet: /                               |         |
| File: Sega Mega Drive.sch              |         |
| <b>Title: SMD Adapter (C64 JoyKEY)</b> |         |
| Size: A4                               | Date:   |
| KiCad E.D.A. kicad (5.1.8)-1           | Rev: A  |
|  | Id: 1/1 |