




AIRSHORE GANTRY/A-FRAME





A-FRAME HEAD



1. ASSEMBLE A-FRAME PIVOTS TO EACH 12" BASE PLATE.
2. ATTACH THE BARREL END OF EACH STRUT TO THE A-FRAME PIVOTS.
3. MAKE SURE TWO 15° PIVOT CLEVIS' ARE IN PLACE ON THE A-FRAME HEAD.
4. ATTACH THE A-FRAME HEAD WITH CLEVIS' ATTACHED TO THE PISTON ENDS OF THE STRUTS.
5. GRADE 70 CHAIN AND ACCESSORIES ARE REQUIRED BETWEEN THE TWO BASE PLATES. PICKETS SHOULD BE PLACED THROUGH BASE PLATES.

**SEE TABULATED DATA SHEET FOR LOAD CAPACITIES



AirShore products have precise assembly specifications. Parts lists and diagrams are for reference and part identification only. Any and all modifications and repairs should be performed only by factory trained personnel.

AirShore
Hurst Jaws of Life®
A Unit of IDEX Corporation

711 North Post Road
Shelby, NC 28150



Tel: 704-487-6961
Fax: 704-487-7271
Internet: www.jawsoflife.com

Form No. 159A181 Rev. 01