

# Atomiton Terminal Loading and Distribution Solution




- digitizing the world one application at the time <sup>TM</sup>

8/25/2019

Version 1.0.0

Atomiton Inc.



Planner User Guide



---

## COPYRIGHT AND DISCLAIMERS STATEMENT

© 2019 Atomiton, Inc. All rights reserved.

The information contained in this document is the proprietary and exclusive property of Atomiton Inc except as otherwise indicated. No part of this document, in whole or in part, may be reproduced, stored, transmitted, or used for design purposes without the prior written permission of Atomiton Inc. The information contained in this document is provided for informational purposes only. Atomiton and for the sole use of Atomiton personnel, authorized users of the equipment, and licensees of Atomiton and for no other purpose. The information contained herein is subject to change without notice. Atomiton specifically disclaims all warranties, express or limited, including, but not limited, to the implied warranties of merchantability and fitness for a particular purpose, except as provided for in a separate software license agreement.

---

## TRADEMARKS STATEMENT

Atomiton and the Atomiton logo are registered trademarks and service marks of Atomiton. Other product, brand, or service names are trademarks or service marks of their respective holders. Do not make copies, show, or use trademarks or service marks without written authority from Atomiton.

---

## REFERENCED DOCUMENTS

Atomiton may not supply all documents that are referenced in this document with the equipment. Atomiton reserves the right to decide which documents are supplied with products and services.

---

## CONTACT INFORMATION

### Atomiton TECHNICAL SUPPORT and SALES

Contact Technical Support: <http://help.atomiton.com>

or via email at [support@atomiton.com](mailto:support@atomiton.com)

Contact Sales: <https://www.atomiton.com/company/contact-us>

### Atomiton REGIONAL OFFICES

#### HEADQUARTERS

Silicon Valley  
3100 De La Cruz Blvd. #206, Santa  
Clara, CA 95054  
United States  
Phone: +1 408-215-2014

For a Complete Contact List of Our Global Offices:

<https://www.atomiton.com/company/contact-us>

Contents	
Overview .....	4
Introduction and Purpose .....	4
Related Document References .....	4
Digital Terminal Solution Architecture .....	5
Solution Components .....	5
Planner User Interface .....	7
Glossary .....	8



## OVERVIEW

This document introduces the terminal planner user to the Terminal Loading and Distribution Solution (TLDS).

## INTRODUCTION AND PURPOSE

The TLDS's Planner Portal provide a single plane of glass for planner users to monitor and control the daily end-to-end fuel distribution operations.

The purpose of this application is to reduce repetitive work and thereby free the users from tedious tasks. By automating tedious tasks, the users can instead focus on ensuring optimal operational execution and thereby increase both customer and third-party partner satisfaction, while minimizing operation cost.

## RELATED DOCUMENT REFERENCES

Atomiton - Terminal Loading and Distribution Solution - Customer User Guide.pdf

Atomiton - Terminal Loading and Distribution Solution - Planner User Guide.pdf

Atomiton - Terminal Loading and Distribution Solution - Terminal User Guide.pdf


Atomiton - Terminal Loading and Distribution Solution - Trucking User Guide.pdf

## DIGITAL TERMINAL SOLUTION ARCHITECTURE

The Terminal Loading and Distribution Solution uses the advanced computing technology, such as sophisticated algorithms' and Artificial Intelligence (AI) to forecast customer inventory levels and optimize schedule delivery operations.

### SOLUTION COMPONENTS

Figure 1 shows a high-level architectural overview of the solution components.



**Figure 1 –Terminal Loading and Distribution Solution – High Level Flow**

The following table describes the devices, gateways, networks and Digital Terminal servers displayed in Figure 1.

Level	Description
<b>Customer</b>	<p>Stations monitoring current inventory and order progress. Stations may either be configured for automation inventory reporting or fully automatic. The latter is referred to as ATG data.</p> <p>The solution provides a portal targeted the needs of this organization.</p>
<b>ATG System</b>	A system providing automatic fuel tank product inventory level.



<b>Enterprise Software System</b>	Provides enterprise software functionality, such as order and billing management.
<b>Truck GPS (PLS)</b>	Provides truck location and Process Lee System (PLS) functionality.
<b>Trucking Company</b>	Organization providing payload transportation services. The solution provides a portal targeted the needs of this organization.
<b>Terminal Dashboard</b>	The Terminal Dashboard provides an interface targeted the needs of the terminal organization.



## PLANNER USER INTERFACE

## GLOSSARY

**ATA:**

Actual Time Arrival.

**ATG:**

Automatic Tank Gauging.

**Description:**

An ATG uses probes located in each tank or compartment to measure fuel and optionally water levels. Each probe may for example consists of a long rod with floats or sensors. In this case the position of the floats tells the ATG controller (computing device) how much fuel and water are present in the tank.

**C&I:**

Commercial & Industrial.

**CSC:**

Customer Service Center.

**DN:**

Delivery Note.

**ETA:**

Estimated Time Arrival.

**ETC:**

Estimated Time of Completion.

**ETD:**

Estimated Time of Departure.

**FAN:**

Filling Advice Notice.

**FBS:**

Fuel Fact  
Truck GPS Data.

**LPO:**

Loss Prevention Observation.

**PLS:**

Process Lee System.

Definition: Lee - 'protecting shelter' or 'the side (as of a ship) or area that is sheltered from the wind'.

**SO:**

Sales Order.

**SOP:**

Standard Operation Procedure.

**TCI:**

Trip Creation Instruction.

**TTLR:**



Tank Top Loading Rack.

**USTS:**

Underground Storage Tank System.

**VCO:**

Value Chain Optimization.

**V&V:**

View & Verify.

---

**Truck 'GPS Data':**

A broad term used for all data related to a given Trucks geolocation, including any data that can be derived from the GPS based data.

Derived includes abrupt breaking or acceleration, driving beyond speed limit, etc.



Silicon Valley  
3100 De La Cruz Blvd. #206, Santa Clara, CA 95054  
United States  
Phone: +1 408-215-2014