





LOAD SHORT OPEN

SMA to u.FL transition

J5



J1



R2 R1



J4

J3

J2

Please check CERN OHL 2 v2
Copyright (C) 2021 Ricardo Gonçalves



Use the 20L loads for calibration
if necessary. Keep in mind this is
only useful for characterization of
this test fixture or to measure a
system in a similar PCB stackup.