




Sensors





Power



Mods

Remove the voltage regulator that is on the NodeMCU and disconnect the USB to UART chip.



Sheet: /
File: transmitter.sch

Title: ESP8266 Sensor

Size: A4 Date:
KiCad E.D.A. kicad 5.0.2-bee76a070ubuntu16.04.1

Rev:
Id: 1/1