

COCKPIT PREPARATION

Parking Brake ON
 Speed Brakes DISARMED/RETRACTED
 Flaps RETRACTED
 Weather Radar OFF
 Engine Master 1 & 2 OFF
 ENG MODE NORM
 Thrust Levers IDLE
 Landing Gear DOWN
 Wipers OFF
 BAT 1 & 2 ON
 EXT PWR AS REQ
 APU MASTER SW AS REQ
 APU START AS REQ
 APU BLEED AS REQ
 Crew Oxygen Supply ON
 ADIRS all NAV
 Nav & Logo ON
 Strobe AUTO
 Interior Lights AS REQ
 Seat Belts ON
 No Smoking AUTO
 EMER EXIT LT ARM
 LDG ELEV AUTO
 Cabin Temp SET
 FIRE TESTS COMPLETE
 Fuel Pumps ON
 FD ON
 FUEL QTY CHECK
 BARO SET
 MCDU SETUP
 Take Off Data SET

BEFORE START

WINDOWS/DOORS CLOSED
 Beacon ON
 Thrust Levers IDLE
 Parking Brake AS REQ
 APU ON
 APU BLEED ON
 EXT Power DISCONNECTED
 ENG MODE IGN/START

ENGINE START

ENG 2 Master ON
when engine 2 started
 ENG 1 Master ON

AFTER START

ENG MODE NORM
 Flaps SET
 Speed Brakes ARMED
 APU BLEED OFF
 APU MASTER SW OFF
 Anti-Ice AS REQ
 ECAM STATUS CHECKED
 PITCH TRIM SET
 RUDDER TRIM ZERO
 RWY TURN OFF ON
 NOSE Light TAXI
 Brake Test DONE

BEFORE TAKEOFF

Initial Altitude SET
 RADAR AS REQ
 PWS AUTO
 TERR ON ND AS REQ
 AUTO BRK MAX
 Cabin Crew ADVISED
 OVHD Panel CHECKED
 Flight Controls CHECKED
 Flight Instruments CHECKED
 Flaps SET FOR TO
 ENG MODE AS REQ
 Transponder AUTO or ON
 ALT RPTG ON
 TCAS TA or TA/RA
 TCAS Traffic ALL or ABV
 ECAM T.O Memo NO BLUE
 LAND Lights ON
 NOSE Light T.O
 STROBE Light AUTO or ON
 BEACON, NAV & LOGO check ON
 RWY TURN OFF ON

AFTER TAKEOFF / CLIMB

Landing Gear UP
 Flaps RETRACTED
 PACKS ON
 Speed Brakes DISARMED
 NOSE Light OFF
 RWY TURN OFF OFF
 LAND Lights AS REQ
 Seat Belts AS REQ

DESCENT / APPROACH

FOR SIMULATION USE ONLY

LAND Lights	AS REQ	APU BLEED	OFF
Seat Belts	ON	EMER EXIT LT	OFF
CSTR	ON	No Smoking	OFF
LS	AS REQ	APU MASTER SW	OFF
ECAM Status	CHECKED	EXT PWR	OFF
BARO	SET	Nav & Logo	OFF
MINIMUMS	SET	BAT 1 & 2	OFF
ENG MODE	AS REQ		

LANDING

Cabin Crew	ADVISED
A/THR	SPEED/OFF
AUTO BRK	AS REQ
Flaps	SET
Speed Brakes	ARMED
Landing Gear	DOWN
ECAM LDG Memo	NO BLUE

AFTER LANDING

Speed Brakes	DISARMED
ENG MODE	NORM
Flaps	RETRACTED
TCAS	STBY
RADAR	OFF
PWS	OFF
APU MASTER SW	ON
APU START	ON
Anti-Ice	AS REQ
LAND Lights	OFF
NOSE Light	TAXI
STROBE Light	AUTO or OFF
RWY TURN OFF	ON

SHUTDOWN

Parking Brake	ON
NOSE Light	OFF
RWY TURN OFF	OFF
APU BLEED	ON
Engine Master 1 & 2	OFF
Seat Belts	OFF
Beacon	OFF
Fuel Pumps	OFF

SECURING AIRCRAFT

ADIRS	OFF
Crew Oxygen Supply	OFF

FOR SIMULATION USE ONLY