

Physics 204 Notes

Cameron Williamson

Fall 2020

Contents

1	SI Units	4
1.1	Base Units	4
1.2	Derived Units	4
2	Equations You Need to Know!!!	5
2.1	Thermodynamics	5
2.2	Electricity	6
2.2.1	A little note about Volume Integrals	7
2.3	Circuits	8
2.4	Magnetism	9
2.5	Optics	9
3	Gasses And Thermodynamics	10
3.1	Temperature	10
3.2	Thermal Equilibrium	10
3.3	Thermal Expansion	10
3.4	Calorimetry	10
3.5	First Law of Thermodynamics	10
3.6	Phases of Matter	11
3.6.1	Example 1	11
3.6.2	Example 2	11
3.7	Molecular Model of Gasses	11
3.8	Simplifying Assumptions of Gaseous Behavior	11
3.9	Finding the Pressure of an Ideal Gas	12
3.10	Root Mean Squared	12
3.11	Kinetic Average	13
3.12	Mean Free Path	13
3.12.1	Example 1	13
3.13	Work	14
3.14	How The First law of Thermodynamics Relates to Work	14
3.15	Pressure / Volume Diagrams	15
3.15.1	Example 1	15
3.15.2	Example 2	16
3.16	Using C_V and C_P	18
3.16.1	Example 1	19
3.16.2	Example 2	20
3.16.3	Example 3	20
3.17	Entropy	22

4	Electricity	23
4.1	Electrostatics	23
4.1.1	Example	23
4.2	Electric Fields	24
4.2.1	Example 1	25
4.2.2	Example 2	26
4.2.3	Example 3	26
4.3	Electric Field Lines	26
4.3.1	Example 1.	27
4.4	Flux and Gauss's Law	28
4.4.1	Example 1	28
4.4.2	Example 2	29
4.4.3	Example 3	30
4.4.4	Example 4	30
4.4.5	Example 4 (Gauss's Law with Conductors)	32
4.5	Electric Potential	34
4.5.1	Example 1	34
4.6	Electrostatic Potential Energy	34
4.6.1	Example 1	35
5	Circuits	37
5.1	Capacitants	37
5.1.1	Example 1	40
5.1.2	Example 2	41
5.2	Dialectics	43
5.3	Current and Resistance	43
5.3.1	Example 1	45
5.3.2	Example 2	46
5.3.3	Example 2	46
5.3.4	Example 3	48
5.4	Circuits and Circuit Analysis	48
5.4.1	Example 1	48
5.4.2	Example 2	50
5.4.3	Example (Draw Later)	52
5.4.4	Using measuring tools	53
5.5	Resistors and Capacitors in Circuits	53
6	Magnetism	56
6.0.1	Example 1	56
6.0.2	Example 2	56
6.1	Creating Magnetic Fields	57
6.1.1	Example 1	57
6.1.2	Example 2	58
6.1.3	Example 3	60
6.1.4	Example 4	60
6.1.5	Example 5	61
6.2	Holl Effect	61
6.2.1	Example 1	61
6.3	Ampere's Law	62
6.3.1	Example 1	63
6.4	Magnetic Inductance	64

6.4.1	Example 1	64
6.5	Eddy Currents	65
6.5.1	Motional Emf (E)	65
6.6	Induced Electric Field	66
6.6.1	Induction Applied to Circuits	66
6.6.2	Example 1	67
6.7	List of Maxwell's Equations:	68
7	Optics	70
7.1	Traveling Waves	70
7.1.1	Example 1	71
7.2	Electromagnetic Spectrum	71
7.3	Creating EM waves	72
7.4	Pointing Vectors	72
7.5	Polarization of Light	75
7.5.1	Example 1	75
7.6	Geometric or Ray Optics	76
7.7	Thin Lens Refraction	77
7.7.1	Example 1	78
7.8	Wave Interference	78
7.8.1	Example 2	79
7.9	Slit Interference	80
7.10	Crystallography	80
7.11	Electron Diffraction	80
7.12	Special Relativity	80
7.12.1	Example	80

1 SI Units

1.1 Base Units

- Length - meter - m
- Mass - kilogram - kg
- Time - second - s
- Electric Current - ampere - A
- Thermodynamic Temperature - kelvin - K
- Amount of substance - mole - mol
- Luminous intensity - candela - cd

1.2 Derived Units

- Frequency - hertz - Hz - s^{-1}
- Force - newton - N - $m * kg * s^{-2}$
- Pressure - pascal - Pa - $\frac{N}{m^2}$
- Energy - joule - J - $N * m$
- Power - watt - W - $\frac{J}{s}$
- Electric charge - coulomb - C - $s * A$
- Electric potential - volt - V - $\frac{W}{A}$
- Electric resistance - ohm - Ω - $\frac{V}{A}$
- Celsius temperature - degree Celsius - $^{\circ}C$ - $K - 273.15$

2 Equations You Need to Know!!!

2.1 Thermodynamics

$$\frac{\Delta L}{L} = \alpha \Delta T \quad (1)$$

$$Q = mc\Delta T \quad (2)$$

$$Q = mL \quad (3)$$

$$PV = nRT \quad (4)$$

$$PV = Nk_bT \quad (5)$$

$$P = \eta k_B T \quad (6)$$

$$v_{rms} = \sqrt{\frac{3RT}{M}} = \sqrt{\frac{3k_B T}{M}} \quad (7)$$

$$K_{avg} = \frac{3}{2} k_B T \quad (8)$$

$$E_{int} = NK_{avg} \quad (9)$$

$$\lambda = \frac{1}{\pi d^2 \eta} \quad (10)$$

$$E_{int} = nC_V T \quad (11)$$

$$\Delta E_{int} = nC_V \Delta T \quad (12)$$

$$C_V = \frac{d}{2} R = \left(\frac{3}{2} R \right)_{mon} = \left(\frac{5}{2} R \right) \quad (13)$$

$$C_P = C_V + R \quad (14)$$

$$\gamma = \frac{C_P}{C_V} \quad (15)$$

$$PV^\gamma = constant \quad (16)$$

$$W = \int P dV \quad (17)$$

$$\Delta E_{int} = Q - W \quad (18)$$

$$\Delta E_{int} = nC_P \Delta T - nR \Delta T \quad (19)$$

$$(20)$$

2.2 Electricity

$$\vec{F}_{12} = \frac{1}{4\pi\epsilon_0} \frac{q_1 q_2}{r_{12}^2} \hat{r}_{12} \quad (21)$$

$$\vec{E}_1 = \frac{1}{4\pi\epsilon_0} \frac{q_1}{r^2} \hat{r} \quad (22)$$

$$\vec{F}_{12} = q_2 \vec{E}_1 \quad (23)$$

$$dQ = \lambda dl \quad (24)$$

$$dQ = \sigma dA \quad (25)$$

$$dQ = \rho dV \quad (26)$$

$$d\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{dQ}{r^2} \hat{r} \quad (27)$$

$$\Phi_E = \int \vec{E} \cdot d\vec{A} \quad (28)$$

$$\oint \vec{E} \cdot d\vec{A} = \frac{Q_{enc}}{\epsilon_0} \quad (29)$$

$$EA = \frac{Q_{enc}}{\epsilon_0} \quad (30)$$

$$U_{12} = \frac{1}{4\pi\epsilon_0} \frac{q_1 q_2}{r_{12}} \quad (31)$$

$$V_1 = \frac{U_{12}}{q_2} \quad (32)$$

$$V_1 = \frac{1}{4\pi\epsilon_0} \frac{q_1}{r} \quad (33)$$

$$dV = \frac{1}{4\pi\epsilon_0} \frac{dQ}{r} \quad (34)$$

$$V_f - V_i = - \int_{s_i}^{s_f} \vec{E} \cdot d\vec{s} \quad (35)$$

$$E_s = - \frac{dV}{ds} \quad (36)$$

2.2.1 A little note about Volume Integrals

In Cartesian coordinates, $dV = dxdydz$. In Cylindrical coordinates, you have a z axis, a Φ axis, and an r axis. A differential amount of radius is dr , a differential amount of z is dz , and a differential amount of Φ is $d\Phi$. $d\Phi$ is really just a certain amount of arclength that is covered. We can call this arclength, dl_Φ .

$$dV = drdl_\Phi dz \quad (37)$$

So we can sub in arclength for dl_Φ

$$(38)$$

$$= dr(r d\Phi) dz \quad (39)$$

$$dV = r dr d\Phi dz \quad (40)$$

$$(41)$$

Now for spherical coordinates, we have 2 angles and a radius. θ is wrapping around the radius of the circle, where Φ is going from the north pole to the south pole. The radius is just r .

$$\begin{aligned} dV &= dr dl_\theta dl_\Phi \\ &= dr(r d\theta)(r \sin\theta d\Phi) \\ dV &= r^2 \sin\theta dr d\theta d\Phi \end{aligned}$$

2.3 Circuits

$$V = IR \quad (42)$$

$$R_{eqinseries} = R_1 + R_2 + R_3 + \dots \quad (43)$$

$$\frac{1}{R_{eqinpara}} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \dots \quad (44)$$

Power

$$(45)$$

$$P = V * I \quad (46)$$

$$P = R * I^2 \quad (47)$$

$$P = \frac{V^2}{R} \quad (48)$$

Voltage

$$(49)$$

$$V = R * I \quad (50)$$

$$V = \frac{P}{I} \quad (51)$$

$$V = \sqrt{P * R} \quad (52)$$

Resisitance

$$(53)$$

$$R = \frac{V}{I} \quad (54)$$

$$R = \frac{V^2}{P} \quad (55)$$

$$R = \frac{P}{I^2} \quad (56)$$

Current

$$(57)$$

$$I = \frac{V}{R} \quad (58)$$

$$I = \frac{P}{V} \quad (59)$$

$$I = \sqrt{\frac{P}{R}} \quad (60)$$

2.4 Magnetism

$$\vec{F} = q\vec{v} \times \vec{B} \quad (61)$$

$$\vec{F} = I\vec{l} \times \vec{B} \quad (62)$$

$$\vec{B} = \frac{\mu_0}{4\pi} \frac{q\vec{v} \times \hat{r}}{r^2} \quad (63)$$

$$\oint \vec{B} \cdot d\vec{l} = \mu_0 I_{th} \quad (64)$$

$$E_{ind} = -\frac{d}{dt} \Phi_B \quad (65)$$

$$\oint \vec{E} \cdot d\vec{l} = -\frac{d}{dt} \int \vec{B} \cdot d\vec{a} \quad (66)$$

$$(67)$$

2.5 Optics

$$E = E_0 \sin(kx - \omega t + \phi_0)$$

$$B = B_0 \sin(kx - \omega t + \phi_0)$$

$$\vec{S} = \frac{1}{\mu_0} \vec{E} \times \vec{B}$$

$$c = \frac{1}{\sqrt{\epsilon_0 \mu_0}}$$

$$c = \lambda f$$

$$E = cB$$

$$\mathcal{I} = \frac{P}{A} = \frac{\mathcal{E}}{At}$$

$$\mathcal{I} = S_{avg} = \frac{1}{\mu_0} E_{rms} B_{rms}$$

$$E_{rms}^2 = \frac{E_0^2}{2}$$

$$B_{rms} = \frac{B_0}{2}$$

$$\mathcal{P} = \frac{\mathcal{I}}{c} \text{ or } 2\frac{\mathcal{I}}{c}$$

$$\theta_1 = \theta'_1$$

$$n_1 \sin \theta_1 = n_2 \sin \theta_2$$

$$\frac{1}{f} = \frac{1}{d_0} + \frac{1}{d_i}$$

$$m = \frac{h_i}{h_0} = \frac{-d_i}{d_0}$$

3 Gasses And Thermodynamics

3.1 Temperature

The measure of hot and cold. More scientifically this is the measure of microscopic kinetic energy. The temperature scales are Kelvin (K) which has a zero point of absolute 0, Celsius (C), which has a zero point of water freezing and has 100 at the boiling point of water, and Fahrenheit (F).

$$T_C = T_K - 273.15$$

$$T_F = \frac{9}{5}T_C + 32$$

3.2 Thermal Equilibrium

Two objects are in thermal equilibrium when, while in direct contact, they have the same temperature. When 2 objects have different temperatures, T_A and T_B are brought into thermal contact and they will exchange energy via heat transfer until they reach thermal equilibrium.

Heat transfer is the spontaneous exchange of microscopic energy due to molecular or atomic collisions.

3.3 Thermal Expansion

Thermal expansion is when a solid object expands when it receives a raise in temperature

$$\frac{dL}{dT} = \alpha L$$

$$\frac{dA}{dT} = 2\alpha A$$

$$\frac{dV}{dT} = 3\alpha V$$

Where α is the coefficient of linear expansion

3.4 Calorimetry

Calorimetry is the science of measuring heat transfer. Internal/Thermal energy is the amount of energy stored in an object as described by its temperature. Heat Transfer = Q

3.5 First Law of Thermodynamics

$$\Delta E_{int} = Q - W$$

$$dE_{int} = dQ - dW$$

$$Q = c\Delta T$$

$$c = \frac{C}{M}$$

$$Q = mc\Delta T$$

Where c is the specific heat capacity, m is the mass of the substance, and ΔT is the change in temperature.

3.6 Phases of Matter

The phases of matter (from hottest to coldest) are Plasma, Gas (condenses to, or evaporates from), Liquid (freezes to, or melts from), Solid, and Condensates. During a phase change $Q = mL_v$ or $Q = mL_v$

3.6.1 Example 1

The U-district bridge has a span of 450ft. How much will it expand in spokane. The bridge is made out of concrete and steel which both have $\alpha = 12 * 10^{-6} \frac{1}{C^\circ}$. $T_{high} = 110^\circ F \rightarrow 120^\circ F$, $T_{low} = -30^\circ F \rightarrow -40^\circ F$

$$\begin{aligned} t_{high} &= 489^\circ C \\ T_{low} &= -40^\circ C L &= 137m \end{aligned}$$

$$\begin{aligned} \frac{\Delta L}{\Delta T} &= \alpha L \\ \Delta L &= \alpha L \Delta T \\ &= \left(12 * 10^{-6} \frac{1}{C^\circ} \right) (137m)(48.9^\circ C - -40^\circ C) \\ &= 0.146m \end{aligned}$$

3.6.2 Example 2

Your freezer is set to $23^\circ F$, you remove a 26g ice cube and place it in an empty glass. The next day the ice has melted and come to $72^\circ F$. Find the change in energy of the ice.

$$\begin{aligned} \Delta E_{int} &= M_{ice} C_{ice} \Delta T_{01} + M_{ice} L_{f_{ice}} + M_{water} C_{water} \Delta T_{12} \\ &= M_{ice} (C_{ice} \Delta T_{01} + L_{f_{ice}} + C_{water} \Delta T_{12}) \end{aligned}$$

3.7 Molecular Model of Gasses

We will describe gasses using state variables. State variables are macroscopic quantities used to describe the state of matter. Relative state variables can be used together to make quantitative predictions. This can be done using equations of state. Pressure $P = \frac{F}{A}$, Volume V, temperature T, the number of gas particles N, or the number of moles $n = \frac{N}{N_A}$ where N_A is Avogadro's number ($6.022 * 10^{23}$)

3.8 Simplifying Assumptions of Gaseous Behavior

These are assumptions for an ideal gas that will make math easier:

- Distance between the gas molecules is much larger than the diameter of the molecules themselves, thus forces between molecules can be ignored.
- When gas molecules collide we will assume they are perfectly elastic collisions, thus P can be easily derived.
- Due to the large distance between molecules, they are very compressible.

- The temperature of the gas is well above boiling point for given P and V .

When a gas can be accurately described by these rules, the gas is considered an ideal gas. Most gasses experienced everyday are ideal gasses. The equation of state for an ideal gas is the ideal gas law:

$$PV = NK_B T \rightarrow PV = n(N_A K_B)T \rightarrow PV = nRT$$

Boltzons Constant $\rightarrow K_B = 1.38 * 10^{-23} \frac{J}{K}$

Gas Constant $\rightarrow R = 8.314 \frac{J}{mol * K}$

3.9 Finding the Pressure of an Ideal Gas

Assuming a gas is within a rigid walled cube of length l , and when a gas molecule hits a wall it will change direction but conserve kinetic energy:

$$\Delta P \rightarrow \Delta P_x = -2mv_x \vec{F} = m\vec{a}\vec{F} = \frac{d}{dt}\vec{P} = \frac{\Delta \vec{P}}{\Delta t}$$

Average time between colisions is $2L = v_x \Delta t$

$$\left| \frac{\Delta P_x}{\Delta t} \right| = \frac{2mv_x}{\frac{2L}{V_x}} = \frac{mv^2}{L} = F_x$$

$$P_i = \frac{F}{A} = \frac{F_x}{L^2} = \frac{m_i v_{xi}^2}{L^3}$$

Total Pressure: $P = \sum_i P_i = \frac{m}{L^3} (\sum_i v_x^2)$

We know:

$$\vec{v} = v_x \vec{i} + v_y \vec{j} + v_z \vec{k}$$

$$v^2 = v_x^2 + v_y^2 + v_z^2$$

$$v^3 = v_x^3 + v_y^3 + v_z^3$$

Therefore we can determine that:

$$P = \frac{m}{L^3} N(v_x^2)_{avg}$$

$$P = \frac{m}{3L^3} N(v^2)_{avg}$$

$$PV = \frac{m}{3} N(v^2)_{avg}$$

Remember that for ideal gasses, $PV = NK_B T$, therefore $K_B T = \frac{1}{3} m(v^2)_{avg}$

3.10 Root Mean Squared

Root mean squared is the average velocity for any given particle. It is defined by the equation $v_{rms} = \sqrt{v_{avg}^2} = \sqrt{\frac{3K_B T}{m}}$, where M is the mass of the object (particle) and T is the temperature of the particle.

3.11 Kinetic Average

$$K_{avg} = \frac{1}{2}m(v^2)_{avg} = \frac{3}{2}K_B T$$

$$E_{int} = K_{tot} = \sum i K_i = N K_{avg_i}$$

$$E_{int} = \frac{3}{2} N K_B T$$

Or

$$E_{int} = \frac{3}{2} n R T$$

3.12 Mean Free Path

The mean free path of a gas is the average distance traveled by a gas molecule between collisions. Considering a room of volume V , that is filled with gas with molecules with diameter d .

$$\lambda = \frac{\text{Length of path in time } \Delta T}{\text{Number of collisions within } \Delta T}$$

$$\lambda = \frac{v \Delta T}{N \frac{V_{Cylinder}}{V}}$$

$$\lambda = \frac{V}{\sqrt{2} N \pi d^2}$$

$$\text{Number Density } \eta = \frac{N}{V}$$

$$\lambda = \frac{1}{\sqrt{2} \eta \pi d^2}$$

$$P V = n R T = N K_B T, P = \eta K_B T$$

3.12.1 Example 1

Find the RMS speed (v_{rms}) of a N_2 molecule in a room at $20^\circ C$. DiNitrogen has a molecular mass of $14 \frac{g}{mol}$, the R constant = $8.314 \frac{J}{mol \cdot K}$, M = molar mass and m = mass and $T=293K$. Recall that $M = m N_A$.

$$v_{rms} = \sqrt{(v^2)_{avg}}$$

$$= \sqrt{\frac{3 K_B T}{m}}$$

$$= \sqrt{\frac{3 K_B T}{\frac{M}{N_A}}}$$

$$= \sqrt{\frac{3 N_A K_B T}{M}} = \sqrt{\frac{3 R T}{M}}$$

$$v_{rms} = \sqrt{\frac{3 \left(8.314 \frac{J}{mol \cdot K} \right) (295 K)}{0.028 \frac{Kg}{mol}}}$$

3.13 Work

How much work will a gas do on its environment? Recall, $P = \frac{F}{A}$.

$$\begin{aligned}dW &= \vec{F} d\vec{x} \\&= Fdx - PAdx \\&= PdV\end{aligned}$$

3.14 How The First law of Thermodynamics Relates to Work

$$\Delta E_{int} = Q - W \rightarrow dE_{int} = Q - PdV$$

$$d\left(\frac{3}{2}NK_B T\right) = Q - PdV$$

$$\left(\frac{3}{2}NK_B T\right) = Q - QdV$$

- Pressure thermal equilibrium (quasi-static)

$$\begin{aligned}\int dw &= \int PdV \\W_{1 \rightarrow 2} &= \int_{v_1}^{v_2} PdV\end{aligned}$$

- Isochoric case ($\Delta V = 0$)

$$w = 0$$

- isobaric ($\Delta P = 0$)

$$\begin{aligned}w_{1 \rightarrow 2} &= P \int_{v_1}^{v_2} dV \\&= P(V_2 - V_1)\end{aligned}$$

- isothermal ($\Delta T = 0$)

$$\begin{aligned}w_{1 \rightarrow 2} &= \int_{V_1}^{V_2} PdV \\P &= \frac{NK_B T}{V} \\w_{1 \rightarrow 2} &= \int_{V_1}^{V_2} \frac{NK_B T}{V} dV \\&= NK_B T \int_{V_1}^{V_2} \frac{dV}{V} \\w_{1 \rightarrow 2} &= NK_B T \ln\left(\frac{V_2}{V_1}\right)\end{aligned}$$

3.15 Pressure / Volume Diagrams

This is an easy way to interperate the changes due to temperature, pressure, and volume changes.

- Adiabatic ($Q = 0$) $\rightarrow E_{int} = W$
- isothermal ($\Delta T = 0$)

$$\Delta E_{int} = Q - W$$

$$\frac{3}{2}NK_B dT = Q - PdV, PdV = Q$$

- Isocloric ($\Delta V = 0$) $\rightarrow W = 0 \rightarrow \Delta E_{int} = 0$
- isoboric ($\Delta P = 0$) $\rightarrow W = P\Delta V \rightarrow \Delta E_{int} = Q - P\Delta V$

3.15.1 Example 1

A sealed ideal gas is in a rigid container of $0.6m^3$ initially at room temperature ($T_1 = 20^\circ C \rightarrow 293K$) and pressure ($P_1 = 1atm \cong 10^5 pa$). If the temp “doubles” to $T_2 = 40^\circ C \rightarrow 313K$,
A.) what is the new pressure(P_2)?

$$PV = nRT$$

Or, $P_1 V_1 = n_1 R T_1, P_2 V_2 = n_2 R T_2$

$$\frac{P_1}{T_1} = \frac{n_1 R}{V_1} = const$$

$$\frac{P_2}{T_2} = \frac{n_1 R}{V_2} = \frac{n_1 R}{V_1}$$

therefore:

$$\frac{P_1}{T_1} = \frac{P_2}{T_2}$$

$$P_2 = P_1 \frac{T_2}{T_1}$$

$$= (10^5 pa) \frac{313K}{293K} = 1.07 * 10^5 pa$$

B.) How much work did the gas do?

$$dW = PdV$$

$$w_{1 \rightarrow 2} = \int_{V_1}^{V_2} PdV$$

$$w_{1 \rightarrow 2} = 0 \text{ There was no change in volume}$$

C.) How much heat was transferred (Not using $mc\Delta T$)?

$$\Delta E_{int} = Q - W (W = \int P dV = 0)$$

$$\Delta E_{int} = Q$$

$$Q = \frac{3}{2}nR(T_2 - T_1) = \frac{3}{2}NK_B(T_2 - T_1)$$

$$= \frac{3}{2}(P_2V_2 - P_1V_1)$$

$$Q = \frac{3}{2}V_1(P_2, P_1)$$

$$= 6,140J$$

3.15.2 Example 2

A sealed ideal gas undergoes an isobaric ($\Delta P = 0$) expansion during which it triples in volume. Then it is isothermically ($\Delta T = 0$) compressed to original volume, after which it cools to its original temperature. Find Q and W in terms of initial pressure and volume for each stage of cycle and the

full cycle. Draw a PV diagram as well.

$$PV = nRT$$

$$P = \frac{nRT}{V} \rightarrow T = \frac{PV}{nR}$$

$$\Delta E_{int_{cyc}} = 0 = Q_{cyc} - W_{cyc}$$

$$Q_{cyc} = W_{cyc}$$

A.) Find the work from 1 to 2:

$$\begin{aligned} W_{1 \rightarrow 2} &= \int_{V_1}^{V_2} PdV \\ &= \int_{V_1}^{3V_1} dV \\ &= P_1(3V_1 - V_1) \\ w_{1 \rightarrow 2} &= 2P_1V_1 \end{aligned}$$

B.) Find the work from 2 to 3:

$$\begin{aligned} W_{2 \rightarrow 3} &= \int_{v_2}^{v_3} PdV \rightarrow PV = nRT \rightarrow P = \frac{nRT}{V} \\ &= \int_{V_2}^{V_1} \frac{nRT}{V} dV \\ &= n_2RT_2 \int_{V_2=3V_1}^{V_1} \frac{dv}{V} \\ &= n_2RT_2 \ln\left(\frac{V_1}{3V_1}\right) = n_2RT_2 \ln\left(\frac{1}{3}\right) \\ w_{2 \rightarrow 3} &= -n_2RT_2 \ln(3) \rightarrow PV = nRT \\ &= -P_2V_2 \ln(3) \\ w_{2 \rightarrow 3} &= -3 \ln(3) P_1V_1 = -3.29 P_1V_1 \end{aligned}$$

C.) Find the work from 3 to 1:

$$\begin{aligned} w_{3 \rightarrow 1} &= \int_{v_3}^{v_1} PdV = 0 \\ w_{3 \rightarrow 1} &= 0 \end{aligned}$$

D.) Find the heat of the cycle

$$\begin{aligned} w_{cyc} &= w_{1 \rightarrow 2} + w_{2 \rightarrow 3} + w_{3 \rightarrow 1} = P_1V_1(2 - 3 \ln 3) \\ &= -1.30 P_1V_1 \end{aligned}$$

Since, $\Delta E_{int_{cyc}} = 0$, then $0 = Q_{cyc} - W_{cyc}$

$$Q_{cyc} = W_{cyc} = -1.30 P_1V_1$$

And since $2 \rightarrow 3$ is an isotherm, we know $Q = W$

$$Q_{2 \rightarrow 3} = W_{2 \rightarrow 3} = -3 \ln(3) P_1V_1$$

For $1 \rightarrow 2$:

$$\begin{aligned} \Delta E_{int_{1 \rightarrow 2}} &= Q_{1 \rightarrow 2} - W_{1 \rightarrow 2} \\ Q_{1 \rightarrow 2} &= \frac{3}{2} nR(T_2 - T_1) + 2P_1V_1 \\ &= \frac{3}{2} n_2RT_2 - \frac{3}{2} n_1RT_1 + 2P_1V_1 \\ &= \frac{3}{2} P_2V_2 - \frac{3}{2} P_1V_1 + 2P_1V_1 \\ &= \frac{3}{2} P_13v_2 - \frac{3}{2} P_1V_1 + 2P_1V_1 \\ &= \left(\frac{9}{2} - \frac{3}{2} + 2\right) P_1V_1 \end{aligned}$$

$$Q_{1 \rightarrow 2} = 5P_1V_1$$

3.16 Using C_V and C_P

While considering the first law, $dE_{int} = Q - PdV$, consider a constant volume: $dE_{int} = Q$, also: $E_{int} = \frac{3}{2}nRT$.

$$\frac{3}{2}nRdT = Q$$

$$nC_vdT = Q$$

$$\frac{3}{2}R = C_v \text{ if volume is constant}$$

$$dE_{int} = nC_vdT$$

when $\Delta V = 0$, then $Q = nC_V\Delta T$, but in all cases, $\Delta E_{int} = nC_V\Delta T$.

We have introduced $C_V = \frac{3}{2}R$

$$\text{But recall: } (v)_{avg}^2 = V_{x_{avg}}^2 + V_{y_{avg}}^2 + V_{z_{avg}}^2$$

which gives us three degrees of translation, which is also why:

$$k_{avg} = \frac{1}{2}m(v^2)_{avg}$$

$$\text{this leads us to } E_{int} = \frac{3}{2}nRT$$

We can generalize $C_V = \frac{3}{2}R$ to be $C_V = \frac{d}{2}R$ for degrees of freedom. Other degrees of freedom come from both rotation and vibration. Most monatomic atoms have 3 degrees of translation, and zero degrees of rotation and vibration. Diatomic atoms on the other hand have 3 degrees of translation, 2 degrees of rotation, and 1 degree of vibration.

Consider the case when $(\Delta P = 0)$. Let's preserve the form $Q = nC_PdT$

$$dE_{int} = Q - PdV$$

$$\Delta E_{int} = Q - P\Delta V$$

$$nC_V\Delta T = Q - P\Delta V$$

$$nC_V\Delta T = nC_P\Delta T - P\Delta V$$

Note that $PV = nRT$

$$dPV = d(nRT) \text{ therefore } P\Delta V = nR\Delta T$$

$$nC_V\Delta T = nC_P\Delta T - nR\Delta T$$

$$C_V = C_P - R$$

$$C_P = C_V + R$$

Now for ($Q = 0$),

$$\begin{aligned}
 dE_{int} &= Q - PdV \\
 nC_V dT &= -PdV \\
 ndT &= -\frac{P}{C_V} dT \\
 \text{because } PV &= nRT, \text{ we can conclude } ndT = \frac{V}{R} + \frac{P}{R} dV \\
 -\frac{P}{C_V} dT &= \frac{V}{R} dP + \frac{P}{R} dV \\
 \text{divide everything by } PV: & -\frac{1}{C_V} \frac{dV}{V} = \frac{1}{R} \frac{dP}{P} + \frac{1}{R} \frac{dV}{V} \\
 \text{Multiply by } C_V R & -R \frac{dV}{V} = C_V \frac{dP}{P} + C_V dV \\
 0 &= C_V \frac{dP}{P} + (C_V + R) \frac{dV}{V} \\
 &= C_V \frac{dP}{P} + C_P \frac{dV}{V} \\
 &= \int \frac{dP}{P} + \frac{C_P}{C_V} \int \frac{dV}{V} \\
 \text{const} &= \ln \frac{P}{P_o} + \frac{C_P}{C_V} \ln \frac{V}{V_o} \\
 PV^{\left(\frac{C_P}{C_V}\right)} &= \text{const} \\
 PV^\gamma &= \text{const for } \gamma = \frac{C_P}{C_V}
 \end{aligned}$$

3.16.1 Example 1

2.2 moles of Ar gas are in a sealed metal container at room temp ($20^\circ C = 68^\circ F$). We then put the container on the sidewalk on a hot ($35^\circ C = 95^\circ F$) day. Let the gas come to temp ($95^\circ F$).

A.) Was any work done by or on the gas? There was little displacement, so almost 0 work done on the container.

B.) was any heat transferred to or from the gas? Heat was transferred to the gas.

C.) Find the gas' internal energy. We can always write:

$$\begin{aligned}
E_{int} &= \frac{3}{2}NK_BT = \frac{3}{2}nRT \\
dE_{int} &= \frac{3}{2}K_B(TdV + NdT) \\
dE_{int} &= \frac{3}{2}K_BdT \\
\Delta E_{int} &= \frac{3}{2}NK_B\Delta T \\
\Delta E_{int} &= nR\Delta T \\
&= \frac{3}{2}(2.2mol)(8.314\frac{J}{molK})(35^\circ C - 20^\circ C) \\
&= 411J
\end{aligned}$$

More generally $E_{int} = \frac{d}{2}nRT$ Where d=degrees of translation

$$= nC_V T \text{ for } C_V = \frac{d}{2}R$$

Around room temperature for monotimic atoms, $C_V = \frac{3}{2}R$. For diatomic molecules it is $C_V = \frac{5}{2}R$.

3.16.2 Example 2

Solve the same problem where the only difference is the gas is a 2.2 moles of H_2 . Given the temperatures, we know that $C_V = \frac{5}{2}R$.

$$\begin{aligned}
\Delta E_{int} &= nC_V\Delta T \\
&= n\frac{5}{2}R\Delta T \\
&= \frac{5}{2}nR\Delta T \\
&= \frac{5}{2}(2.2mol)(8.314\frac{J}{molK})(15K) \\
&= 687J
\end{aligned}$$

3.16.3 Example 3

Calculate work done by a gas during adiabatic expansion from V_1 to $V_2 = 4V_1$ in terms of V_1 and V_2 . Remeber that adiabats result in no heat transfer ($Q = 0$) and $PV^\gamma = \text{constant}$, which means

$\gamma = \frac{C_P}{C_V} = \text{const.}$ Let $PV^\gamma = \text{const.}$

$$\begin{aligned}
\text{Always: } w &= \int_{V_1}^{V_2} P dV \\
&= \int_{V_1}^{V_2} V_2 \frac{b}{V^\gamma} dv \\
&= b \int_{V_1}^{V_2} V^{-\gamma} dv \\
&= \frac{b}{-\gamma + 1} V^{\gamma+1} \Big|_{V_1}^{V_2} = 4V_1 \\
&= \frac{b}{1-\gamma} \left[(4V_1)^{1-\gamma} - V_1^{1-\gamma} \right] \\
&= \frac{b}{1-\gamma} \left[4^{1-\gamma} V_1^{1-\gamma} - V_1^{1-\gamma} \right] \\
&= \frac{b}{1-\gamma} V_1^{1-\gamma} [4^{1-\gamma} - 1] \\
&= \frac{4^{1-\gamma} - 1}{1-\gamma} b V_1^{1-\gamma} \\
&= \frac{4^{1-\gamma} - 1}{1-\gamma} P_1 V_1^\gamma V_1^{1-\gamma} \\
W &= \frac{4^{1-\gamma} - 1}{1-\gamma} P_1 V_1
\end{aligned}$$

Work done by a gas during an adiabatic expansion from V_1 to $4V_1$. Let's find a more simplified answer for monatomic and diatomic gasses. The adiabatic ratio is $\gamma = \frac{C_P}{C_V}$, but it also means $C_P = C_V + R$. At room temperature, $C_V = \frac{3}{2}R$ for monatomic and $C_V = \frac{5}{2}R$.

$$\begin{aligned}
\gamma_{mon} &= \frac{\frac{3}{2}R + R}{\frac{3}{2}R} = \frac{\frac{5}{2}R}{\frac{3}{2}R} = \frac{5}{3} \\
\gamma_{dia} &= \frac{\frac{5}{2}R + R}{\frac{5}{2}R} = \frac{\frac{7}{2}R}{\frac{5}{2}R} = \frac{7}{5}
\end{aligned}$$

$$\begin{aligned}
\text{We found that } W &= \frac{4^{1-\gamma} - 1}{1-\gamma} P_1 V_1 \\
W_{dia} &= \frac{4^{1-\gamma} - 1}{1-\gamma} P_1 V_1 \text{ for } \gamma_{dia} = \frac{7}{5} \\
w_{dia} &= 1.06 P_1 V_1 \\
W_{mon} &= \frac{4^{\frac{3}{3}-\frac{5}{3}} - 1}{\frac{3}{3}\frac{5}{3}} P_1 V_1 \\
&= \frac{-4^{\frac{-2}{3}} - 1}{\frac{-2}{3}} P_1 V_1 \\
&= \frac{3}{2} \left(1 - 4^{\frac{-2}{3}} \right) P_1 V_1 \\
&= .905 P_1 V_1 \\
\Delta E_{int} &= -1
\end{aligned}$$

3.17 Entropy

Reversible processes can have their processes reversed in time. When played in reverse, the behavior still looks physical (like a video). Any real system will have dissipative forces and thus will not be perfectly reversible. Considering heat transfer, recording an ice cube melt and playing that video in reverse would look nonsensical. According to the second law of thermodynamics, heat always flows spontaneously from a hotter object to a colder object and vice versa. Irreversible process can happen within a closed system.

For a reversible system, entropy is given by $dS = \frac{dQ}{T}$. For isothermal processes:

$$\begin{aligned}\int dS &= \int \frac{dQ}{T} \\ \int dS &= \frac{1}{T} \int dQ \\ \Delta S &= \frac{Q}{T}\end{aligned}$$

Imagine an ice cube melting at 0°C . Then $Q = mL_f$,

$$\Delta S = \frac{mL_f}{T}$$

In general for a reversible process, we know:

$$\begin{aligned}dE_{int} &= dQ - dW \\ dQ &= dE_{int} + dW \\ \text{then entropy is: } ds &= \frac{dQ}{T} = \frac{dE_{int} + dW}{T} \\ &= \frac{nC_V dT + PdV}{T} = nC_V \frac{dT}{T} + P \frac{dV}{T} \\ \text{from the ideal gas law, } PV &= nRT \text{ or } \frac{P}{T} = \frac{nR}{V} \\ \text{then, } \int dS &= \int nC_V \frac{dT}{T} + \int \frac{nRdV}{V} \\ \Delta S_{0 \rightarrow 1} &= nC_V \ln \frac{T_1}{T_2} + nR \ln \frac{V_1}{V_2}\end{aligned}$$

For a reversible complete cycle:

$$\oint dS = 0$$

4 Electricity

4.1 Electrostatics

Electric charge is a property of some objects that allow such objects to feel an electric force. The units for charge are coulombs (C). The smallest amount of charge an object can have is the elementary charge: $e = 1.602 * 10^{-19}C$. For an electron, this is -e, while for a proton it is +e. As everyone knows, like charges repel, and opposite charges attract each other.

Any material we use is made of atoms, which themselves are made of charge. There are two different types of materials, insulators and conductors. For insulators, atomic/molecular electrons are stuck in place with their parent atom/molecule and their electrons are immobile. For conductors, the atomic/molecular electrons are shared among the material (these are also known as mobile electrons). Our typical insulators are wood, plastic, and printer paper, while typical conductors are metal, water, and humans.

The force that charge q_1 exerts on charge q_2 is: (Coulombs law)

$$F_{1 \rightarrow 2}(r_{1 \rightarrow 2}) = \frac{1}{4\pi\epsilon_0} \frac{q_1 q_2}{r_{1 \rightarrow 2}^2} r_{1 \rightarrow 2}$$
$$\text{Where } \epsilon_0 = 8.85 * 10^{-12} \frac{C^2}{Nm^2}$$

4.1.1 Example

Find the net force on q_c due to q_a and q_b where $q_a + q_b$ are fixed in space. Remember that forces are vectors.

$$\begin{aligned} F_{net_c}^{\vec{}} &= F_{bc}^{\vec{}} + F_{ac}^{\vec{}} \\ &= \frac{1}{4\pi\epsilon_0} \frac{q_b q_c}{r_{bc}^2} r_{bc}^{\hat{}} + \frac{1}{4\pi\epsilon_0} \frac{q_a q_c}{r_{ac}^2} r_{ac}^{\hat{}} \\ &= \frac{1}{4\pi\epsilon_0} \frac{q_b q_c}{X_0^2} (+\hat{i}) + \frac{1}{4\pi\epsilon_0} \frac{q_a q_c}{Y_0^2} (+\hat{j}) \\ &= \frac{1}{4\pi\epsilon_0} \left(\frac{q_b q_c}{x_0^2} \hat{i} + \frac{q_a q_c}{y_0^2} \hat{j} \right) \end{aligned}$$

if $q_b = q_a$ and $x_0 = y_0$, then

$$F_{net_c}^{\vec{}} = \frac{q_a q_c}{4\pi\epsilon_0 x_0^2} (\hat{i} + \hat{j})$$

Coulombs law works with super position:

$$F_{1 \rightarrow 2}^{\vec{}} = \frac{1}{4\pi\epsilon_0} \frac{q_1 q_2}{r_{1 \rightarrow 2}^2} r_{1 \rightarrow 2}^{\hat{}}$$

Find the force on charge Q_A due to other stationary charges:

$$\begin{aligned}
\vec{F}_{ba} &= \frac{1}{4\pi\epsilon_0} \frac{q_a q_b}{r_{ba}^2} \hat{r}_{ba} \\
&= \frac{1}{4\pi\epsilon_0} \frac{q_a q_b}{y_0^2} \hat{j} \\
\vec{F}_{ca} &= \frac{1}{4\pi\epsilon_0} \frac{q_a q_c}{r_{ca}^2} \hat{r}_{ca} \\
&= \frac{q_c q_a}{4\pi\epsilon_0} \left[\frac{1}{r_{ca}^2} \sin(\theta) (\hat{i}) + \frac{1}{r_{ca}^2} \cos(\theta) (-\hat{j}) \right] \\
&= \frac{q_c q_a}{r^2 \epsilon_0} \left[\frac{1}{x_0^2 + y_0^2} \frac{x_0}{\sqrt{x_0^2 + y_0^2}} \hat{i} - \frac{1}{\sqrt{x_0^2 + y_0^2}} \frac{y_0}{\sqrt{x_0^2 + y_0^2}} \hat{j} \right] \\
&= \frac{q_c q_a}{4\pi\epsilon_0} \frac{1}{(x_0^2 + y_0^2)^{\frac{3}{2}}} (x_0 \hat{i} - y_0 \hat{j})
\end{aligned}$$

Now find $f_{net_a} = F_{ca} + F_{ba}$

$$\begin{aligned}
&= (F_{ba_x} + F_{ca_x}) \hat{i} + (F_{ba_y} + F_{ca_y}) \hat{j} \\
F_{net_a} &= \frac{1}{4\pi\epsilon_0} \left[\frac{q_c q_a}{(x_0^2 + y_0^2)^{\frac{3}{2}}} x_0 \hat{i} + \left(\frac{q_b q_a}{y_0} - \frac{q_c q_a}{(x_0^2 + y_0^2)^{\frac{3}{2}}} y_0 \right) \hat{j} \right]
\end{aligned}$$

4.2 Electric Fields

A field is a function that has different values throughout space that can be changed in time. Temperature is a scalar field when looking at the temperature around a room. Wind patterns are a vector field on a weather map. We will study the electric field \vec{E} . This field helps us find the force exerted on any charge Q .

$$\vec{F} = Q\vec{E}$$

The field \vec{E} created by a charge q is:

$$\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r}$$

This field acts on another charge Q such that:

$$\begin{aligned}
\vec{F} &= Q\vec{E} \\
&= Q \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r} \\
\vec{F} &= \frac{1}{4\pi\epsilon_0} \frac{qQ}{r^2} \hat{r} \text{ (Coulombs Law)}
\end{aligned}$$

\vec{E} Fields point away from positive charges and towards negative ones. Since \vec{E} is a vector, if two or more static charges each create a field, the net field is their vector sum (superposition).

$$\vec{E}_{net} = \sum_{i=1}^n \vec{E}_i$$

4.2.1 Example 1

Two identical charges $q_1 = q_2 = q$ are equidistant from the origin on the x-axis. Find \vec{E} anywhere on the x-axis.

$$\begin{aligned}\vec{E} &= 2 \left(\frac{1}{4\pi\epsilon_0} \frac{q_2}{r_2^2} \cos\theta \right) \hat{k} \\ &= 2 \frac{1}{4\pi\epsilon_0} \frac{2qz}{\left(z^2 + \left(\frac{L}{2}\right)^2\right)^{\frac{3}{2}}} \hat{k} \\ \vec{E}(z) &= \frac{1}{4\pi\epsilon_0} \frac{2qz}{\left(z^2 + \left(\frac{L}{2}\right)^2\right)^{\frac{3}{2}}} \hat{K}\end{aligned}$$

What if the charges that make a field are grouped together closely? Then we will describe those charges as a continuous distribution. Linear charge density is $\lambda = \frac{dq}{dl} \rightarrow dq = \lambda dl$. Recall,

$$\begin{aligned}\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r} \\ &= \sum_{i=1}^N \frac{1}{4\pi\epsilon_0} \frac{q_i}{r_i^2} \hat{r}_i \rightarrow \vec{E} = \frac{1}{4\pi\epsilon_0} \int \frac{dq}{r^2} \hat{r}\end{aligned}$$

For this problem:

$$\begin{aligned}E &= \frac{1}{r\pi\epsilon_0} \int_{-\frac{L}{2}}^{\frac{L}{2}} \frac{\lambda dx}{z^2 + x^2} \frac{z}{\sqrt{z^2 + x^2}} \hat{k} \\ &= \frac{1}{r\pi\epsilon_0} \lambda z \int_{-\frac{L}{2}}^{\frac{L}{2}} \frac{dx}{(z^2 + x^2)^{\frac{3}{2}}} \hat{k} \\ &= \frac{1}{4\pi\epsilon_0} \lambda z \left(\frac{x}{z^2 \sqrt{x^2 + z^2}} \right) \Big|_{-\frac{L}{2}}^{\frac{L}{2}} \hat{k} \\ &= \frac{1}{4\pi\epsilon_0} \lambda z \left[\frac{\frac{L}{2} - \frac{-L}{2}}{z^2 \sqrt{\frac{L^2}{2} + z^2}} \right] \hat{k} \\ &= \frac{1}{4\pi\epsilon_0} 2\lambda z \frac{\frac{L}{2}}{z^2 \sqrt{\frac{L^2}{2} + z^2}} \hat{k}\end{aligned}$$

If the line of charge is inf in length, then the only change would be the bounds of the integral.

4.2.2 Example 2

Find \vec{E} where the midpoint of a uniform line of charge as shown. The X components cancel.

$$\begin{aligned} d\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{dq}{r^2} \hat{r} \\ \lambda &= \frac{dq}{dl} = \frac{dq}{dx} \\ dq &= \lambda dx \end{aligned}$$

We see that $E_x = 0$ while $E_z \neq 0$ then,

$$\begin{aligned} d\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{\lambda dx}{x^2 + z^2} \frac{z}{\sqrt{x^2 + z^2}} \hat{k} \\ &= \frac{1}{4\pi\epsilon_0} \frac{\lambda dx z}{(x^2 + z^2)^{\frac{3}{2}}} \hat{k} \\ E &= \int_{-\frac{L}{2}}^{\frac{L}{2}} \frac{1}{4\pi\epsilon_0} \frac{\lambda dx z}{(x^2 + z^2)^{\frac{3}{2}}} \\ &= \frac{\lambda z}{4\pi\epsilon_0} \int_{-\frac{L}{2}}^{\frac{L}{2}} (x^2 + z^2)^{-\frac{3}{2}} dx \\ \vec{E}(z) &= \frac{2\lambda z}{4\pi\epsilon_0} \frac{\frac{L}{2}}{z^2 \sqrt{\frac{L^2}{4} + z^2}} \hat{k} \end{aligned}$$

4.2.3 Example 3

Find \vec{E} for the situation shown:

$$\begin{aligned} d\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{dq}{r^2} \hat{r} \\ &= \frac{1}{4\pi\epsilon_0} \frac{\lambda dx}{r^2} (\cos\theta \hat{i} + \sin\theta \hat{k}) \\ &= \frac{\lambda}{4\pi\epsilon_0} \left[\int_0^L \frac{dx(x-L)}{(z^2 + (x-L))^{\frac{3}{2}}} \hat{i} + \int_0^L \frac{dx z}{(z^2 + (x-L))^{\frac{3}{2}}} \right] \end{aligned}$$

We will let $x' = x - L$

$$x = 0 \rightarrow x' = 0 - L = -L$$

$$x = L \rightarrow x' = 0$$

$$dx' = dx - dL \text{ because } L = \text{const}$$

$$\begin{aligned} &= \frac{\lambda}{4\pi\epsilon_0} \left[\int_{-L}^0 \frac{dx' x'}{(z^2 + x'^2)^{\frac{3}{2}}} \hat{i} + \int_{-L}^0 \frac{dx' z}{(z^2 + x'^2)^{\frac{3}{2}}} \hat{k} \right] \\ \vec{E} &= \frac{\lambda}{4\pi\epsilon_0} \left[\frac{x'}{x'^2 \sqrt{x^2 + z^2}} \Big|_{x'=L}^{x'=0} \hat{i} + \frac{-1}{\sqrt{x^2 + z^2}} \Big|_{x'=-L}^{x'=0} \hat{k} \right] \end{aligned}$$

4.3 Electric Field Lines

We can draw field lines to represent how an electric field looks in space. Recall that for a point charge, $\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r}$

Let's find \vec{E} above the midpoint of two opposite charges $+q$ and $-q$ which are a distance d apart.

$$\begin{aligned}
 r^2 &= z^2 + \left(\frac{d}{2}\right)^2 \\
 \vec{E} &= \vec{E}_- - \vec{E}_+ \\
 &= \frac{1}{4\pi\epsilon_0} \frac{q}{z^2 + \frac{d^2}{2}} \left(-\frac{\frac{d}{2}}{\sqrt{z^2 + \frac{d^2}{2}}} \hat{i} - \frac{z}{\sqrt{z^2 + \frac{d^2}{2}}} \hat{k} \right) + \frac{1}{4\pi\epsilon_0} \frac{q}{z^2 + \frac{d^2}{2}} \left(-\frac{\frac{d}{2}}{z^2} \hat{i} + \frac{z}{\sqrt{z^2 + \frac{d^2}{2}}} \hat{k} \right) \\
 \vec{E} &= -\frac{1}{4\pi\epsilon_0} \frac{qd}{\left(z^2 + \frac{d^2}{2}\right)^{\frac{3}{2}}} \hat{i}
 \end{aligned}$$

Consider $\vec{p} = q\vec{d}$. This is an electric dipole moment.

$$\vec{E} = -\frac{1}{r\pi\epsilon_0} \frac{\vec{p}}{\left(z^2 + \frac{d^2}{2}\right)^{\frac{3}{2}}}$$

As you get further from the dipole, $z \gg d$:

$$\vec{E} \cong -\frac{1}{4\pi\epsilon_0} \frac{\vec{p}}{(z^2)^{\frac{3}{2}}}$$

If you get very far away: $z \rightarrow \infty$ or $\frac{d}{2} \rightarrow \infty$

$$\vec{E} = \frac{-1}{4\pi\epsilon_0} \frac{qd}{\left(z^2 + \frac{d^2}{2}\right)^{\frac{3}{2}}} \hat{i} = \frac{-1}{4\pi\epsilon_0} \frac{q\left(\frac{d}{z}\right)}{\left(1 + \frac{d^2}{2z^2}\right)^{\frac{3}{2}}} \hat{i}$$

For dipoles in an external field, $\vec{p} = q\vec{d}$. The net displacement force on \vec{p} is 0, but it will have torque.

$$\begin{aligned}
 \tau &= \vec{r} \times \vec{F} = \left(\frac{\vec{d}}{2} \times \vec{F}_+ \right) + \left(\frac{\vec{d}}{2} \times \vec{F}_- \right) = \left(\frac{\vec{d}}{2} \times q\vec{E}_{ext} \right) + \left(-\frac{\vec{d}}{2} \times q\vec{E}_{ext} \right) \\
 &= 2 \left(\frac{\vec{d}}{2} \times q\vec{E}_{ext} \right) \\
 \vec{\tau} &= (q\vec{d} \times \vec{E}_{ext}) \\
 \boxed{\vec{\tau} &= \vec{P} \times \vec{E}_{ext}}
 \end{aligned}$$

4.3.1 Example 1.

The field \vec{E} is above the center of a uniformly charged ring is $\vec{E} = \frac{1}{r\pi\epsilon_0} \frac{Qz}{(z^2 + k^2)^{\frac{3}{2}}} \hat{k}$. Now let the ring instead, be a disk with total charge Q that is uniformly distributed.

Total charge Q over a total area of πR^2

$$\begin{aligned}\frac{Q}{\pi R^2} &= \sigma \\ dQ &= \sigma 2\pi r dr \\ dE &= \frac{1}{4\pi\epsilon_0} \frac{dQ}{r^2} \hat{r} \\ dQ &= \sigma 2\pi r' dr'\end{aligned}$$

All of the x and y components vanish, which leaves us with:

$$\begin{aligned}\int dE &= \int \frac{1}{4\pi\epsilon_0} \frac{\sigma 2\pi r' dr'}{r'^2 + z^2} \frac{z}{\sqrt{r'^2 + z^2}} \hat{k} \\ \vec{E} &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma z \int_0^R \frac{r' dr'}{(r'^2 + z^2)^{\frac{3}{2}}} \hat{k} \\ &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma z \left(-\frac{1}{\sqrt{r'^2 + z^2}} \right) \Big|_{r'=0}^{r'=R} \\ &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma z \left[-\frac{1}{R^2 + z^2} - \frac{1}{z} \right] \hat{k} \\ \boxed{\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{2Q}{R^2} z \left(\frac{1}{z} - \frac{1}{\sqrt{R^2 + z^2}} \right) \hat{k}}\end{aligned}$$

4.4 Flux and Gauss's Law

Flux is the amount of flow of a material or substance through some region. Area vectors point out of the plane of the area itself. Flux is denoted by Φ , and the equation for flux is:

$$\Phi = \int \vec{f} \cdot d\vec{a}$$

4.4.1 Example 1

Find the flux Φ of $\vec{E} = \epsilon_0 \frac{z}{z_0} \vec{i}$ through an area $y_0 + z_0$ in the y-z plane.

$$\begin{aligned}\Phi &= \int \vec{E} \cdot d\vec{a} \\ &= \int E da \\ &= \int_0^{z_0} \int_0^{y_0} E da \\ &= \int_0^{z_0} \int_0^{y_0} \epsilon_0 \frac{z}{z_0} dy dz \\ &= \epsilon_0 \frac{y_0}{z_0} \int_0^{z_0} dz \\ &= \epsilon_0 \frac{y_0}{z_0} \left(\frac{1}{2} z_0^2 - \frac{1}{2} 0^2 \right) \\ \boxed{\Phi &= \frac{1}{2} \epsilon_0 y_0 z_0}\end{aligned}$$

First, a single charge Q . We must apply a Gaussian surface to the point charge:

$$\begin{aligned}
 \Phi &= \int \vec{E} \cdot d\vec{a} = \int (E\hat{r}) \cdot (da\hat{r}) \\
 &= \int \vec{E} \cdot d\vec{a} \\
 &= \int \frac{1}{4\pi\epsilon_0} \frac{1}{R^2} da \\
 &= \frac{1}{4\pi\epsilon_0} \int da \\
 &= \frac{q}{\epsilon_0}
 \end{aligned}$$

More generally, we write:

$$\Phi_E = \oint \vec{E} \cdot d\vec{a} = \frac{q}{\epsilon_0}$$

This brings us to Gauss's law. This law is always true but it is only useful in certain situations. 1) When $\vec{E} \cdot d\vec{a}$ is an easy dot product (they are parallel vectors). 2) When E is constant in magnitude across the surface. Then we can pull E through the integral. 3) When the total surface area is known. For example, we want the equations to be able to do the following:

$$\begin{aligned}
 &\oint \vec{E} \cdot d\vec{a} \\
 &\oint E da \\
 &E \oint da / \text{to } E_a = \frac{q_{inside}}{\epsilon_0}
 \end{aligned}$$

4.4.2 Example 2

A sphere has a uniform charge Q throughout its volume and radius, R . Find E everywhere.

Outside:

$$\begin{aligned}
 \oint \vec{E} \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
 \oint E da &= \frac{Q}{\epsilon_0} \\
 E \oint da &= \frac{Q}{\epsilon_0} \\
 E 4\pi r^2 &= \frac{Q}{\epsilon_0} \\
 \boxed{\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{Q}{r^2} \hat{r} \text{ for } r > R}
 \end{aligned}$$

Now for the inside:

$$\begin{aligned}
 \int dq_{enc} &= \int \rho dv \\
 q_{enc} &= \rho \int dv_{gauss} \\
 &= \rho \frac{4}{3} \pi r^3 \\
 \text{Also } \rho &= \frac{Q}{\frac{4}{3} \pi R^3} \\
 E 4\pi r^2 &= \frac{q_{enc}}{\epsilon_0} \\
 E &= \frac{1}{4\pi r^2} \frac{1}{\epsilon_0} Q \frac{r^3}{R^3} \\
 \boxed{E &= \frac{1}{4\pi \epsilon_0} \frac{Qr}{R^3} \hat{r} \text{ for } r < R}
 \end{aligned}$$

4.4.3 Example 3

Find \vec{E} everywhere for a very long line of charge with a charge density λ (constant and uniform charge).

$$\begin{aligned}
 \oint \vec{E} \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
 \int \vec{E} \cdot d\vec{a}_{curve} + \int \vec{E} \cdot d\vec{a}_{left} + \int \vec{E} \cdot d\vec{a}_{right} &= \int \vec{E} \cdot d\vec{a}_{curve} = \frac{\lambda l}{\epsilon_0} \\
 \int \vec{E} \cdot d\vec{a}_{curve} &= \frac{\lambda l}{\epsilon_0} \\
 E \int d\vec{a}_{curve} &= \frac{\lambda L}{\epsilon_0} \\
 E(2\pi r l) &= \frac{\lambda l}{\epsilon_0} \\
 \boxed{\vec{E} &= \frac{\lambda}{2\pi \epsilon_0 r} \hat{r}}
 \end{aligned}$$

4.4.4 Example 4

A sphere has a non-uniform charge density of $\rho = \rho_0 \frac{r}{R}$ for a sphere with a radius, R . Find \vec{E} everywhere.

$$\int \int \int dx dy dz \rightarrow \int \int \int r^2 \sin \theta d\theta dr d\phi$$

First, the outside:

$$\begin{aligned}
r &> R \\
\oint \vec{E} \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
\oint E da &= \frac{q_{enc}}{\epsilon_0} \\
E \oint da &= \frac{q_{enc}}{\epsilon_0} \\
E(4\pi r^2) &= \frac{q_{enc}}{\epsilon_0} \\
\int dq_{enc} &= \int \rho dV_{enc} \\
q_{enc} &= \int \rho_0 \frac{r}{R} dV \\
&= \frac{\rho_0}{R} \int_0^{2\pi} \int_0^\pi \int_0^R r r^2 \sin\theta dr d\theta d\phi \\
&= \frac{\rho_0}{R} 4\pi \int_0^R r^3 dr \\
&= \rho_0 \frac{1}{R} 4\pi \frac{1}{4} R^4 \\
q_{enc} &= \pi \rho_0 R^3 \\
E(4\pi r^2) &= \frac{1}{\epsilon_0} \pi \rho_0 R^3 \\
\boxed{\vec{E} = \frac{1}{4\epsilon_0} \frac{\rho_0 R^3}{r^2} \hat{r} \text{ for } r > R}
\end{aligned}$$

What about for $r < R$? Because of the boundary, we will have to separately find \vec{E} for $r < R$:

$$\begin{aligned}
\oint \vec{E} \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
\oint E da &= \frac{q_{enc}}{\epsilon_0} \\
E \oint da &= \frac{q_{enc}}{\epsilon_0} \\
E(4\pi r^2) &= \frac{q_{enc}}{\epsilon_0} \\
\int dq_{enc} &= \int \rho dV_{gauss} \\
q_{enc} &= \int \rho_0 \frac{r}{R} dV_{gauss} = \frac{\rho_0}{R} \int_0^{2\pi} \int_0^\pi \int_0^r rr^2 \sin\theta dr d\theta d\phi \\
&= 4\pi \frac{\rho_0}{R} \int_0^r r^3 dr \\
q_{enc} &= \pi \frac{\rho_0}{R} r^4 \\
\rightarrow \text{Gauss's law } E(4\pi r^2) &= \frac{1}{\epsilon_0} \pi \rho_0 \frac{r^4}{R} \\
E &= \frac{1}{4\epsilon_0 R} \rho_0 r^2 \\
\boxed{E} &= \frac{1}{4\epsilon_0} \rho_0 \frac{r^2}{R}
\end{aligned}$$

The equations agree at $r = R$, therefore when greater than or equal to and less than and equal to, the answer also works as $r \rightarrow 0$ or $r \rightarrow \infty$.

4.4.5 Example 4 (Gauss's Law with Conductors)

: Let's consider 2 large conductivity plates that are side by side. Let's put $\pm Q$ on both of the conductivity plates.

$$\begin{aligned}
\oint \vec{E} \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
\int \vec{E} d\vec{a}_{right} + \int \vec{E} d\vec{a}_{left} + \int \vec{E} d\vec{a}_{top} + \int \vec{E} d\vec{a}_{bottom} + \int \vec{E} d\vec{a}_{top} + \int \vec{E} d\vec{a}_{front} \\
\int \vec{E} d\vec{a}_{right} + \int \vec{E} d\vec{a}_{left} &= \frac{q_{enc}}{\epsilon_0} \\
E_a + E_a &= \frac{q_{enc}}{\epsilon_0} \text{ Surface charge density} \\
2E_a &= \frac{\sigma a}{\epsilon_0} \hat{i} \text{ Between plates} \\
\vec{E} &= \frac{\sigma}{2\epsilon_0} \hat{i} \text{ left of the plates}
\end{aligned}$$

Now for the right plate:

4.5 Electric Potential

4.5.1 Example 1

Find \vec{E} above a disk of charge distribution that is uniform. the disk has radius (R) and total charge (Q). Let's find V then \vec{E}

$$dV = \frac{1}{4\pi\epsilon_0} \frac{dq}{r}$$

The charge distribution is $\sigma = \frac{Q}{\pi R^2}$

$$\begin{aligned} dq &= \sigma dA \\ &= \sigma 2\pi r dr \end{aligned}$$

This r is not the same r as before, so we will call them r'

$$\begin{aligned} &= \sigma 2\pi r' dr' \\ dV &= \frac{1}{4\pi\epsilon_0} \frac{\sigma 2\pi r' dr'}{\sqrt{z^2 + r'^2}} \\ V &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma \int_0^R \frac{r' dr'}{\sqrt{z^2 + r'^2}} \\ V &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma \sqrt{z^2 + r'^2} \Big|_{r'=0}^{r'=R} \\ \boxed{V &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma \left[\sqrt{z^2 + R^2} - z \right]} \end{aligned}$$

Now let's find \vec{E}

$$\begin{aligned} E_x &= -\frac{\partial}{\partial x} V = 0 \\ E_y &= -\frac{\partial}{\partial y} V = 0 \\ E_z &= -\frac{\partial}{\partial z} V = -\frac{1}{4\pi\epsilon_0} 2\pi\sigma \left[\frac{1}{2} (z^2 + R^2)^{-\frac{1}{2}} 2z - 1 \right] \\ \boxed{\vec{E} &= \frac{1}{4\pi\epsilon_0} 2\pi\sigma \left[1 - \frac{z}{\sqrt{z^2 + R^2}} \hat{K} \right]} \end{aligned}$$

What does it mean to have potential charge? Potential doesn't have a proper value. Defining a reference point for V. $E_s = -\frac{\partial}{\partial s} V$. Consider V and $V + V_0$ where V_0 is a constant. We get the same \vec{E} value. $E_s = -\frac{\partial}{\partial s} V = -\frac{\partial}{\partial s} (V + v_0)$. This is analogous to choosing an origin. For example, if you are going to calculate the velocity of a marker hitting the ground, you have to keep track of position so you must choose an origin. This is the same way that V is chosen when doing these equations. We need to choose where $V = 0$. We choose $V = 0$ at infinity. Recall that $V = \frac{1}{4\pi\epsilon_0} \frac{q}{r}$.

4.6 Electrostatic Potential Energy

Electric forces are conservative. This doesn't mean not progressive, it means that they conserve energy. We can do these calculations using energy alone, similar to gravity or $MgH = \frac{1}{2}mv^2$. The

law of energy conservation is $\Delta K + \Delta U = 0$. Energy is not always conserved though. One physics 103 example is friction (drag). Dissipative forces are also a good example of ways energy is not fully conserved. Energy is not lost, it is just converted from translational energy to heat energy. Macroscopically, the energy is not conserved, but at a microscopic level, the energy is fully conserved. We will not consider dissipative forces in this course. This means that we can use the law of energy conservation ($\Delta K + \Delta U = 0$). We've said previously that the $U = QV$. Very similar to $\vec{F} = Q\vec{E}$.

4.6.1 Example 1

Charge $Q_1 = 6\mu C$ and $Q_2 = 4\mu C$ are released from rest at a distance apart of $l = 10cm$. Find their final speeds v_1 and v_2 . The forces of point Q_1 and Q_2 are going to exert forces away from each other. It is possible to take a force approach to this problem, but as they move apart, their acceleration changes. This makes the problem much more difficult, but you can do an energy approach because the stages in between do not matter within this approach. We will solve this using energy.

$$\Delta K + \Delta U = 0$$

$$K_1 - K_0 + U_1 - U_2 = 0$$

We have to change either Q_1 and Q_2 or change K_0 and K_1 because they don't mean the same thing. We are going to change Q to be Q_A and Q_B . Initially, their kinetic energy is zero:

$$K_1 + U_1 - U_0 = 0$$

$$\left(\frac{1}{2}m_A v_a^2 + \frac{1}{2}m_b v_b^2\right) + \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{r_{AB}} - \frac{1}{4\pi\epsilon_0} \frac{Q_A}{l} = 0$$

Interaction energy is a better term than potential energy. Potential energy goes in pairs. It is how two charges interact, not how a single charge exists. No matter how far apart they are, they will exert a force on each other. $\frac{Q_A}{Q_B} \rightarrow 0$ because $r_{AB} \rightarrow 0$

$$\frac{1}{2}m_A v_A^2 + \frac{1}{2}m_B v_B^2 = \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{l}$$

Let $M_A = M_B = 15g$

In this system, $\vec{F}_{AB} = -\vec{F}_{BA}$ Also there are no external forces acting so,

$$\begin{aligned}
\vec{F}_{net} &= \vec{F}_{AB} + \vec{F}_{BA} = 0 = \frac{d}{dt} \vec{P} \\
\Delta P_{01} &= 0 = P_1 - P_0 \\
0 &= m_A v_A + m_B v_B \\
\rightarrow v_A^2 &= V_B^2 \frac{m_B^2}{m_A^2} \\
\rightarrow \frac{1}{2} m_A \left[v_B^2 \frac{m_B^2}{m_A^2} \right] + \frac{1}{2} m_B v_B^2 &= \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{l} \\
\frac{1}{2} v_B^2 \left[\frac{m_B^2}{m_A} + m_B \right] &= \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{l} \\
m_b v_B^2 &= \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{l} \\
v_b &= \sqrt{\frac{1}{m_b} \frac{1}{4\pi\epsilon_0} \frac{Q_A Q_B}{l}} \\
v_a &= -v_B \frac{m_B}{m_A} \\
v_A &= -v_B
\end{aligned}$$

5 Circuits

5.1 Capacitance

Previously we found that $E = \frac{\sigma}{2\epsilon_0} + \frac{\sigma}{2\epsilon_0} = \frac{\sigma}{\epsilon_0}$ where $\sigma = \frac{Q}{A}$. Let's find potential V between the plates. Recall that $v = -\int \vec{E} \cdot d\vec{s}$.

$$\begin{aligned} V &= -\int_0^d \vec{E} \cdot d\vec{s} \\ \text{for } \vec{E} &= \frac{\sigma}{\epsilon_0} \\ V &= -\int_0^d E ds = -\int_0^d E dx \\ &= -E \int_0^d dx \\ V &= -Ed \text{ This is from the pos to negative plate} \end{aligned}$$

Equivalently from - to + plate:

$$\begin{aligned} V &= -\int_0^d \vec{E} \cdot d\vec{s} \\ &= -\int_0^d (-E ds) = \int_0^d E dx \\ V &= Ed \text{ This is from neg to pos plate} \end{aligned}$$

Now we want to relate our two equations to a charge to find the charge within the plate.

Consider that if there are more charges on the plates, then the potential (difference) between them will be larger. Difference is in parenthesis because we could have had a ΔV instead of just a V if we wanted. The potential goes with the field, and the field is larger if we have more charges in it.

$$Q = CV$$

Let us introduce capacitance C such that $Q = CV$. In magnitude, we found $V = Ed$, which gives the potential difference across the plates. And $E = \frac{\sigma}{\epsilon_0}$

$$V = \frac{\sigma}{\epsilon_0} d = \frac{1}{\epsilon} \frac{Q}{A} d$$

Using our new definition of $V = \frac{Q}{C}$, we find:

$$\begin{aligned} \frac{1}{\epsilon_0} \frac{Q}{A} d &= \frac{Q}{C} \\ C &= \epsilon_0 \frac{A}{d} \end{aligned}$$

This is for parallel plate capacitance. This only depends on geometry. Due to the equation $Q = CV$, as soon as we know the charge on the plates we can easily determine the potential energy of the plates. $Q = CV$ is true for all capacitors.

Let's discuss combining capacitors. For a parallel plate capacitor, we found that its capacitance is $C = \epsilon_0 \frac{A}{d}$. What if we stacked plates together? What would the capacitance be for this combined system?

$$\begin{aligned} A_{new} &= A_1 + A_2 + A_3 \\ &= \frac{d}{\epsilon_0} C_1 + \frac{d}{\epsilon_0} C_2 + \frac{d}{\epsilon_0} C_3 \\ \frac{d}{\epsilon_0} C_{new} &= \frac{d}{\epsilon_0} C_1 + \frac{d}{\epsilon_0} C_2 + \frac{d}{\epsilon_0} C_3 \end{aligned}$$

d is the same everywhere, and ϵ_0 is a constant so they both cancel

$$\begin{aligned} C_{new} &= C_1 + C_2 + C_3 \\ C_{new} &= C_{parallel} \end{aligned}$$

Capacitance increases when area is increased.

What if instead we put capacitors one after another (in sequential order)? The area is the same, and the two middle sets of plates are going to have zero charge.

$$\begin{aligned} d_{new} &= d_1 + d_2 + d_3 \\ \epsilon_0 \frac{A}{C_{new}} &= \epsilon_0 \frac{A}{C_1} + \epsilon_0 \frac{A}{C_2} + \epsilon_0 \frac{A}{C_3} \\ \frac{1}{C_{series}} &= \frac{1}{C_1} + \frac{1}{C_2} + \frac{1}{C_3} + \dots \\ C_{series} &= \left[\frac{1}{C_1} + \frac{1}{C_2} + \frac{1}{C_3} + \dots \right]^{-1} \end{aligned}$$

Capacitance let's us calculate the energy stored inside of the field between its plates. This is similar to throwing a ball from a lower surface to a higher one. The kinetic energy is changed into potential energy.

Recall that $U = VQ$.

Consider:

$$dU = VdQ$$

and $Q = CV$

$$\begin{aligned}\rightarrow dU &= \frac{Q}{C}dQ \\ U &= \frac{1}{C} \int QdQ \\ &= \frac{1}{C} \frac{1}{2} Q^2 \\ &= \frac{1}{2} \frac{1}{C} C^2 V^2 \\ \boxed{U &= \frac{1}{2} CV^2}\end{aligned}$$

Or

$$\begin{aligned}\boxed{U &= \frac{1}{2} \frac{Q^2}{C}} \\ U &= \frac{1}{2} Q^2 \frac{V}{Q} \\ \boxed{U &= \frac{1}{2} QV}\end{aligned}$$

Let's discuss energy density.

$$u = \frac{U}{volume}$$

This is always true, but for a parallel-plate capacitor, the volume is:

$$volume = Ad$$

Then,

$$\begin{aligned}U &= \frac{1}{2} CV^2 \\ \rightarrow u &= \frac{1}{2} CV^2 \frac{1}{Ad} \\ &= \frac{1}{2} \left(\epsilon_0 \frac{A}{d} \right) V^2 \frac{1}{Ad} \\ u &= \frac{\epsilon_0}{2} \frac{V^2}{d^2} \\ u &= \frac{\epsilon_0}{2} \left(\frac{V}{d} \right)^2\end{aligned}$$

Recall,

$$\begin{aligned}V &= Ed \\ \rightarrow E &= \frac{V}{d}\end{aligned}$$

We find

$$u = \frac{\epsilon_0}{2} E^2$$

Energy density relies solely on the energy field between the plates.

5.1.1 Example 1

Let's find the capacitance C of the demo capacitor. The area of the capacitor is A ($A = \pi r^2$) for $r = 6\text{cm}$. $A = \pi 36\text{cm}^2$, also d is 2cm . We also need ϵ_0 . This number is a constant. $\epsilon_0 = 8.85 \times 10^{-12} \frac{F}{m}$, where F stands for farads. For parallel plates, $C = \epsilon_0 \frac{A}{d}$. The units are farads (F).

$$C = \left(8.85 \times 10^{-12} \frac{F}{m} \right) \left(\frac{\pi 36\text{cm}^2}{2\text{cm}} \right) \left(\frac{1m}{100\text{cm}} \right)$$

$$C = 5.00 \times 10^{-12} F = 5\text{pF}$$

C of the other two objects:

$$C_{\text{blue}} = 10\mu F = 10 \times 10^{-6} F = 10^{-5} F$$

$$C_{\text{brown}} = 0.33\mu F = 0.33 \times 10^{-6} F = 3.3 \times 10^{-7}$$

The capacitance of a capacitor is typically given within tolerances, not as raw numbers. Let's find the electric field around the first capacitor. If there is no charge on the plates, then there is no electric field between the plates, thus the capacitor is not storing any energy. An analogy to gravity: if there is no mass for two plates you're trying to calculate gravity for, then there is no gravity between the two plates. By adding electric charge to the plates, a field is created between them in which energy is stored.

$$U = \frac{1}{2} CV^2$$

$$Q = CV$$

$$U = \frac{1}{2} QV$$

$$= \frac{1}{2} \frac{Q^2}{C}$$

Let's put a 9V battery across our capacitor.

$$U = \frac{1}{2} CV^2$$

$$= \frac{1}{2} (5 \times 10^{-12} F) (9V)^2$$

$$U = 2.03 \times 10^{-10} J$$

$$U = .203\text{nJ}$$

Consider a microwave oven. Many are powered at around 1200 Watts. We run it for 2 minutes. How much energy does this use? How much time is how much energy used?

$$\begin{aligned}
 P &= \frac{\Delta E}{\Delta T} \\
 \Delta E &= P \Delta T \\
 &= \left(1200 \frac{J}{s}\right) (120s) \\
 \boxed{\Delta E &= 144000J} \\
 &= 144kJ
 \end{aligned}$$

There are some benefits for something using a low amount of power. Let's recall that $C = 5 \times 10^{-5}$. Q of d would like instead $10 \times 10^{-17} F$. d can combine capacitors. Consider $C = \epsilon \frac{A}{d}$. If you want more capacitance, you can increase the area. If you double the area you double the capacitance.

$$\begin{aligned}
 C &= C_1 + C_2 \\
 &= 2C \\
 &= 10 \times 10^{-12}
 \end{aligned}$$

5.1.2 Example 2

There is a potential across the plates such that if a charge is placed you can easily calculate the potential energy and then the kinetic energy. Let's find the capacitants of something that is not necessarily parallel plates. We still need 2 plates, but they are not going to be flat plates. We are going to calculate the capacitance of a spherical capacitor.

$$\begin{aligned}
 Q &= CV \\
 C_{parallelplates} &= \epsilon_0 \frac{A}{d}
 \end{aligned}$$

The capacitance of a capacitor is always fully defined.

For the spherical case, let's find C. Q is the charge on either plate, NOT BOTH. This is to prevent having zero as your Q value. The easiest way to find the voltage is by using Gauss' law to find \vec{E} to find the electric field then using that to solve for the volutage.

$$\begin{aligned}
 \vec{E} &= 0 \quad r < a \\
 \vec{E} &= 0 \quad r > b
 \end{aligned}$$

For $a < r < b$:

$$\begin{aligned}
 \oint E \cdot d\vec{a} &= \frac{q_{enc}}{\epsilon_0} \\
 E(4\pi r^2) &= \frac{Q}{\epsilon_0} \\
 \boxed{\vec{E} &= \frac{1}{4\pi\epsilon_0} \frac{Q}{r^2} \hat{r}} \\
 V &= - \int \vec{E} \cdot d\vec{l}
 \end{aligned}$$

From $r = a$ to $r = b$

$$V = - \int_a^b \frac{1}{4\pi\epsilon_0} \frac{Q}{r^2} \hat{r} \cdot d\vec{r}$$

Potential is always path independent. The dot product enforces it in this situation. It always ends up being $E \cdot dl$ which is in the r direction. Therefore the direction does not matter but the start and endpoints do matter. Analogous to gravity where the potential energy remains the same regardless of the horizontal position of an object.

$$= - \frac{1}{r\pi\epsilon_0} Q \int_a^b \frac{1}{r^2} \hat{r} \cdot dr \hat{r}$$

This can be done because it is being written in it's direction vector times the magnitude. This will make the computations easier. Now we are able to find the dot product because the unit vectors are being dotted now as well.

$$\begin{aligned} &= - \frac{1}{4\pi\epsilon_0} Q \int_a^b r^{-2} dr \\ V &= - \frac{1}{4\pi\epsilon_0} Q (-r^{-1}) \Big|_{r=a}^{r=b} \\ V &= \frac{1}{4\pi\epsilon_0} Q \left(\frac{1}{b} - \frac{1}{a} \right) \end{aligned}$$

We need to ask ourselves if the sign or the units make sense for the sign. From $a \rightarrow b$, the voltage should decrease because it's being taken away from the electric charge. V is always a scalar so our "direction" is correct. We can now use $Q = CV$. Q is not the total charge, it is the charge on either plate.

$$\begin{aligned} C &= \frac{Q}{V} = \frac{|Q|}{|V|} \\ &= \frac{Q}{\frac{1}{4\pi\epsilon_0} Q \left(\frac{1}{a} - \frac{1}{b} \right)} \\ &= 4\pi\epsilon_0 \left(\frac{1}{a} - \frac{1}{b} \right)^{-1} \end{aligned}$$

$$\boxed{C = 4\pi\epsilon_0 \frac{ab}{b-a}}$$

5.2 Dialectics

We can nicely build capacitors by placing insulators between the plates. If you can decrease the space between the capacitors, then there is a higher capacitance level. For parallel plates,

$$\begin{aligned} \vec{E}_{new} &= \vec{E} + \vec{E}_i \\ \vec{E}_{new} &< \vec{E} \\ \vec{E}_{new} &= \frac{1}{\kappa} \vec{E} \\ C &= \kappa C_0 \end{aligned}$$

5.3 Current and Resistance

Electric current is the movement of charges in time. $I = \frac{dq}{dt}$ This means that in order to have a current, the mobile charges must be in the presence of an electric field. If you apply a force, then the charges start to move and the movement of charges is an electric current. Imagine a region with some charges and due to external charges, an external electric field affects the charges in the original region. All of the charges are going to move in the direction of the field. Because of this, the motion of the charges is messy. Also, electrons on a conductor. The electrons are all initially going to be spread out along the conductor, but if an electric field is implemented along the surface of the field, all of the charges are going to move the opposite direction of the electric field. The charges end up zigzagging along the path of the conductor.

Charge is given in Coulombs (C). The elementary charge is $e = 1.602 \times 10^{-19}C$. The unit for current is $\frac{C}{s}$. This is also called an ampere or amp (A).

Consider a copper wire being influenced by an external electric field (figure 4.9.1). v_d is the drift velocity. This is the average speed of charged particles moving in a current. What about for electrons in a copper wire?

We've said:

$$I = \frac{dq}{dt}$$

Let's break it down into individual charges:

$$\begin{aligned} I &= \frac{d(eN)}{dt} \\ &= e \frac{dN}{dT} \\ &= e \frac{ndV}{dt} \end{aligned}$$

Where n is the number of electrons in a volume

$$\begin{aligned}
 &= e \frac{nAdl}{dt} \\
 &= enAv_d \\
 \boxed{v_d = \frac{I}{enA}}
 \end{aligned}$$

For a current of 10A, consider a copper wire of radius 1mm. We know that $e = 1.602 \times 10^{-19}$, and $A = \pi r^2$ for $r = 1mm$. The number density is around $10^{23} \frac{1}{cm} \left(\frac{100cm}{m} \right)^3 = 10^{29} \frac{1}{m^3}$. Plugging these numbers in we will find a typical drift velocity of about $v_d \approx 10^{-4} \frac{m}{s}$ or $0.1 \frac{mm}{s}$. This is very slow.

Current density is:

$$\begin{aligned}
 dI &= \vec{J} \cdot d\vec{A} \\
 I &= \int \vec{J} \cdot d\vec{A}
 \end{aligned}$$

Why do I care about \vec{J} in the first place? When the electrons move in the wire, the external electric field forces them down the wire making those electrons move through a volume of the form $V = Al$. A is the crosssectional area of the wire, so current density let's us relate the movement of the electrons to the shape/geometry of the wire. \vec{J} flows through $d\vec{A}$. The stronger the external field, the larger the current density.

$$\begin{aligned}
 \vec{J} &\approx \vec{E} \\
 \vec{J} &= \sigma \vec{E} \\
 \vec{J} &= \frac{1}{\rho} \vec{E}
 \end{aligned}$$

σ is electric conductance, and ρ is electric resistivity. Further, $\rho = \frac{1}{\sigma}$. Both ρ and σ depend of the properties of the materials of the wire. You can think of σ as telling us how good of a conductor a given material is. Whereas, ρ tells us how poor of a conductor the material is.

Figure 4.9.3

$$\vec{E} = \rho \vec{J}$$

Let's consider uniform \vec{E} considering magnitudes:

$$\begin{aligned}
 E &= \rho J \\
 &= \rho \frac{I}{A}
 \end{aligned}$$

You can do this substitution because of the following:

$$\begin{aligned}\int dI &= \int \vec{J} \cdot d\vec{A} \\ &= \int J dA \\ &= J \int dA \\ I &= JA\end{aligned}$$

When electric charges are uniform we can calculate the voltage:

$$\begin{aligned}V &= - \int \vec{E} \cdot d\vec{l} \\ &= - \int E dl \\ &= -E \int dl \\ V &= -El\end{aligned}$$

Now substituting for E:

$$\begin{aligned}\frac{V}{l} &= \rho \frac{I}{A} \\ V &= I \rho \frac{l}{A}\end{aligned}$$

Where $R = \rho \frac{l}{A}$ called resistance.

Notice that R depends on material ρ and on geometry $\frac{l}{A}$

$$I = \frac{V}{R} = \frac{V}{\rho} \frac{A}{l}$$

Resistance depends on geometry and resistivity. Resistivity is a property of a material (intrinsic property). $R = \rho \frac{l}{A}$.

5.3.1 Example 1

Let's find the resistivity ρ for the power resistor. We know that $R = 10\Omega$. The length of the resistor is $L = 18cm$, and the area is $A = 2cm \times 1cm$. Using the equation above, we can solve for ρ and find

the resistance of the object.

$$\begin{aligned}
 R &= \rho \frac{l}{A} \\
 \rho &= R \frac{A}{L} \\
 \rho &= 10\Omega \left(\frac{2cm^2}{18cm} \right) \left(\frac{1m}{100cm} \right) \\
 \rho &= 0.01111\Omega m
 \end{aligned}$$

For comparison's sake, the resistivity of silver is $\rho_{silver} = 1.59 \times 10^{-8}\Omega m$.

5.3.2 Example 2

Resistors in series. There is a long resistor with another resistor right behind it (r_1, r_2, r_3). What is the net (equivalent) resistance? An electron goes from one resistor to the next and so on.

$$\begin{aligned}
 R &= \rho \frac{L}{A} \rightarrow L = R \frac{A}{\rho} \\
 L_{eq} &= L_1 + L_2 + L_3 \\
 R_{eq} \frac{A}{\rho} &= R_1 \frac{A}{\rho} + R_2 \frac{A}{\rho} + R_3 \frac{A}{\rho} \\
 R_{eq} &= R_1 + R_2 + R_3
 \end{aligned}$$

5.3.3 Example 2

Resistors in parallel. If resistors are in parallel, then the charges see the resistors as one large resistor. Analogous to a river. If a river widens, then the water slows down. Adding up the areas:

$$\begin{aligned}
 A_{eq} &= A_1 + A_2 + A_3 \\
 A &= \rho \frac{l}{R} \\
 \rho \frac{L}{R_{eq}} &= \rho \frac{L}{R_1} + \rho \frac{L}{R_2} + \rho \frac{L}{R_3} \\
 \frac{1}{R_{eq}} &= \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3}
 \end{aligned}$$

In series:

$$\begin{aligned}
 R_{eq} &= R_1 + R_2 + R_3 \\
 C_{eq} &= \left(\frac{1}{C_1} + \frac{1}{C_2} + \frac{1}{C_3} + \dots \right)
 \end{aligned}$$

In parallel:

$$\begin{aligned}
 R_{eq} &= \left(\frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_3} + \dots \right) \\
 C_{eq} &= C_1 + C_2 + C_3
 \end{aligned}$$

For some capacitors, if there are only two of them

$$\begin{aligned}
 C_{eq} &= \left(\frac{1}{C_1} + \frac{1}{C_2} \right)^{-1} \\
 &= \frac{1}{\frac{1}{C_1} + \frac{1}{C_2}} \\
 C_{eq} &= \frac{1}{\frac{1}{C_1} + \frac{1}{C_2}} \frac{C_1 C_2}{C_1 C_2} \\
 &= \frac{1}{\frac{C_2 + C_1}{C_1 C_2}} \frac{C_1 C_2}{1} \\
 \boxed{C_{eq} &= \frac{C_1 C_2}{C_1 + C_2}} \\
 \boxed{R_{eq} &= \frac{R_1 R_2}{R_1 + R_2}}
 \end{aligned}$$

Electrical Power

$$\begin{aligned}
 P &= \frac{dW}{dt} = \frac{dU}{dt} \\
 P &= \frac{d(qV)}{dt}
 \end{aligned}$$

For a given voltage, the power output is:

$$\begin{aligned}
 P &= V \frac{dq}{dt} \\
 P &= VI \\
 \boxed{P &= IV}
 \end{aligned}$$

For a circuit with a resistance R,

$$\begin{aligned}
 V &= IR \\
 \rightarrow P &= I^2 R \text{ and } P = \frac{V^2}{R}
 \end{aligned}$$

Household outlets in America supply 120 Volts. In order to change the power output of an appliance, we must adjust its resistance to change the current. We want $P_{max} = I_{max} V$. We know that $V = IR$.

$$I_{max} = \frac{V}{R_{max}}$$

For some resistor of resistance R, the power it outputs is $P = I^2 R$. The resistor will disipate energy as heat.

5.3.4 Example 3

Say a wire of diameter $d = 4mm$ has a current through it, $I = 6mA$. Assume a uniform current density.

$$\begin{aligned}dI &= \vec{J} \cdot d\vec{a} \\ \int dI &= \int J da \\ I &= J \int da \\ I &= JA \\ \boxed{J &= \frac{I}{A}}\end{aligned}$$


Recall,

$$\begin{aligned}\vec{E} &= \sigma \vec{J} \\ \rightarrow V &= IR\end{aligned}$$

5.4 Circuits and Circuit Analysis

Let's start with an example and then let's discuss the physical implications of the example after

5.4.1 Example 1



There is one current that describes this entire circuit. Let's let $V_0 = 11V$, $R_0 = 10k\Omega$, $R_1 = 12k\Omega$, and $R_2 = 35k\Omega$. To get I_0 we need to know R_{eq} . These resistors are all in series with each other. Because they are all in series, we know that:

$$\begin{aligned}R_{eq} &= R_0 + R_1 + R_2 \\ &= 57k\Omega\end{aligned}$$

Then with $V = IR$ we set:

$$V_0 = I_0 R_{eq}$$

$$\boxed{I_0 = \frac{V_0}{R_{eq}}}$$

$$I_0 = \frac{11V}{57k\Omega} = 0.193mA$$

If you start somewhere in a gravitational field, and you move something down, it has changed in its potential energy. Because electric force is conservative, a charge that travels any path and then comes back to its original location has no net change in potential energy

For a given loop,

$$\sum qV_{loop} = 0$$

$$\sum V_{loop} = 0$$

To use this, pick any starting location. Take a complete path that's called a loop and consider the change in voltage across various circuit elements. For a battery or a power supply, if you travel from the negative to the positive, you have an increase in voltage across the battery. Converse also works. For a resistor, if you are traveling with the current, voltage will drop across the resistor.

Let's try a clockwise loop from the top left corner.

$$\sum V_{loop} =$$

$$-I_0 R_0 - I_0 R_1 - I_0 R_2 + V_0 = 0$$

$$V_0 = I_0 (R_0 + R_1 + R_2)$$

$$V_{R_0} = -I_0 R_0 = (-0.193mA)(10k\Omega)$$

$$V_{R_0} = -1.93V$$


$$V_{R_1} = -2.32V$$

$$V_{R_2} = -6.76V$$

$$\boxed{\sum V_{loop} = -11.0V}$$

$$P_{R_0} = IV$$

$$IV = 0.37mW$$



5.4.2 Example 2

$$\sum V_{loop} = 0$$

$$a : -V_0 + I_1 R_1 = 0$$


$$b : -I_1 R_1 + I_2 R_2 = 0$$

$$\boxed{\sum I_{in} = \sum I_{out}}$$

$$x : I_0 = I_1 + I_2$$

$$y : I_1 + I_2 = I_0$$

There are basically two rules when it comes to circuit analysis. $\sum V_{loop} = 0$ and $\sum I_{in} = I_{out}$. This is essentially conservation of energy and conservation of charge. Let's consider the following circuit. Let's let $V_0 = 11V$, $R_1 = 12k\Omega$, and $R_2 = 35k\Omega$. First let's find the current directly out of the



battery.

$$R_{eq} = \frac{R_1 R_2}{R_1 + R_2} = 8.94k\Omega$$

$$V_0 = I_0 R_{eq}$$

$$\boxed{I_0 = \frac{V_0}{R_{eq}}}$$

$$I_0 = \frac{11V}{8.94k\Omega} = 1.23mA$$

$$P_0 = I_0 V_0 = (1.23mA)(11V) = 13.5mW$$

Now let's find the current through each resistor. Let's start with going from the battery to R_1 and back (a). and then going from R_2 through R_1 . The third loop could go from the battery to R_2 and back but it is not important to do so because all of the variables show up in these two equations already.

$$\sum V_{loop} = 0$$

$$a) V_0 - I_1 R_1 = 0$$

$$b) I_1 R_1 - I_1 R_2 = 0$$

$$\sum I_{in} = \sum I_{out}$$

$$x) I_0 = I_1 + I_2$$

$$y) I_1 + I_2 = I_0$$

We have already done the physics, and now we must solve for the things that we do not know. This is just basic algebra.

$$\rightarrow V_0 = I_1 R_1$$

$$I_1 = \frac{V_0}{R_0}$$

$$= \frac{11V}{12k\Omega}$$

$$\boxed{I_1 = 0.917mA}$$

$$\rightarrow I_2 = I_0 - I_1$$

$$= 1.23mA - 0.917mA$$

$$\boxed{I_2 = 0.313mA}$$

Now let's find the power of these two resistors. Remember $V = IR = I^2 R = \frac{V^2}{R}$

$$P_1 = I_1^2 R_1 = (0.917mA)^2 (12k\Omega)$$

$$P_1 = 10.1mW$$

$$P_2 = I_2^2 R_2 = (0.313mA)^2 (35k\Omega)$$

$$P_2 = 3.43mW$$

Notice that $P_1 + P_2 = 13.5mW$, which is the same amount of power that the batter puts out! Now let's find the voltage drops across $R_1 + R_2$ from IV

$$V_1 = \frac{P_1}{I_1} = \frac{10.1mW}{0.916mA}$$

$$V_1 = 11.0V$$


$$V_2 = \frac{P_2}{I_2} = \frac{3.43mW}{0.313mA}$$

$$V_2 = 11.0V$$

Notice that $V_1 = V_2 = V_0$. We get the same voltage across all three.

The voltage drops across parallel segments of circuit are equal. V_0 , R_1 , and R_2 are all in parallel, which means they all have the same voltage. We essentially did it with the first loop but we did not. Energy is conserved, but voltage is NOT conservative. To determine how to combine the resistors, you must first determine where the charge will flow.

5.4.3 Example (Draw Later)



There is a short within this circuit, which means it flows without resistance. Even with a short, you still calculate everything the same way. Let's find the current out of the battery and the power output of R_0

$$\sum V_{bat} = 0$$

$$\sum I_{in} = \sum I_{out}$$

A quick way to get I_0 is using $V_0 = I_0 R_{eq}$. Let's find R_{eq}

$$R_{eq} = R_0 \frac{R_{45} R_{123}}{R_{45} + R_{123}}$$

$$\text{Also, } R_{45} = R_4 + R_5$$

$$R_{123} = R_1 + \frac{R_2 R_3}{R_2 + R_3}$$

$$R_{eq} = R_0 + \frac{(R_4 + R_5) \left(R_1 + \frac{R_2 R_3}{R_2 + R_3} \right)}{R_4 + R_5 + R_1 + \frac{R_2 R_3}{R_2 + R_3}}$$

5.4.4 Using measuring tools

How to measure current using a digital multimeter.

To measure current, we must carefully add the ammeter to the circuit. To use an ammeter you must break the circuit. So in order to add an ammeter, first be sure the circuit is not currently powered! Plug the hole with the ammeter and then turn on the power supply.

How to measure voltage using a DMM.

Set the DMM to the voltmeter. Set the DMM to be a voltage. We then add the loads across the element whose voltage drop we want to measure. We must not break the circuit or turn off the power supply to measure the voltage.

Ammeters go into circuits and have low internal resistance, while voltmeters go across circuit elements and have high internal resistance.

5.5 Resistors and Capacitors in Circuits

$$V_R = IR$$

$$V_C = \frac{Q}{C}$$

When the switch is closed:

$$V_R = V_C = 0$$

Let's throw the switch to the position (a):

There are no junctions and there is only one loop:

$$\sum V_{loop} = 0$$

$$V_0 - IR - \frac{Q}{C} = 0$$

How much charge accumulates on the plates? What is Q in terms of capacitance, resistance, and the battery. The amount of charge that accumulates within the circuit is a property of the circuit only, whereas battery voltage, resistance, and capacitance are functions of themselves. Using $I = \frac{dQ}{dt}$, we get an equation that's a differential. We must get dQ with Q and we must get dt with t .

$$\begin{aligned}
 V_0 - R \frac{dQ}{dt} - \frac{Q}{C} &= 0 \\
 V_0 - \frac{Q}{C} &= R \frac{dQ}{dt} \\
 CV_0 - Q &= RC \frac{dQ}{dt} \\
 \frac{1}{RC} &= \frac{1}{CV_0 - Q} \frac{dQ}{dt} \\
 \frac{dt}{RC} &= \frac{dQ}{CV_0 - Q} \\
 \int_0^t \frac{dt}{RC} &= \int_0^Q \frac{dQ}{CV_0 - Q}
 \end{aligned}$$

Let $U = CV_0 - Q$, and $du = -dQ$:

$$\begin{aligned}
 \frac{1}{RC}(t - 0) &= \int_{CV_0}^{CV_0 - Q} \frac{-du}{u} \\
 \frac{t}{RC} &= -\ln \left(\frac{CV_0 - Q}{CV_0} \right) \\
 e^{-\frac{t}{RC}} &= \frac{CV_0 - Q}{CV_0} \\
 CV_0 e^{-\frac{t}{RC}} &= CV_0 - Q \\
 Q &= CV_0 - CV_0 e^{-\frac{t}{RC}} \\
 \boxed{Q(t) = CV_0 \left(1 - e^{-\frac{t}{RC}} \right)}
 \end{aligned}$$

Charging a capacitor

At $t = 0$

$$Q(0) = CV_0 \left(1 - e^{-\frac{0}{RC}} \right) = 0$$

After a long time, $Q = CV_0$

$$\begin{aligned}
 V_0 &= IR - \frac{CV_0}{C} = 0 \\
 V_0 - IR &= V_0
 \end{aligned}$$

This is only true if $I = 0$. If we take the derivative of our $Q(t)$ then we can see how current depends on time:

$$\begin{aligned} I(t) &= \frac{d}{dt}Q(t) \\ &= CV_0 \left(0 - \frac{-1}{RC} e^{-\frac{t}{RC}} \right) \end{aligned}$$

$$\boxed{I(t) = \frac{V_0}{R} e^{-\frac{t}{RC}}}$$

Charging a capacitor. Notice that RC has dimension of time.

6 Magnetism

This is very similar to electricity. Magnetic fields are created by moving electric charges. Magnetic fields are represented as \vec{B} . The force that a \vec{B} field exerts on a charge is $\vec{F} = q\vec{v} \times \vec{B}$, where q is the charge, \vec{v} is the velocity, and \vec{B} is the field the charge is in.

6.0.1 Example 1

An electron is moving with speed v to the right. An external field, \vec{B} , points into the page. Find the force on the charge. We are going to be using an x-y axis with z not shown, but it points into the picture. (Figure 6.1)

$$\vec{v} = v(-\hat{i}) = -v\hat{i}$$

$$\vec{B} = B\hat{k}$$

$$\vec{F} = -e\vec{v} \times \vec{B}$$

$$\vec{F} = F(-\hat{i})$$

Also, let's compute \vec{F}

$$\begin{aligned}\vec{F} &= q\vec{v} \times \vec{B} \\ &= (-e)(-v\hat{i}) \times (B\hat{k}) \\ &= ev\hat{i} \times B\hat{k} \\ &= evB(\hat{i} \times \hat{k}) \\ &= evB(-\hat{j})\end{aligned}$$

6.0.2 Example 2

Find the period of motion of a positive charge Q in an external magnetic field \vec{B} . Let $\vec{v} = v\hat{i}$ and $\vec{B} = B\hat{k}$. (Figure 6.2)

$$\vec{F} = Q\vec{v} \times \vec{B}$$

Cyclotron motion is the circular motion of a charge particle in a \vec{B} field. This is uniform circular motion. This means you cannot use a magnetic field to change speed. Magnetic fields do no work.

$$F = QvB\sin\theta$$

$$F = QvB$$

Let's equate this force with $\vec{F} = ma$

$$QvB = ma$$

$$QvB = m\frac{v^2}{R}$$

$$\frac{Q}{m} = \frac{v}{BR}$$

The period, T , of the field is given by $T = \frac{2\pi R}{v}$

$$T = \frac{2\pi R}{BR\frac{Q}{m}}$$

$$T = 2\pi \frac{m}{BQ}$$

$$f = \frac{1}{2\pi} B \frac{Q}{m}$$

This is the cyclotron period and the cyclotron frequency.

6.1 Creating Magnetic Fields

In the Biot Savart we know that electric chages that are moving create electric fields. In order to determine the direction we still must do the right hand rule. This is easier to visualize with a current (describes electromagnets.) Instead we are going to talk about a piece of charge:

$$\vec{B} = \frac{\mu_0}{4\pi} \frac{q\vec{v} \times \hat{r}}{r^2}$$

$$d\vec{B} = \frac{\mu_0}{4\pi} \frac{dq\vec{v} \times \hat{r}}{r^2}$$

This is the Biot-Savart Law

6.1.1 Example 1

Find magnetic field \vec{B} a distance d from an infinitely long wire carrying a current I make sure you always place the $d\vec{l}$ so it creates a triangle.

$$d\vec{B} = \frac{\mu_0}{4\pi} \frac{dq \frac{d\vec{l}}{dt} \times \hat{r}}{r^2}$$

$$= \frac{\mu_0}{4\pi} \frac{\frac{dq}{dt} d\vec{l} \times \hat{r}}{r^2}$$

$$= \frac{\mu_0}{4\pi} \frac{I d\vec{l} \times \hat{r}}{r^2}$$

Because the current changes over time, $\frac{dq}{dt} = I$. Current is moving charges so current moving on a wire thats dl long in a certain direction creates $d\vec{B}$. This is analagous to electric fields and solving for the electric field.

$$\vec{B} = \frac{\mu_0}{4\pi} I \int_{-\infty}^{\infty} \frac{d\vec{l} \times \hat{r}}{r^2}$$

We took the right hand rule to find the direction of \vec{B} but this does not tell us the magnitude of the vectors because $d\vec{l}$ is changing. We are going to use $\sin\theta$ where theta is the angle between $d\vec{l}$ and \hat{r} to make this easier to compute. \hat{r} is a unit vector so its magnitude is one. It is only there to help us find the direction.

$$\vec{B} = \frac{\mu_0}{4\pi} I \int_{-\infty}^{\infty} \frac{dl \sin(\theta)}{r^2}$$

Now we are going to take the $\sin\theta$ and change it into the coordinates we are using (xyz). We can figure out that $r^2 = x^2 + d^2$ and that $\sin\theta = \frac{d}{r}$

$$= \frac{\mu_0}{4\pi} I \int_{-\infty}^{\infty} \frac{dx}{x^2 + d^2} \frac{d}{\sqrt{x^2 + d^2}}$$

d is a constant of integration because the current doesn't change along d at all.

$$= \frac{\mu_0}{4\pi} Id \int_{-\infty}^{\infty} \frac{dx}{(x^2 + d^2)^{\frac{3}{2}}}$$

$$= \frac{\mu_0}{4\pi} Id \left[\frac{x}{d^2 \sqrt{x^2 + d^2}} \right]_{x=-\infty}^{x=\infty} \quad \text{out of page}$$

We are going to divide both the top and bottom by x because infinity cannot be at the top of a fraction.

$$d\vec{B} = \frac{\mu_0}{4\pi} Id \left[\frac{1}{d^2 \sqrt{1 + \frac{d^2}{x^2}}} \right]_{x=-\infty}^{x=\infty}$$

This is a problem because if we evaluate it now, we will get 0 as our magnetic field. Because of this we must do the following:

$$\vec{B} = 2 \frac{\mu_0}{4\pi} \frac{I}{d} \frac{1}{\sqrt{1 + \frac{d^2}{x^2}}} \Big|_{x=-\infty}^{x=\infty}$$

$$\vec{B} = \frac{\mu_0}{2\pi} \frac{I}{d} [1 - 0]$$

$$\boxed{\vec{B} = \frac{\mu_0 I}{2\pi d} \text{ out of page}}$$

There is an additional right hand rule. Put your thumb in the direction of the current wire, then your wrapped fingers will give the direction of \vec{B} .

6.1.2 Example 2

Remember that magnetic force is written as $\vec{F} = q\vec{v} \times \vec{B}$. In scenario 1 we are going to have a positive charge that is going to move initially to the right with some velocity v . It is about to enter a region with a magnetic charge that points into the page. What electric field can we add to the region to prevent the moving charge from deflecting? By the right hand rule, the particle is going to feel a force upward.

$$\vec{F}_B = q\vec{v} \times \vec{B}$$

$$\vec{F}_B = qvB, \text{ up}$$

We need \vec{E} to cause an equal force down so that $\vec{F}_{net} = 0$

$$\vec{F}_E = q\vec{E}$$

\vec{E} must point downward.

$$\begin{aligned} F_E &= F_B \\ qE &= qvB \\ E &= vB \end{aligned}$$

Now in scenario 2 we have a negative charge that is going to move initially to the right with a magnetic region pointing into the charge. With a negative charge and right hand rule, we must flip our hand over because of the negativity.

$$\begin{aligned} \vec{F}_B &= qvB, \text{ Down. we need} \\ \vec{F} &= q\vec{E} \text{ to point up.} \end{aligned}$$

We actually get the same answer as before. This is because they both depend on q, and if the sign on q changes, it changes on both sides of the equation.

In scenario 3, our charged particle will be positive and heading right, but the magnetic field is in line with the charge's movement.

$$\begin{aligned} \vec{F}_B &= q\vec{v} \times \vec{B} = 0 \\ \rightarrow &= qvB\sin(0) = 0 \end{aligned}$$

In this case we don't need an \vec{E} field at all to keep the charge from deflecting.

With scenario 4, we have a positive charge moving to the right into a magnetic field that has a diagonal vector.

$$\begin{aligned} \vec{F}_B &= q\vec{v} \times \vec{B} \\ F_B &= qvB_{\perp} \end{aligned}$$

We must cross with the vertical component of B because the horizontal is parallel and gives 0

$$\begin{aligned} \vec{F}_B &= qvB\sin(\theta), \text{ out of page} \\ \vec{E} &\text{ is into the page} \\ qE &= qvB\sin(\theta) \\ \rightarrow E &= vB\sin(\theta) \end{aligned}$$

6.1.3 Example 3

Let $\vec{B} = B(-\hat{j}) = -B\hat{j}$ and \vec{v} that initially looks like $\vec{v} = v_{0y}\hat{j} + v_{0z}\hat{k}$. What will the motion of q look like?

$$\begin{aligned}\vec{F} &= q\vec{v} \times \vec{B} \\ &= q(v_{0y}\hat{k} + v_{0z}\hat{j}) \times (-B\hat{j}) \\ &= -q(v_{0y}B(\hat{j} \times \hat{j}) + v_{0z}B(\hat{k} \times \hat{j})) \\ &= -qv_{0z}B(\hat{k} \times \hat{j}) \\ &= -qv_{0z}B(-\hat{i})\end{aligned}$$

$$\boxed{\vec{F}_0 = qv_{0z}B\hat{i}}$$

This will cause a helical motion: linear in \hat{j} and cyclotron in the \hat{i} and \hat{k} directions. Basically it creates a spring.

6.1.4 Example 4

Force on a current.

$$\vec{F} = q\vec{v} \times \vec{B}$$

Imagine a small amount of charge dq. The force exerted on this small amount of charge dq by an external field \vec{B} is:

$$d\vec{F} = dq\vec{v} \times \vec{B}$$

$$d\vec{F} = dq \frac{d\vec{l}}{dt} \times \vec{B}$$

$$d\vec{F} = \frac{dq}{dt} d\vec{l} \times \vec{B}$$

$$\boxed{d\vec{F} = Id\vec{l} \times \vec{B}}$$

If everything is uniform,

$$\begin{aligned}\int d\vec{F} &= \int Id\vec{l} \times \vec{B} \\ \vec{F} &= I\vec{l} \times \vec{B}\end{aligned}$$

6.1.5 Example 5

For a uniform external field, $\vec{B} = 4mT$ into the page, which way will a free wire move if the current as shown is $I = 2A$ CCW. Let $a = 10cm$. The force will be to the right.

$$\begin{aligned}\vec{F} &= I\vec{l} \times \vec{B} \\ F &= IlB \\ &= (2A)(10cm)(4mT) \\ &= (2A)(0.1m)(4 \times 10^{-3}T) \\ \boxed{\vec{F} = 8 \times 10^{-4}T}\end{aligned}$$

6.2 Hall Effect

Consider a metal plate. We will drive a current through this metal plate (figure 6.3). Let's add \vec{B} into the page. The current will feel a force acting upwards due to the right hand rule. This is because our fingers go to the right and curl to inside the page, the thumb gives us up which is the direction in which the force will move. These two figures are almost the same exact setup, but there is a change in the measured voltage.

If the measured voltage is positive, the current is made up of positively charged particles. If the measured voltage is negative, the current is made up of negative charged particles. It turns out that the charge carriers are negative (electrons).

6.2.1 Example 1

This is a Biot Savart example.

$$d\vec{B} = \frac{\mu_0}{4\pi} \frac{Id\vec{l} \times \hat{r}}{r^2}$$

Let's find \vec{B} at the center of an arc of current (figure 6.5). Remember that the cross product of $d\vec{l} \times \vec{B}$. For magnetic field, we put our thumb in the direction of the current and wrap our hands around to the direction of the field. The current is going to be going along the rod clockwise. \hat{r} is always going to be perpendicular to $d\vec{l}$ because I is always going to be pointing directly out of the circle, while r always points inward.

$$\begin{aligned}
 d\vec{B} &= \frac{\mu_0}{4\pi} I \frac{dl * 1 * \sin(90)}{r^2} \text{ into page} \\
 \int d\vec{B} &= \int \frac{\mu_0}{4\pi} I \frac{dl}{r^2} \text{ into page} \\
 \vec{B} &= \frac{\mu_0}{4\pi} I \int \frac{dl}{R^2} \text{ into page} \\
 \vec{B} &= \frac{\mu_0}{4\pi} \frac{I}{R^2} \int dl \\
 \vec{B} &= \frac{\mu_0}{4\pi} \frac{I}{R^2} \int R d\theta \\
 &= \frac{\mu_0}{4\pi} \frac{I}{R} \int d\theta \\
 \boxed{\vec{B} = \frac{\mu_0 I}{4\pi R} \theta \text{ into page}}
 \end{aligned}$$

For a full loop of current, $\theta = 2\pi$

$$\begin{aligned}
 \vec{B} &= \frac{\mu_0 I}{4\pi R} 2\pi \\
 \boxed{\vec{B} = \frac{\mu_0 I}{2R} \text{ into page}}
 \end{aligned}$$

If I was variable, then we couldn't pull it out of the integral, but the direction would remain the same.

6.3 Ampere's Law

Figure 6.6

$$\boxed{\oint \vec{B} \cdot d\vec{l} = \mu_0 I_{th}}$$

Very similar to Gauss' law. We must choose a path in which we can nicely handle the expression above.

$$\oint B dl = \mu_0 I_{th}$$

$$B \oint dl = \mu_0 I$$

$$B 2\pi r = \mu_0 I$$

$$\boxed{\vec{B} \frac{\mu_0 I}{2\pi r} \text{ CCW}}$$

If you were to pick $d\vec{l}$ to go to the wrong direction, the dot product results in zero so you get: $-\oint B dl = \mu_0(-I)$. The minuses cancel and you end up getting the same answer: $\vec{B} = \frac{\mu_0 I}{2\pi r}$

A solenoid is a coil of wire in the shape of a slinky (it stays in place) this is shown in figure 6.7. Magnetic field lines never start or stop and they never diverge, meaning they are always parallel. An ideal solenoid has a length much larger than it's radius ($L \gg R$). Solenoids are used in MRI machines, hence the name (Magnetic resonance imaging). They are the tube that people are pushed into.

6.3.1 Example 1

Imagine an infinite perfect solenoid (figure 6.8). Let's find \vec{B} for an ideal solenoid. The $d\vec{l}$ loop must encapsulate some form of current in order to be useful with this equation

$$\oint \vec{B} \cdot d\vec{l} = \mu_0 I_{th}$$

It is easiest to split this up into multiple loops because there are four sides for the rectangle we chose. We labeled the sides (1, 2, 3, 4) so we could label our integrals.

$$\int \vec{B} \cdot d\vec{l}_1 + \int \vec{B} \cdot d\vec{l}_2 + \int \vec{B} \cdot d\vec{l}_3 + \int \vec{B} \cdot d\vec{l}_4 = \mu_0 I_{th}$$

For the first integral, $\vec{B} \cdot d\vec{l}_1$ gives us bl . For the second and fourth integrals, the dot product equals zero. For the third segment, $\vec{B} = 0$ so we cannot do anything with that. The amount of current all along the loop is the same throughout. I is the current through each of the wires so the current through one wire is going to be I .

$$Bl + 0 + 0 + 0 = \mu_0 2I$$

In a more general case, let's say that N currents pierce through the Amperian loop.

$$Bl = \mu_0 NI$$

If for the whole solenoid length L :

$$BL_{tot} = \mu_0 N_{tot} I$$

$$B = \mu_0 \frac{N_{tot}}{L_{tot}} I$$

$B = \mu_0 n I$

 Where n is turns per length

If you want a bigger field you can either increase the current or put more turns in the current.

6.4 Magnetic Inductance

We will first consider Faraday's Law.

$$\Phi_B = \vec{B} \cdot d\vec{A}$$

Where Φ_B is magnetic flux.

$E_{ind} = -\frac{d}{dt}\Phi_B$

E_{ind} is also known as E.M.F. which is an induced voltage or potential.

6.4.1 Example 1

A \vec{B} field is into the page and increasing linearly in time: $B = b_0 \frac{t}{t_0}$. Find the direction and magnitude of current induced on a circular loop of wire with radius, r , and resistance, R , in plane with the page (figure 6.9). Electricity and magnetism are two different expressions of the same thing (electromagnetism). If a voltage is induced on a wire where we can calculate current we can just use Ohm's Law. We need a magnetic field that fluctuates in time. If the flux doesn't change in time then there is no induced electric field. While magnetic field is into the page everywhere, the resistor only cares about the magnetic field that is on the wire. It is okay that our B value does not have area dependence because we are calculating the flux of the magnetic field. We only need to discuss the area of magnetism when we get the flux.

$$\begin{aligned} \Phi_B &= \int \vec{B} \cdot d\vec{A} \\ &= \int \left(B_0 \frac{t}{t_0} \hat{k} \right) \cdot (dA \hat{k}) \\ &= B_0 \frac{t}{t_0} \int dA \\ &= B_0 \frac{t}{t_0} \pi r^2 \end{aligned}$$

Always find the flux before taking the time derivative. Now we are moving on to the time derivative:

$$\begin{aligned}\rightarrow \frac{d}{dt}\Phi_B &= \frac{d}{dt}B_0 \frac{t}{t_0} \pi r^2 \\ &= B_0 \frac{\pi r^2}{t_0}\end{aligned}$$

Recall that $E_{ind} = -\frac{d}{dt}\Phi_B$. The negative sign is because of Lenz's law. This basically just helps determine the direction of the magnitude of E_{ind} . Lenz's Law: The induced current $I_{ind} = \frac{E_{ind}}{R}$ has a direction such that B_{ind} opposes the change in flux, that is, $\frac{d}{dt}\Phi_B$. For this case, I_{ind} must flow counter-clockwise because it must oppose the change in the flux.

$$|E_{ind}| = \left| \frac{d}{dt}\Phi_B \right| = \left| B_0 \frac{\pi r^2}{t_0} \right|$$

$$I_{ind} = \frac{1}{R} B_0 \frac{\pi r^2}{t_0}, \text{ ccw}$$

Here are some other Lenz's law cases (figure 6.10). The equation for \vec{B} in this case is $\vec{B} = B \frac{t}{t_0} \hat{k}$. The flux is decreasing into the page so the B_{ind} is going to point into the page, which would mean that our I_{ind} is going clockwise. You oppose the change in the flux. You do not oppose the direction of the magnetic field.

Let's now look at figure 6.11. This figure has a square loop in the middle and we know that I_{int} goes clockwise because the magnetic force is going into the page and not out of the page. With $B = B_0 e^{\frac{t}{t_0}}$, there is no real change in this problem compare to the last. We must also understand that we deal with a square loop the same way we dealt with a circular one.

6.5 Eddy Currents

Similar to how if you're rowing a boat. As you pull your oar through the water you get little eddy's around the stick. These are magnetically induced currents that appear when Farade's law results in the slowing down of an object. This is a type of induced current. An example of this is sorting recyclables. You have a platform with a bunch of material heading down a slope. If the box is cardboard, then it will have an induced E_{mf} , but won't feel an induced current. If the recyclables are made from aluminum such as cans, then they will continue moving downward.

6.5.1 Motional Emf (E)

This goes along with figure 6.12. What direction will the force be in?

$$\begin{aligned}\vec{F} &= I \vec{l} \times \vec{B} \\ &= I_{ind} \vec{l} \times B_{ext}\end{aligned}$$

Say we pull such that the speed of the loop is constant. Because we already know the direction we are going to just use the magnitude to determine what E_{ind} is.

$$\begin{aligned}
 E_{ind} &= -\frac{d}{dt}\Phi_B \\
 |E_{ind}| &= \left| -\frac{d}{dt}\Phi_B \right| \\
 |E_{ind}| &= \frac{d}{dt}(BA) \\
 |E_{ind}| &= B\frac{d}{dt}A + A\frac{d}{dt}B \\
 &= B\left(L\frac{dx}{dt} + x\frac{dL}{dt}\right) \\
 &= BL\frac{dx}{dt}
 \end{aligned}$$

We know that the speed is not changing so we can come to the conclusion that:

$$\boxed{|E_{ind}| = B_{ext}Lv}$$

From Ohm's law:

$$\begin{aligned}
 E_{ind} &= I_{ind}R \\
 I_{ind} &= \frac{B_{ext}Lv}{R} \\
 P &= I_{ind}E_{ind} \\
 \boxed{P} &= \frac{B_{ext}^2 L^2 v^2}{R}
 \end{aligned}$$

6.6 Induced Electric Field

Farade's Law: $E_{ind} = -\frac{d}{dt}\Phi_B$ (Figure 6.13). This means that E_{ind} points the same direction as I_{ind} . This gives us that $\oint \vec{E}_{ind} \cdot d\vec{l} = -\frac{d}{dt}\Phi_B$. These charged particles must be in a loop in order to come to this conclusion. Farade's law helps us further relate the previous equation.

$$\oint \vec{E}_{ind} \cdot d\vec{l} = -\frac{d}{dt} \int \vec{B} \cdot d\vec{a}$$

A time varying magnetic flux induces an electric field. Electric and magnetic fields are frame dependent. They depend on what inertial frame they are in. An inertial frame is one in which there is no acceleration.

6.6.1 Induction Applied to Circuits

Let's consider a solenoid. If we apply a current then there will be a magnetic field throughout the inside of the solenoid. The best way to solve for the magnetic field within a solenoid is by using

Ampere's law, $B = \mu_0 n I$. The flux through the solenoid is:

$$\Phi_B = \int \vec{B} \cdot d\vec{a}$$

$$\Phi_B = B a$$

We can say that because the flux is proportional to the magnetic field, the flux is proportional to the current as well. We now introduce inductance L .

$$\Phi_B = L I$$

L depends on the solenoid's geometry.

$$N \Phi_B = L I$$

Where N is the number of turns in the solenoid

$$L = N \frac{\Phi_B}{I}$$

Let's find the E_{ind} of the solenoid

$$E_{ind} = -\frac{d}{dt} \Phi_B = -\frac{d}{dt} \left(\frac{L I}{N} \right)$$

$$E_{ind} = -\frac{L}{N} \frac{d}{dt} I$$

For a self induced emf:

$$E_{ind} = -L \frac{dI}{dt}$$

6.6.2 Example 1

Let's find the amount of energy stored in the magnetic field of a solenoid. First let's find the power.

$$|P| = IV = \left| -L I \frac{dI}{dt} \right|$$

We know that power is the change of energy over the change in time, this is why we are able to jump to the next step.

$$U = \int P dt$$

$$= \int L I \frac{dI}{dt} dt$$

$$= \int L I dI$$

$$U_B = \frac{1}{2} L I$$

Recall from electricity, $U_E = \frac{1}{2}CV^2$. In this case the charges are moving. With the magnetic energy equation, we are changing the energy for already moving charges.

6.7 List of Maxwell's Equations:

$$\int \vec{E} \cdot d\vec{a} = \frac{Q_{enc}}{\epsilon_0}$$

$$\oint \vec{B} \cdot d\vec{l} = \mu_0 I_{th}$$

$$\text{also } \oint \vec{B} \cdot d\vec{a} = 0$$

There are no magnetic charges/monopoles. Magnetic fields never terminate.

We have recently used Farade's law

$$E_{ind} = -\frac{d}{dt}\Phi_B$$

$$\oint \vec{E} \cdot d\vec{l} = -\frac{d}{dt} \int \vec{B} \cdot d\vec{a}$$

We will update Ampere's law to be:

$$\oint \vec{B} \cdot d\vec{l} = \mu_0 I_{th} + \mu_0 I_{disp}$$

$$\text{or } \oint \vec{B} \cdot d\vec{l} = \mu_0 \int \vec{J} \cdot d\vec{a} + \mu_0 \epsilon_0 \frac{d}{dt} \Phi_E$$

Where I_{disp} and $\epsilon_0 \frac{d}{dt} \Phi_E$ are the displacements of the currents

Example with the new Ampere's Law: Current changing with a capacitor (figure 6.13). We are allowing a bubble to encapsulate the leftmost plate where there is no loop. There must be a

changing electric flux to resolve this issue.

Gauss's Law:

$$\oint \vec{E} \cdot d\vec{a} = \frac{Q_{enc}}{\epsilon_0}$$

$$\oint \vec{B} \cdot d\vec{a} = 0$$

Farade's Law:

$$\oint \vec{E} \cdot d\vec{l} = -\frac{d}{dt} \int \vec{B} \cdot d\vec{a}$$

Ampere-Maxwell:

$$\oint \vec{B} \cdot d\vec{l} = \mu_0 \int \vec{J} \cdot d\vec{a} + \mu_0 \epsilon_0 \frac{d}{dt} \int \vec{E} \cdot d\vec{a}$$

Lorenty Force Law:

$$\vec{F} = q\vec{E} + q\vec{v} \times \vec{B}$$

Here's the differential form of all of these equations:

$$\vec{\nabla} = \frac{\partial}{\partial x} \hat{i} + \frac{\partial}{\partial y} \hat{j} + \frac{\partial}{\partial z} \hat{k}$$

$$\vec{\nabla} \cdot \vec{E} = \frac{\rho}{\epsilon_0}$$

$$\vec{\nabla} \cdot \vec{B} = 0$$

$$\vec{\nabla} \times \vec{E} = -\frac{\partial}{\partial t} \vec{B}$$

$$\vec{\nabla} \times \vec{B} = \mu_0 \vec{J} + \mu_0 \epsilon_0 \frac{\partial}{\partial t} \vec{E}$$

7 Optics

7.1 Traveling Waves

Let's first just consider a sine wave. We see that $y = \sin(x)$. Let's say that the y-axis is the vertical displacement vertically, and x-axis is the horizontal displacement. The amplitude is y_0 and $-y_0$. Our original equation needs a few fixes.

$$y = y_0 \sin(x)$$

Because you cannot take the sin of something in meters, we need to change this to be an angle. Pme full oscilation coresponds to $2\pi rad$ or λ distance

$$y = y_0 \sin\left(2\pi \frac{x}{\lambda}\right)$$

Sometimes we use the parameter called the wave number:

$$k = \frac{2\pi}{\lambda}$$
$$y = y_0 \sin(kx)$$

What if also the wave moves to the right at speed v (figure 6.16)? Let's take advantage of inertial frames. Let the prime axis (x' and y') travel with the wave. In the prime frame, $v' = 0$. We can write $y' = y'_0 \sin(kx')$. Now we want to get y based on y' . We can see that $y_0 = y'_0$. What about x and x' ?

$$\Delta x = v\Delta t = v(t - 0)$$
$$x - x' = vt$$

Both sides of this equation provide a positive displacement. And now to get y from y' , we will sub out x' for x .

$$y' = y_0 \sin(kx')$$
$$= y_0 \sin(kx')$$
$$y = y_0 \sin(k(x - vt))$$
$$y = y_0 \sin(kx - kvt)$$

Let's look at kv

$$\rightarrow kv = \frac{2\pi}{\lambda} v$$
$$= \frac{2\pi}{\lambda} \frac{\lambda}{T}$$
$$= \frac{2\pi}{T}$$
$$y = y_0 \sin\left(\frac{2\pi}{\lambda} x - \frac{2\pi}{T} t\right)$$

Notice that $\frac{2\pi}{T} = 2\pi f = \omega$ Where ω is the angular frequency.

$$y = y_0 \sin(kx - \omega t)$$

Recall from 1D kinematics: $x = x_0 + v_0 t + \frac{1}{2} a_x t^2$

We will add a phase constant Φ_0

$$\rightarrow y(x, t) = y_0 \sin(kx - \omega t + \phi_0)$$

The total phase is:

$$\phi = kx - \omega t + \phi_0$$

7.1.1 Example 1

The following \vec{E} and \vec{B} fields satisfy this set of four equations (figure 7.1)

$$\begin{aligned}\vec{E} &= E_0 \sin(kz - \omega t) \hat{i} \\ \vec{B} &= B_0 \sin(kz - \omega t) \hat{j}\end{aligned}$$

The pointing vector tells us the direction and magnitude of this combined electromagnetic wave. We must cross \vec{B} and \vec{E} in order to get the correct direction. In this case we are going to $\vec{E} \times \vec{B}$

$$\vec{S} \approx \vec{E} \times \vec{B}$$

In order to make this an equality we must add $\frac{1}{\mu_0}$.

$$\boxed{\vec{S} = \frac{1}{\mu_0} \vec{E} \times \vec{B}}$$

This means that electric fields do not need a median in order to move. Now let's figure out how fast this electromagnetic wave moves. We recently saw in class that $kv = \omega$. For this case we do find that $v = \frac{\omega}{k} = \frac{1}{\sqrt{\mu_0 \epsilon_0}}$. It was immediately noticed that light traveled at exactly this value. This is denoted as:

$$c = \frac{1}{\sqrt{\mu_0 \epsilon_0}} \approx 3 \times 10^8 \frac{m}{s}$$

It turns out that light is an electromagnetic wave! Optics is the applied study of electromagnetic waves.

7.2 Electromagnetic Spectrum

For light,

$$\begin{aligned}c &= \frac{\omega}{k} = \frac{2\pi f}{\frac{2\pi}{\lambda}} \\ c &= \lambda f\end{aligned}$$

Notice that we can change the wavelength or the frequency but the product must result in c. This gives us a spectrum of wavelengths we can choose.

In terms of wavelength, humans can see from violet ($\sim 400nm$) up to red ($\sim 600nm$). In terms of frequency, red is about 1.21×10^{14} and violet is around 7.86×10^{14}

7.3 Creating EM waves

Figure 7.2. I flip the switch up and change the capacitor to $Q_0 = cv_0$. Then I flip the switch to exclude the battery. The new circuit just excludes the battery. The charges are going to flow cw through the inductor, which rejects the current. The charges are going to equilibrate and the current is going to weaken. This is an oscillating current.

$$\omega = \frac{1}{\sqrt{lc}}$$

$$f = \frac{1}{2\pi} \frac{1}{\sqrt{lc}}$$

7.4 Pointing Vectors

Recall that we saw that we can make an EM wave with an LC oscillator circuit. The energy stored in an electric field in a capacitor is:

$$U_E = \frac{1}{2} CV^2$$

The energy density can be written more generally as, where u_E is the energy density and U_B is the potential energy:

$$u_E = \frac{U_E}{\text{volume}} = \frac{1}{2} \epsilon_0 E^2$$

The energy stored in a magnetic field in an inductor is:

$$U_B = \frac{1}{2} LI^2$$

The energy density can be written more generally as:

$$u_B = \frac{U_B}{\text{volume}} = \frac{1}{2} \frac{1}{\mu_0} B^2$$

Consider figure 7.1 again. On the EM wave, the energy density is:

$$u = u_E + u_B$$

$$u = \frac{1}{2} \epsilon_0 E^2 + \frac{1}{2} \frac{1}{\mu_0} B^2$$

$$u = \frac{1}{2} \epsilon_0 (cB)^2 + \frac{1}{2} \frac{1}{\mu_0} B^2$$

Recall that $c = \frac{1}{\sqrt{\epsilon_0 \mu_0}}$

$$u = \frac{1}{2} \epsilon_0 \frac{1}{\epsilon_0} B^2 + \frac{1}{2} \frac{1}{\mu_0} B^2$$

$$u = \frac{1}{\mu_0} B^2$$

Equivalently, because $B = \frac{E}{c}$:

$$\begin{aligned} \rightarrow u &= \frac{1}{\mu_0} \frac{E^2}{c^2} \\ &= \frac{1}{\mu_0} \epsilon_0 \mu_0 E^2 \\ \boxed{u &= \epsilon_0 E^2} \end{aligned}$$

Energy density in EM wave

An electromagnetic wave transports energy in its EM fields. This energy transport is called the pointing vector \vec{S} .

$$\begin{aligned} S &= \frac{\text{energy flux through area in time } \Delta t}{A \Delta t} \\ &= \frac{1}{\mu_0} EB \end{aligned}$$

$$\boxed{\text{In Vector Form, } \vec{S} = \frac{1}{\mu_0} \vec{E} \times \vec{B}}$$

$u(z, t)$ is the wave's energy density, so if i want the energy transport in time, we must multiply it by the volume to get energy.

$$\begin{aligned} u * \text{volume} &= u * A \\ S &= \frac{u A c \Delta t}{A \Delta t} = uc \\ &= \epsilon_0 E^2 c = \epsilon_0 (cE)(E) \end{aligned}$$

When we see light, our eye is detecting the EM waves in the pointing vector. Our brain arranges out the fast oscillations. So essentially, the intensity of light we see is the time-average pointing vector. Intensity is script i:

$$\begin{aligned} i &= S_{avg} = \left(\frac{1}{\mu_0} EB \right)_{avg} \\ &= \left(\frac{1}{\mu_0} E \frac{E}{c} \right)_{avg} \\ &= \frac{1}{\mu_0 c} (E^2)_{avg} \\ &\neq \frac{1}{\mu_0} (E_{avg})^2 \\ E &= E_0 \sin(kz - \omega t) \\ E_{avg} &= 0 \\ (E^2)_{avg} &= E_0^2 (\sin^2(kz - \omega t))_{avg} = \frac{1}{2} E_0^2 \\ i &= \frac{1}{\mu_0 c} \frac{E_0^2}{2} \end{aligned}$$

We can also write:

$$\sqrt{(E^2)_{avg}} = E_{rms}$$

$$E_{rms} = \frac{E_0}{\sqrt{2}}$$

More on intensity. The general definition of intensity is:

$$\mathcal{I} = \frac{P}{A}$$

Light has no mass, and there is no mass in electromagnetic fields. Although it doesn't have mass, it has momentum and pressure. Radiation pressure (P_{rad}):

$$P_{rad} = \frac{dW}{d} = \frac{\vec{F}_{rad} \cdot d\vec{z}}{dt} = \frac{F_{rad} dz}{dt}$$

$$P_{rad} = F_{rad} c$$

$$\mathcal{I} = \frac{P}{A}$$

$$= \frac{F_{rad} c}{A}$$

$$= \mathcal{P}_{rad} c$$

$$\rightarrow P_{rad} = \frac{\mathcal{I}}{c}$$

Note: $F = ma$ does not apply here, but Newton's second law, $\vec{F}_{net} = \frac{d}{dt}\vec{p}$. For a massive object,

$$\vec{p} = m\vec{v}$$

$$\vec{F}_{net} = \frac{d}{dt}(m\vec{v})$$

$$= m \frac{d}{dt}\vec{v}$$

$$= m\vec{a}$$

Here, we do not have mass in the EM wave. We cannot use $\vec{F} = m\vec{a}$ in any calculations.

Let's consider an EM wave that is incident on a surface. How much force will be exerted on the surface when the wave hits it? This depends on whether the wave is absorbed or reflected.

$$\vec{F} = \frac{\Delta\vec{p}}{\Delta t}$$

If the wave is reflected, how must $\Delta\vec{p}$ look? Let's call the initial momentum \vec{p}_0 .

$$\Delta\vec{p} = \vec{p}_+ - \vec{p}_0$$

$$= -2\vec{p}_0$$

By contrast, during an absorption,

$$\Delta\vec{p} = \vec{p}_f - \vec{p}_i$$

$$\Delta\vec{p} = -\vec{p}_0$$

With this, consider:

$$\mathcal{P}_{rad} = \frac{\mathcal{I}}{c}$$

$$\frac{F_{rad}}{A} = \frac{\mathcal{I}}{c}$$

$$F_{rad} = \frac{\mathcal{I} A}{c} = \frac{S_{avg} A}{c} \text{ Absorbtion}$$

For reflection we can just update the derivation:

$$F_{rad} = 2 \frac{\mathcal{I} A}{c} = 2 \frac{S_{avg} A}{c} \text{ Reflection}$$

If you would like to use EM waves to exert a force on something, it is twice as efficient to have the wave reflect instead of absorb. For example, a solar sail. Consider a satellite in space that has a solar sail that is being pushed by the electromagnetic waves of the sun. The sunlight will exert a force with reflection. Keep in mind that A is the sail's cross sectional area.

$$F_{rad} = 2 \frac{\mathcal{I} A}{c}$$

This is exerted on the sail

$$2 \frac{\mathcal{I} A}{c} = ma$$

$$a = \frac{2 \mathcal{I} A}{mc}$$

7.5 Polarization of Light

With a normal electromagnetic wave, $\vec{E} = E\hat{i} = E_0 \sin(kz - \omega t + \mathcal{P}_0)\vec{i}$ and $\vec{B} = B\hat{j} = B_0 \sin(kz - \omega t + \mathcal{P}_0)\vec{j}$. When such a wave $(\vec{S} = \frac{1}{\mu_0} \vec{E} \times \vec{B})$ reaches a surface, that surface can polarize the light. Light from the sun and lightbulbs are unpolarized. A polaroid is a thin material that polarizes light. It does so by building long parallel chains of molecules. When sunlight reflects off the road, it is largely polarized in plane with the road. So windshields are polarized vertically to block thin horizontal glare.

7.5.1 Example 1

This is an intensity example. A 18W light bulb is 1m away from a tennis ball (diameter of 12cm). How much energy has the tennis ball absorbed. Assume that the ball absorbs 70 percent of incident energy (figure 7.3). Let's assume the light bulb is isotropic (the same in all directions). Let's assume there's no reflection off the table for simplicity. How do we determine how much light goes towards the ball? First let's determine which variables cover which units. r is going to be the distance from the ball, and r_{ball} is the radius of the ball. $P_{light} = 18W$, $r = 1m$, $r_{ball} = 6cm = 0.06m$, $t = 1hr = 3600s$. More generally, let's say that $P_{light} = P_{src} = 18W$. First we need to determine the amount of power incident on the ball ("absorbed") is $P_{inc} = P_{src} \frac{a_{ball}}{a_{shell}}$. This is where a_{ball} is

the cross sectional area and a_{shell} is the surface area of the sphere.

$$\begin{aligned}
 P_{inc} &= P_{src} \frac{a_{ball}}{a_{shell}} \\
 &= P_{src} \frac{\pi r_{ball}^2}{4\pi r^2} \\
 \boxed{P_{inc} &= \frac{1}{4} P_{src} \frac{r_{ball}^2}{r^2}}
 \end{aligned}$$

This is the power incident on the tennis ball, but how intense is the light at the tennis ball?

$$\mathcal{I}_{attheball} = \frac{P_{src}}{A_{shellattheball}} = \frac{P_{src}}{4\pi r^2}$$

Notice that $P_{inc} = \mathcal{I}_{src} a_{ball}$. The energy absorbed in one hour is $\mathcal{E} = P_{inc} t$

$$\begin{aligned}
 \mathcal{E} &= \frac{0.7}{4} P_{src} \frac{r_{ball}^2}{r^2} t \\
 \mathcal{E} &= \frac{0.7}{4} (18W) \frac{(0.6m)^2}{(1m)^2} (3600s) \\
 \boxed{\mathcal{E} &= 40.8J}
 \end{aligned}$$

7.6 Geometric or Ray Optics

Reflection: consider a bullet. If we shoot a gun such that it hits the floor, it will bounce back (reflect off the surface) at a 90 degree angle from the angle it came in at. This is due to Newton's second law, every action must have an equal and opposite reaction (figure 7.4).

$$\begin{aligned}
 \vec{F} &= m\vec{a} \\
 \vec{F} &= \frac{\Delta \vec{p}}{\Delta t}
 \end{aligned}$$

The law of reflection states that $\theta_1 = \theta'_1$. Let's now consider light incident on a still surface of water (figure 7.5). The law of refraction is known as snell's law:

$$n_1 \sin \theta_1 = n_2 \sin \theta_2$$

n is the index of refraction. The value of n depends on the medium

$$n = \frac{c}{v}$$

For gasses a good approximation for n is 1. This also applies in a vacuum

$$\begin{aligned}
 n_{water} &= 1.333 \\
 n_{diamonds} &= 2.42
 \end{aligned}$$

The incident angle at which light will totally internally reflect is called the critical angle (θ_c). Now we are going to figure out what θ_c is.

$$\begin{aligned} n_1 \sin \theta_c &= n_2 \sin 90^\circ \\ \theta_c &= \arcsin \frac{n_2}{n_1} \end{aligned}$$

For diamond to air,

$$\begin{aligned} \theta_c &= \arcsin \frac{1}{2.42} \\ &= 24.4^\circ \end{aligned}$$

A great application of this idea is fiber optic cables. For wavelets in Refraction we will wait some time (Δt) for the wavelength to travel into the water. Keep in mind that light travels faster in air than in water.

7.7 Thin Lens Refraction

Look at figure 7.7. Here are the rules for ray diagrams (thin lenses):

- A ray through the center of the lens from the object goes straight through the lens.
- Parallel rays go through the focal point.

The crossing point from any two rays gives the image location. Real images are inverted. The thin lens equation is the following:

$$\frac{1}{f} = \frac{1}{d_o} + \frac{1}{d_i}$$

For this problem, let's find d_i .

$$\begin{aligned} \frac{1}{f} - \frac{1}{d_o} &= \frac{1}{d_i} \\ d_i &= \left(\frac{1}{f} - \frac{1}{d_o} \right)^{-1} \\ &= \left(\frac{1}{f} + \frac{1}{-d_o} \right)^{-1} \\ &= \frac{f(-d_o)}{f + (-d_o)} \\ d_i &= \frac{fd_o}{d_o - f} \\ &= \frac{(15cm)(46cm)}{46cm - 15cm} = 22.3cm \end{aligned}$$

With my ray diagram, I get 21.5cm, which is pretty close to 22.3cm

7.7.1 Example 1

Here $f = 15\text{cm}$ and $d_0 = 10\text{cm}$. This is figure 7.8. This gives is a virtual image. Virtual images are upright and cannot be seen/projected on a screen. Again, $\frac{1}{f} = \frac{1}{d_0} + \frac{1}{d_i}$ gives:

$$d_i = \frac{fd_0}{d_0 - f}$$
$$d_i = \frac{(15\text{cm})(10)}{(10\text{cm}) - (15\text{cm})} = -30\text{cm}$$

By hand on the board, we got -33cm. With a pen on gridpaper, we should be within 0.5cm.

The ratio of image height to object (with a minus sign) is called magnification.

$$m = \frac{h_i}{h_0} = \frac{-d_i}{d_0}$$

Here we have $m = \frac{h_i}{h_0} = \frac{37\text{cm}}{11.5\text{cm}} = 3.2$ also, if we calculate using d_i and d_0 , $m = -\frac{33\text{cm}}{10\text{cm}} = 3.3$

Diverging lens ray diagram (figure 7.9). Must treat f as negative.

$$d_i = \frac{fd_0}{d_0 - f} = \frac{(-15\text{cm})(47\text{cm})}{47\text{cm} - (-15\text{cm})}$$

I measure -11.4cm. This matches exactly. Now to calculate the magnification:

$$m = \frac{h_i}{h_0} = \frac{-d_i}{d_0}$$
$$= \frac{2.5\text{cm}}{10\text{cm}} \text{ or } -\frac{-11.4\text{cm}}{47\text{cm}}$$
$$= 0.25$$

7.8 Wave Interference

Let's recall from last class that we treated light as particle-like. For example, ray tracing. However at times, light acts like a wave. For context, let's consider water waves. Both waterwaves and light waves have interference. Let's think about an interferometer (figure 7.10). The interference equation is the following:

$$\text{difference in path length} = \text{integer number of } \lambda\text{s}$$

For our laser interferometer, this equation will give constructive interference.

$$2d_1 - 2d_2 = m\lambda$$

Where m is the integer from above. Now for destructive interference:

$$2d_1 - 2d_2 = m\lambda + \frac{1}{2}\lambda$$
$$2d_1 - 2d_2 = \left(m + \frac{1}{2}\right)\lambda$$

let's discuss more of what happens at an interface. Consider again light refracting from air to water. We know that $n_{\text{air}} = 1$ and $n_{\text{water}} = 1.33$. $n = \frac{c}{v}$. In waves, $v = \lambda f$. If in air or a vacuum, $c = \lambda f$, but in water $v = \lambda f$. Either λ or f needs to change because of the change in medium.

$$\frac{c}{n} = \frac{\lambda f}{n}$$

Do we want $\frac{c}{n} = \frac{\lambda}{n} f$ or $\frac{c}{n} = \lambda \frac{f}{n}$?

We cannot have the second option because frequency must be constant across the boundary. There is no way for the frequency to change as it goes through an interface. If this were the case then the frequency would increase when it comes back in contact with air.

7.8.1 Example 2

This involves thin film interference. On a soap bubble there are many different colors that reflect off of the bubble. We are going to assume that the soapy water has $n = 1.4$. Some of the light will reflect and some of the light will refract and then reflect off the inner surface. Recall that the interference equation is *diffinpathlength = integernumberof* λ s.

$$2t = m\lambda$$

This is on the right track but an important detail is missing.

In order to determine what this important detail that's missing is, we must consider first a wave phase shift. With a heavy rope knotted with a light rope, we can see that the wave from the rope is refracted, not reflected.

The following is true for light:

- From high n to low n , there is no phase change upon reflection.
- From low n to high n , there is a 180° or π rad or flip in phase, or $\frac{1}{2}\lambda$
- For refraction/transmission, there is never a phase change.

Earlier, we found $2t = m\lambda$. But we must still account for phase flips for reflections.

$$\text{diffinpathlength} = \text{integernumberof} \lambda \text{s}$$

$$2t + \frac{1}{2}\lambda = m\lambda$$

Because the changing of the color of the light occurs within the soapy bubble, we are going to use the wavelength of light in soapy water on both sides of our equation.

$$\begin{aligned} \rightarrow 2t + \frac{1}{2} \frac{\lambda_0}{n_{s.w.}} &= m \frac{\lambda_0}{n_{s.w.}} \\ 2t &= \left(m - \frac{1}{2}\right) \frac{\lambda_0}{n_{s.w.}} \text{ constructive} \\ 2t &= \left(m - \frac{1}{2}\right) \frac{\lambda_0}{n_{s.w.}} + \frac{1}{2} \frac{\lambda_0}{n_{s.w.}} \\ 2t &= m \frac{\lambda_0}{n_{s.w.}} \text{ destructive} \end{aligned}$$

Both the constructive and destructive are for $m = 1, 2, 3, 4, \dots$

7.9 Slit Interference

For a single slit diffraction, $\frac{a}{2} \sin \theta = m\lambda$ for construction, $m = 0, 1, 2$. For destructino, it is $a \sin \theta = m\lambda$, $m = 0, 1, 2$. For double slit interference, the constructive equation is $d \sin \theta = m\lambda$ for $m = 0, 1, 2$. Destructive is $d \sin \theta = (m + \frac{1}{2}) \lambda$. Notice that $\sin \theta = \frac{y_m}{\sqrt{y_m^2 + D^2}}$.

7.10 Crystallography

Also called Xr-ray diffraction or bragg diffraction. The following is a basic crystal (figure 7.11).

$$difference in path length = int num \lambda$$

$$\boxed{2d \sin \theta = m\lambda}$$

7.11 Electron Diffraction

Consider a single-slit setup. When shooting electrons at the slit, we also see an interference pattern. Electrons, then must also have wave characteristics. deBroglie:

$$\lambda_c = \frac{h}{p}$$

Where h is the Planchs constant.

7.12 Special Relativity

- 1860s Maxwell unifies electricity and magnetism.
- Light is an electromagnetic wave
- Waves require a medium
- In 1877, Nichelsen and mosley try to measure the luminous ether, the medium in which light must travel. They measured no change.

Einstein came up with two postulates to try to understand everythign that doesn't make sense (1905). The Principle of Relativity: The laws of physice are the same in all inertial (non-accelerating) frames. Invariance of c . Signals don't arrive instantaneously but propogate. Thus, there must be a maximum universal speed.

7.12.1 Example

Let's look at a light clock (figure 7.12). The left side of the figure is when the light clock is at rest. We can derive that $t_0 = \frac{2L_0}{c}$. The right side of the figure is when the light clock is at speed. We

know that the light is moving at $\sqrt{c^2 + u^2}$. Now let's put this into terms of light:

$$\begin{aligned}
 t &= \frac{2\sqrt{L_0^2 + \left(\frac{ut}{2}\right)^2}}{\sqrt{c^2 + u^2}} \\
 &= \frac{2\sqrt{\left(\frac{ct}{2}\right)^2 + \left(\frac{ut}{2}\right)^2}}{\sqrt{c^2 + u^2}} \\
 &= \frac{2\sqrt{\left(\frac{1}{2}\right)^2 [(ct)^2 + (ut)^2]}}{\sqrt{c^2 + u^2}} \\
 t &= \frac{t\sqrt{c^2 + u^2}}{\sqrt{c^2 + u^2}} \\
 t &= t
 \end{aligned}$$

However, this is NOT reality. From a special relativity (SR) approach things are different. Light always travels at c in all inertial reference frames. We can use the same figure as before but we much do a different analysis. Because the speed of light is always c , our analysis triangles from before does not work. The way the velocity vectors combine is different.

$$\begin{aligned}
 t &= \frac{2\sqrt{L_0^2 + \left(\frac{ut}{2}\right)^2}}{c} \\
 t &= \frac{2\left(\frac{ct_0}{2}\right)^2 + \left(\frac{ut}{2}\right)^2}{c} \\
 (ct)^2 &= (ct_0)^2 + (ut)^2 \\
 (ct)^2 - (ut)^2 &= (ct_0)^2 \\
 t^2(c^2 - u^2) &= (ct_0)^2 \\
 t^2 &= \frac{(ct_0)^2}{c^2 - u^2} \\
 t &= \frac{ct_0}{\sqrt{c^2 - u^2}} \\
 \boxed{t} &= t_0 \frac{1}{\sqrt{1 - \frac{u^2}{c^2}}}
 \end{aligned}$$

This is called Time Dilation. Time panes move slowly for moving objects.

Now let's say the clock ticks at rest with a time of $t_0 = 1\text{sec}$. In order to make the clock tick one percent slower, that is, $t = 1.01\text{sec}$, the clock must move at a speed of $42,000,000 \frac{m}{s}$!