



You might use a classical Xtal or a Low Power oscillator chip here.
In the case of using an oscillator chip, connect its output to the OSI and leave OSO open.



Date: 07.12.2020 18:39:19

TITLE: Pulsar P3 RepMOD

Sheet: 1/1